TravelMate 4740/4740G/4740Z/4740ZG Series Service Guide

Service guide files and updates are available on the ACER/CSD web; for more information, please refer to http://csd.acer.com.tw

PRINTED IN TAIWAN

Downloaded from www.Manualslib.com manuals search engine

Revision History

Please refer to the table below for the updates made on TravelMate 4740/4740G/4740Z/4740ZG Series service guide.

Date	Chapter	Updates

Downloaded from www.Manualslib.com manuals search engine

Copyright

Copyright © 2010 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation.
Intel is a registered trademark of Intel Corporation.
Pentium and Pentium II/III are trademarks of Intel Corporation.
Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Downloaded from www.Manualslib.com manuals search engine

Conventions

The following conventions are used in this manual:

SCREEN MESSAGES	Denotes actual messages that appear on screen.
NOTE	Gives bits and pieces of additional information related to the current topic.
WARNING	Alerts you to any damage that might result from doing or not doing specific actions.
CAUTION	Gives precautionary measures to avoid possible hardware or software problems.
IMPORTANT	Reminds you to do specific actions relevant to the accomplishment of procedures.

Downloaded from www.Manualslib.com manuals search engine

Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Chapter 1 System Introduction 1

Features 1
Your Acer Notebook Tour 11
Hotkeys 12
Closed Front View 13
Left View 13
Right View 13
Base View 14
Hardware Specifications and Configurations 15

Chapter 2 System Utilities 23

Phoenix SecureCore Setup Utility 23
Accessing the Setup Utility 24
Navigating through the Setup Utility 25
BIOS Setup Utility Menus 25
Information 26
Main 27
Security 28
Boot 31
Exit 32
Updating the BIOS 33

Chapter 3 Machine Disassembly and Replacement 35

Disassembly Requirements 35
General Information 36
Pre-disassembly Instructions 36
Disassembly Process 36
External Module Disassembly Process 37
External Modules Disassembly Flowchart 37
Removing the Battery Pack 38
Removing the Card Reader Dummy Card 38
Removing the Back Cover 39
Removing the Hard Disk Drive Module 39
Removing the DIMM Modules 41
Removing the WLAN Module 41
Main Unit Disassembly Process 43
Main Unit Disassembly Flowchart 43
Removing the Optical Drive 44
Removing the Keyboard 45
Removing the Upper Case 45
Removing the Power Button Board 49
Removing the Speakers 50
Removing the Touchpad Board 51
Removing the LCD Module 51
Removing the USB Board 53
Removing the Bluetooth Module 54
Removing the Mainboard 55

Downloaded from www.Manualslib.com manuals search engine

Removing the Heatsink Fan Module 56
Removing the Processor 57
LCD Module Disassembly Process 59
LCD Module Disassembly Flowchart 59
Removing the LCD Bezel 60
Removing the LCD Panel 61
Removing the LCD Hinges 62
Removing the Webcam Module 62
Removing the Microphone 63
Removing the WLAN Antennas 63

Chapter 4 Troubleshooting 65

System Check Procedures 66
External Diskette Drive Check 66
External Optical Drive Check 66
Keyboard or Auxiliary Input Device Check 66
Memory Check 67
Power System Check 67
Touchpad Check 68
Power-On Self-Test (POST) Error Message 68
Index of Error Messages 69
Error Codes 69
Error Messages 69
No Beep Error Messages 71
Phoenix BIOS Beep Codes 72
Symptom-to-FRU Error Messages 76
Intermittent Problems 79
Undetermined Problems 80
Block Diagram 81

Chapter 5 System Architecture 81

Mainboard Layout 82
Clearing a BIOS Password 85
Unlocking the HDD 86
BIOS Recovery 87
Creating the BIOS Crisis Recovery Disk in Windows 87
Performing a BIOS Recovery 87
Running the Flash Utility 87

Chapter 6 FRU (Field Replaceable Unit) List 89

Exploded Diagram 90
FRU List 91

Appendix A Model Definition and Configuration 99

TravelMate 4740 100
Travelmate 4740G 121
Travelmate 4740Z 144
Travelmate 4740ZG 145

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Appendix B Test Compatible Components **147**

Hardware Device Tests 148

Appendix C Online Support Information **151**

Index **153**

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

System Introduction

Features

Below is a brief summary of the TravelMate 4740/4740G/4740Z/4740ZG Series computer's many features.

TravelMate 4740/4740Z

Operating System

Travelmate 4740	Travelmate 4740Z
• Genuine Windows® 7 Professional 32-bit • Genuine Windows® 7 Home Premium 64-bit • Genuine Windows® 7 Home Basic 64-bit	• Genuine Windows® 7 Home Premium 64-bit • Genuine Windows® 7 Home Basic 64-bit

Platform

Travelmate 4740	Travelmate 4740Z
• Intel® Core i5-430M/i5-520M/i5-540M processor (3 MB L3 cache, 2.26/2.40/2.53 GHz with Turbo Boost up to 2.53/2.93/3.06 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Intel® Core™ i3-330M/i3-350M processor (3 MB L3 cache, 2.13/2.26 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Mobile Intel® HM55 Express Chipset	• Intel® Pentium® processor P6000 (3 MB L3 cache, 1.86 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Mobile Intel® HM55 Express Chipset

System Memory

Travelmate 4740	Travelmate 4740Z

• Dual-channel DDR3 SDRAM support
  • Up to 4 GB of DDR3 system memory, upgradable to 8 GB using two soDIMM modules5 (for 64-bit OS)
  • Up to 2 GB of DDR3 system memory, upgradable to 4 GB using two soDIMM modules6 (for 32-bit OS)
	• Dual-channel DDR3 SDRAM support:
	  • Up to 4 GB of DDR3 system memory, upgradable to 8 GB using two soDIMM modules5 (for 64-bit OS)
	  • Up to 2 GB of DDR3 system memory, upgradable to 4 GB using two soDIMM modules6 (for 32-bit OS)

Display

Travelmate 4740	Travelmate 4740Z
• 14" HD 1366 x 768 pixel resolution, high-brightness LED-backlit TFT LCD • Glare / anti-glare option • Mercury free, environment friendly	• 14" HD 1366 x 768 pixel resolution, high-brightness LED-backlit TFT LCD • Glare / anti-glare option • Mercury free, environment friendly

Downloaded from www.Manualslib.com manuals search engine

Graphics

Travelmate 4740	Travelmate 4740Z

• Intel® HD Graphics with 128 MB of dedicated system memory, supporting Microsoft® DirectX® 10
• Dual independent display support
• 16.7 million colors
• External resolution / refresh rates:
  • VGA port up to 2560 x 1600: 60 Hz
  • HDMI™ port up to 1920 x 1080: 60 Hz
• MPEG-2/DVD decoding
• WMV9 (VC-1) and H.264 (AVC) decoding
• HDMI™ (High-Definition Multimedia Interface) with HDCP (High-bandwidth Digital Content Protection) support
	• Intel® HD Graphics with 128 MB of dedicated system memory, supporting Microsoft® DirectX® 10
	• Dual independent display support
	• 16.7 million colors
	• External resolution / refresh rates:
	  • VGA port up to 2560 x 1600: 60 Hz
	  • HDMI™ port up to 1920 x 1080: 60 Hz
	• MPEG-2/DVD decoding
	• WMV9 (VC-1) and H.264 (AVC) decoding
	• HDMI™ (High-Definition Multimedia Interface) with HDCP (High-bandwidth Digital Content Protection) support

Storage subsystem

Travelmate 4740	Travelmate 4740Z
• 2.5" hard disk drive • DVD-Super Multi double-layer drive • Multi-in-1 card reader	• 2.5" hard disk drive • DVD-Super Multi double-layer drive • Multi-in-1 card reader

Audio

Travelmate 4740	Travelmate 4740Z
• Two built-in stereo speakers • High-definition audio support • Built-in microphone • MS-Sound compatible	• Two built-in stereo speakers • High-definition audio support • Built-in microphone • MS-Sound compatible

Storage

Travelmate 4740	Travelmate 4740Z
• 160/250/320/500/640 GB or larger hard disk drive • Multi-in-1 card reader, supporting Secure Digital™ (SD) Card, MultiMediaCard (MMC), Memory Stick™ (MS), Memory Stick PRO™ (MS PRO), xD-Picture Card™ (xD)	• 160/250/320/500/640 GB or larger hard disk drive • Multi-in-1 card reader, supporting Secure Digital™ (SD) Card, MultiMediaCard (MMC), Memory Stick™ (MS), Memory Stick PRO™ (MS PRO), xD-Picture Card™ (xD)

Optical Media Drive

Travelmate 4740	Travelmate 4740Z

• 8X DVD-Super Multi double-layer drive:
  • Read: 24X CD-ROM, 24X CD-R, 24X CD-RW, 8X DVD-ROM, 8X DVD-R, 8X DVD+R, 6X DVD-ROM DL, 6X DVD-R DL, 6X DVD+R DL, 6X DVD-RW, 6X DVD+RW, 5X DVD-RAM
  • Write: 24X CD-R, 16X CD-RW, 8X DVD-R, 8X DVD+R, 4X DVD-R DL, 4X DVD+R DL, 6X DVD-RW, 8X DVD+RW, 5X DVD-RAM
	• 8X DVD-Super Multi double-layer drive:
	  • Read: 24X CD-ROM, 24X CD-R, 24X CD-RW, 8X DVD-ROM, 8X DVD-R, 8X DVD+R, 6X DVD-ROM DL, 6X DVD-R DL, 6X DVD+R DL, 6X DVD-RW, 6X DVD+RW, 5X DVD-RAM
	  • Write: 24X CD-R, 16X CD-RW, 8X DVD-R, 8X DVD+R, 4X DVD-R DL, 4X DVD+R DL, 6X DVD-RW, 8X DVD+RW, 5X DVD-RAM

Downloaded from www.Manualslib.com manuals search engine

Communication

Travelmate 4740	Travelmate 4740Z

• Acer Video Conference, featuring:
  • Acer Crystal Eye webcam with 1280 x 1024 resolution
  • Acer Video Conference Manager software, featuring Video Quality Enhancement (VQE) technology, supporting 640 x 480 resolution online video calls
• WLAN:·
  • Acer InviLink™ Nplify™ 802.11b/g/n Wi-Fi CERTIFIED™
  • Acer InviLink™ 802.11b/g Wi-Fi CERTIFIED™
  • Supporting Acer SignalUp™ wireless technology
• WPAN:
  • Bluetooth® 3.0+HS
  • Bluetooth® 2.1+EDR
• LAN
  • Gigabit Ethernet, Wake-on-LAN ready
• WWAN
  • UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE (850/900/1800/ 1900 MHz) upgradeable to 7.2 Mb/s HSDPA and 5.7 Mb/s HSUPA
	• Acer Video Conference, featuring:
	  • Acer Crystal Eye webcam with 1280 x 1024 resolution
	  • Acer Video Conference Manager software, featuring Video Quality Enhancement (VQE) technology, supporting 640 x 480 resolution online video calls
	• WLAN:·
	  • Acer InviLink™ Nplify™ 802.11b/g/n Wi-Fi CERTIFIED™
	  • Acer InviLink™ 802.11b/g Wi-Fi CERTIFIED™
	  • Supporting Acer SignalUp™ wireless technology
	• WPAN:
	  • Bluetooth® 3.0+HS
	  • Bluetooth® 2.1+EDR
	• LAN
	  • Gigabit Ethernet, Wake-on-LAN ready
	• WWAN
	  • UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE (850/900/1800/ 1900 MHz) upgradeable to 7.2 Mb/s HSDPA and 5.7 Mb/s HSUPA

Privacy control

Travelmate 4740	Travelmate 4740Z
• BIOS user, supervisor, HDD passwords • Kensington lock slot	• BIOS user, supervisor, HDD passwords • Kensington lock slot

Dimensions and weight

Travelmate 4740	Travelmate 4740Z
• 342 (W) x 245 (D) x 26.3/33.2 (H) mm (13.5 x 9.6 x 1.03/1.31 inches) • 2.2 kg (4.85 lbs.) with 6-cell battery pack	• 342 (W) x 245 (D) x 26.3/33.2 (H) mm (13.5 x 9.6 x 1.03/1.31 inches) • 2.2 kg (4.85 lbs.) with 6-cell battery pack

Power subsystem

Travelmate 4740	Travelmate 4740Z

• ACPI 3.0 CPU power management standard: supports Standby and Hibernation power-saving modes
• 3-pin 65 W AC adapter:
  • 108 (W) x 46 (D) x 29.5 (H) mm (4.25 x 1.81 x 1.16 inches)
  • 225 g (0.49 lbs.) with 180 cm DC cable
• 48.8 W 4400 mAh 6-cell Li-ion standard battery pack
• Battery life: 4.0 hours
• ENERGY STAR®
	• ACPI 3.0 CPU power management standard: supports Standby and Hibernation power-saving modes
	• 3-pin 65 W AC adapter:
	  • 108 (W) x 46 (D) x 29.5 (H) mm (4.25 x 1.81 x 1.16 inches)
	  • 225 g (0.49 lbs.) with 180 cm DC cable
	• 48.8 W 4400 mAh 6-cell Li-ion standard battery pack
	• Battery life: 4.0 hours
	• ENERGY STAR®

Downloaded from www.Manualslib.com manuals search engine

Special keys and controls

Travelmate 4740	Travelmate 4740Z
• 88-/89-/93-key keyboard with inverted "T" cursor layout • 10 function keys, four cursor keys, two Windows® keys, hotkey controls, embedded numeric keypad, international language support, independent US dollar and Euro symbol keys • Multi-gesture touchpad, supporting two-finger scroll, pinch, rotate, flip • Media control keys (printed on keyboard): play/pause, stop, previous, next	• 88-/89-/93-key keyboard with inverted "T" cursor layout • 10 function keys, four cursor keys, two Windows® keys, hotkey controls, embedded numeric keypad, international language support, independent US dollar and Euro symbol keys • Multi-gesture touchpad, supporting two-finger scroll, pinch, rotate, flip • Media control keys (printed on keyboard): play/pause, stop, previous, next

I/O interface

Travelmate 4740	Travelmate 4740Z
• Multi-in-1 card reader (SD™, MMC, MS, MS PRO, xD) • Three USB 2.0 ports • HDMI™ port with HDCP support • External display (VGA) port • Headphone/speaker/line-out jack • Microphone-in jack • Ethernet (RJ-45) port • DC-in jack for AC adapter	• Multi-in-1 card reader (SD™, MMC, MS, MS PRO, xD) • Three USB 2.0 ports • HDMI™ port with HDCP support • External display (VGA) port • Headphone/speaker/line-out jack • Microphone-in jack • Ethernet (RJ-45) port • DC-in jack for AC adapter

Software

Travelmate 4740	Travelmate 4740Z
• Acer Backup Manager • Acer ePower Management • Acer eRecovery Management • Acer Optical Drive Power Management • Microsoft® Office Personal 2007 (Service Pack 2) (Japan only, subject to customer request) • Microsoft® Office Ready (Service Pack 2) • Google Toolbar™ • Adobe® Flash® Player 10 • Adobe® Reader® 9.1 • eSobi™ • Norton™ Online Backup • McAfee® Internet Security Suite Trial • Corel® WinDVD • NTI Media Maker™ • Acer 3G Connection Manager • Acer Crystal Eye • Acer Video Conference Manager • Microsoft® Silverlight™ • Skype™ • Windows Live™ Essentials - Wave 3.2 (Mail, Photo Gallery, Live™ Messenger, Movie Maker, Writer) • Acer Accessory Store1 (Belgium, France, Germany, Italy, Netherlands, Spain, Sweden, UK only) • Acer Assist • Acer Identity Card • Acer Registration	• Acer 3G Connection Manager • Acer Crystal Eye • Acer Launch Manager • Acer Video Conference Manager • Adobe® Flash® Player • Adobe® Reader® • Corel® WinDVD® • eSobi™ • Google™ Toolbar • McAfee® Internet Security Suite Trial • Microsoft® Office Professional 2007 Trial (Service Pack 2) • Microsoft® Office Personal 2007 (Service Pack 2) (Japan only) • Microsoft® Silverlight • Norton™ Online Backup • NTI Media Maker™ • Skype™ • Windows Live™ Essentials

Downloaded from www.Manualslib.com manuals search engine

• Acer Updater • eBay® shortcut 20091 (Canada, France, Germany, Italy, Mexico, Spain, UK, US only) • Netflix shortcut1 (US only)	

Optional Items

Travelmate 4740	Travelmate 4740Z
• 1 GB / 2 GB / 4 GB DDR3 1066 MHz soDIMM module • 6-cell Li-ion battery pack • 3-pin 65 W AC adapter	• 1 GB / 2 GB / 4 GB DDR3 1066 MHz soDIMM module • 6-cell Li-ion battery pack • 3-pin 65 W AC adapter

Warranty

Travelmate 4740	Travelmate 4740Z
One-year International Travelers Warranty (ITW)	One-year International Travelers Warranty (ITW)

Environment

Travelmate 4740	Travelmate 4740Z

• Temperature:
  • Operating: 5° C to 35° C
  • Non-operating: -20° C to 65° C
• Humidity (non-condensing):
  • Operating: 20%~80%
  • Non-operating: 20%~80%
	• Temperature:
	  • Operating: 5° C to 35° C
	  • Non-operating: -20° C to 65° C
	• Humidity (non-condensing):
	  • Operating: 20%~80%
	  • Non-operating: 20%~80%

Downloaded from www.Manualslib.com manuals search engine

Operating System

Travelmate 4740G	Travelmate 4740ZG
• Genuine Windows® 7 Professional 32-bit • Genuine Windows® 7 Home Premium 64-bit • Genuine Windows® 7 Home Basic 64-bit	• Genuine Windows® 7 Home Premium 64-bit • Genuine Windows® 7 Home Basic 64-bit

Platform

Travelmate 4740G	Travelmate 4740ZG
• Intel® Core i5-430M/i5-520M/i5-540M processor (3 MB L3 cache, 2.26/2.40/2.53 GHz with Turbo Boost up to 2.53/2.93/3.06 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Intel® Core™ i3-330M/i3-350M processor (3 MB L3 cache, 2.13/2.26 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Mobile Intel® HM55 Express Chipset	• Intel® Pentium® processor P6000 (3 MB L3 cache, 1.86 GHz, DDR3 1066 MHz, 35 W), supporting Intel® 64 architecture, Intel® Smart Cache • Mobile Intel® HM55 Express Chipset

System Memory

Travelmate 4740G	Travelmate 4740ZG

• Dual-channel DDR3 SDRAM support
  • Up to 4 GB of DDR3 system memory, upgradable to 8 GB using two soDIMM modules5 (for 64-bit OS)
  • Up to 2 GB of DDR3 system memory, upgradable to 4 GB using two soDIMM modules6 (for 32-bit OS)
	• Dual-channel DDR3 SDRAM support:
	  • Up to 4 GB of DDR3 system memory, upgradable to 8 GB using two soDIMM modules5 (for 64-bit OS)
	  • Up to 2 GB of DDR3 system memory, upgradable to 4 GB using two soDIMM modules6 (for 32-bit OS)

Display

Travelmate 4740G	Travelmate 4740ZG
• 14" HD 1366 x 768 pixel resolution, high-brightness LED-backlit TFT LCD • Glare / anti-glare option • Mercury free, environment friendly	• 14" HD 1366 x 768 pixel resolution, high-brightness LED-backlit TFT LCD • Glare / anti-glare option • Mercury free, environment friendly

Graphics

Travelmate 4740G	Travelmate 4740ZG
• NVIDIA® GeForce® GT 330M with up to 4091 MB of TurboCache™ (1024 MB of dedicated DDR3 VRAM, up to 3067 MB of shared system memory), supporting NVIDIA® CUDA™, PhysX™, PureVideo® HD technology, OpenEXR High Dynamic-Range (HDR) technology, Shader Model 4.0, Microsoft® DirectX® 10.1 • NVIDIA® GeForce® 310M with up to 3579 MB of TurboCache™ (512 MB of dedicated DDR3 VRAM, up to 3067 MB of shared system memory), supporting NVIDIA® CUDA™, PhysX™, PureVideo® HD technology, OpenEXR High Dynamic-Range (HDR) technology, Shader Model 4.0, Microsoft® DirectX® 10.1	• NVIDIA® GeForce® GT 330M with up to 4091 MB of TurboCache™ (1024 MB of dedicated DDR3 VRAM, up to 3067 MB of shared system memory), supporting NVIDIA® CUDA™, PhysX™, PureVideo® HD technology, OpenEXR High Dynamic-Range (HDR) technology, Shader Model 4.0, Microsoft® DirectX® 10.1 • NVIDIA® GeForce® 310M with up to 3579 MB of TurboCache™ (512 MB of dedicated DDR3 VRAM, up to 3067 MB of shared system memory), supporting NVIDIA® CUDA™, PhysX™, PureVideo® HD technology, OpenEXR High Dynamic-Range (HDR) technology, Shader Model 4.0, Microsoft® DirectX® 10.1

Downloaded from www.Manualslib.com manuals search engine

• Dual independent display support
• 16.7 million colors
• External resolution / refresh rates:
  • VGA port up to 2048 x 1536: 85 Hz
  • HDMI™ port up to 1920 x 1080: 60 Hz
• MPEG-2/DVD decoding
• WMV9 (VC-1) and H.264 (AVC) decoding
• HDMI™ (High-Definition Multimedia Interface) with HDCP (High-bandwidth Digital Content Protection) support
	• Dual independent display support
	• 16.7 million colors
	• External resolution / refresh rates:
	  • VGA port up to 2048 x 1536: 85 Hz
	  • HDMI™ port up to 1920 x 1080: 60 Hz
	• MPEG-2/DVD decoding
	• WMV9 (VC-1) and H.264 (AVC) decoding
	• HDMI™ (High-Definition Multimedia Interface) with HDCP (High-bandwidth Digital Content Protection) support

Storage subsystem

Travelmate 4740G	Travelmate 4740ZG
• 2.5" hard disk drive • DVD-Super Multi double-layer drive • Multi-in-1 card reader	• 2.5" hard disk drive • DVD-Super Multi double-layer drive • Multi-in-1 card reader

Audio

Travelmate 4740G	Travelmate 4740ZG
• Two built-in stereo speakers • High-definition audio support • Built-in microphone • MS-Sound compatible	• Two built-in stereo speakers • High-definition audio support • Built-in microphone • MS-Sound compatible

Storage

Travelmate 4740G	Travelmate 4740ZG
• 160/250/320/500/640 GB or larger hard disk drive • Multi-in-1 card reader, supporting Secure Digital™ (SD) Card, MultiMediaCard (MMC), Memory Stick™ (MS), Memory Stick PRO™ (MS PRO), xD-Picture Card™ (xD)	• 160/250/320/500/640 GB or larger hard disk drive • Multi-in-1 card reader, supporting Secure Digital™ (SD) Card, MultiMediaCard (MMC), Memory Stick™ (MS), Memory Stick PRO™ (MS PRO), xD-Picture Card™ (xD)

Optical Media Drive

Travelmate 4740G	Travelmate 4740ZG

• 8X DVD-Super Multi double-layer drive:
  • Read: 24X CD-ROM, 24X CD-R, 24X CD-RW, 8X DVD-ROM, 8X DVD-R, 8X DVD+R, 6X DVD-ROM DL, 6X DVD-R DL, 6X DVD+R DL, 6X DVD-RW, 6X DVD+RW, 5X DVD-RAM
  • Write: 24X CD-R, 16X CD-RW, 8X DVD-R, 8X DVD+R, 4X DVD-R DL, 4X DVD+R DL, 6X DVD-RW, 8X DVD+RW, 5X DVD-RAM
	• 8X DVD-Super Multi double-layer drive:
	  • Read: 24X CD-ROM, 24X CD-R, 24X CD-RW, 8X DVD-ROM, 8X DVD-R, 8X DVD+R, 6X DVD-ROM DL, 6X DVD-R DL, 6X DVD+R DL, 6X DVD-RW, 6X DVD+RW, 5X DVD-RAM
	  • Write: 24X CD-R, 16X CD-RW, 8X DVD-R, 8X DVD+R, 4X DVD-R DL, 4X DVD+R DL, 6X DVD-RW, 8X DVD+RW, 5X DVD-RAM

Downloaded from www.Manualslib.com manuals search engine

Communication

Travelmate 4740G	Travelmate 4740ZG

• Acer Video Conference, featuring:
  • Acer Crystal Eye webcam with 1280 x 1024 resolution
  • Acer Video Conference Manager software, featuring Video Quality Enhancement (VQE) technology, supporting 640 x 480 resolution online video calls
• WLAN:·
  • Acer InviLink™ Nplify™ 802.11b/g/n Wi-Fi CERTIFIED™
  • Acer InviLink™ 802.11b/g Wi-Fi CERTIFIED™
  • Supporting Acer SignalUp™ wireless technology
• WPAN:
  • Bluetooth® 3.0+HS
  • Bluetooth® 2.1+EDR
• LAN
  • Gigabit Ethernet, Wake-on-LAN ready
• WWAN
  • UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE (850/900/1800/ 1900 MHz) upgradeable to 7.2 Mb/s HSDPA and 5.7 Mb/s HSUPA
	• Acer Video Conference, featuring:
	  • Acer Crystal Eye webcam with 1280 x 1024 resolution
	  • Acer Video Conference Manager software, featuring Video Quality Enhancement (VQE) technology, supporting 640 x 480 resolution online video calls
	• WLAN:·
	  • Acer InviLink™ Nplify™ 802.11b/g/n Wi-Fi CERTIFIED™
	  • Acer InviLink™ 802.11b/g Wi-Fi CERTIFIED™
	  • Supporting Acer SignalUp™ wireless technology
	• WPAN:
	  • Bluetooth® 3.0+HS
	  • Bluetooth® 2.1+EDR
	• LAN
	  • Gigabit Ethernet, Wake-on-LAN ready
	• WWAN
	  • UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE (850/900/1800/ 1900 MHz) upgradeable to 7.2 Mb/s HSDPA and 5.7 Mb/s HSUPA

Privacy control

Travelmate 4740G	Travelmate 4740ZG
• BIOS user, supervisor, HDD passwords • Kensington lock slot	• BIOS user, supervisor, HDD passwords • Kensington lock slot

Dimensions and weight

Travelmate 4740G	Travelmate 4740ZG
• 342 (W) x 245 (D) x 26.3/33.2 (H) mm (13.5 x 9.6 x 1.03/1.31 inches) • 2.2 kg (4.85 lbs.) with 6-cell battery pack	• 342 (W) x 245 (D) x 26.3/33.2 (H) mm (13.5 x 9.6 x 1.03/1.31 inches) • 2.2 kg (4.85 lbs.) with 6-cell battery pack

Power subsystem

Travelmate 4740G	Travelmate 4740ZG

• ACPI 3.0 CPU power management standard: supports Standby and Hibernation power-saving modes
• 3-pin 90 W AC adapter:
  • 133 (W) x 59 (D) x 31 (H) mm (5.23 x 2.32 x 1.22 inches)
  • 390 g (0.86 lbs.) with 180 cm DC cable
• Acer QuicCharge™ technology:
  • 80% charge in 1 hour
  • 2-hour rapid charge system-off
• 48.8 W 4400 mAh 6-cell Li-ion standard battery pack
• Battery life: 2.7 hours
• ENERGY STAR®
	• ACPI 3.0 CPU power management standard: supports Standby and Hibernation power-saving modes
	• 3-pin 90 W AC adapter:
	  • 133 (W) x 59 (D) x 31 (H) mm (5.23 x 2.32 x 1.22 inches)
	  • 390 g (0.86 lbs.) with 180 cm DC cable
	• Acer QuicCharge™ technology:
	  • 80% charge in 1 hour
	  • 2-hour rapid charge system-off
	• 48.8 W 4400 mAh 6-cell Li-ion standard battery pack
	• Battery life: 2.7 hours
	• ENERGY STAR®

Downloaded from www.Manualslib.com manuals search engine

Special keys and controls

Travelmate 4740G	Travelmate 4740ZG
• 88-/89-/93-key keyboard with inverted "T" cursor layout • 10 function keys, four cursor keys, two Windows® keys, hotkey controls, embedded numeric keypad, international language support, independent US dollar and Euro symbol keys • Multi-gesture touchpad, supporting two-finger scroll, pinch, rotate, flip • Media control keys (printed on keyboard): play/pause, stop, previous, next	• 88-/89-/93-key keyboard with inverted "T" cursor layout • 10 function keys, four cursor keys, two Windows® keys, hotkey controls, embedded numeric keypad, international language support, independent US dollar and Euro symbol keys • Multi-gesture touchpad, supporting two-finger scroll, pinch, rotate, flip • Media control keys (printed on keyboard): play/pause, stop, previous, next

I/O interface

Travelmate 4740G	Travelmate 4740ZG
• Multi-in-1 card reader (SD™, MMC, MS, MS PRO, xD) • Three USB 2.0 ports • HDMI™ port with HDCP support • External display (VGA) port • Headphone/speaker/line-out jack • Microphone-in jack • Ethernet (RJ-45) port • DC-in jack for AC adapter	• Multi-in-1 card reader (SD™, MMC, MS, MS PRO, xD) • Three USB 2.0 ports • HDMI™ port with HDCP support • External display (VGA) port • Headphone/speaker/line-out jack • Microphone-in jack • Ethernet (RJ-45) port • DC-in jack for AC adapter

Software

Travelmate 4740G	Travelmate 4740ZG
• Acer Backup Manager • Acer ePower Management • Acer eRecovery Management • Acer Optical Drive Power Management • Microsoft® Office Personal 2007 (Service Pack 2) (Japan only, subject to customer request) • Microsoft® Office Ready (Service Pack 2) • Google Toolbar™ • Adobe® Flash® Player 10 • Adobe® Reader® 9.1 • eSobi™ • Norton™ Online Backup • McAfee® Internet Security Suite Trial • Corel® WinDVD • NTI Media Maker™ • Acer 3G Connection Manager • Acer Crystal Eye • Acer Video Conference Manager • Microsoft® Silverlight™ • Skype™ • Windows Live™ Essentials - Wave 3.2 (Mail, Photo Gallery, Live™ Messenger, Movie Maker, Writer) • Acer Accessory Store1 (Belgium, France, Germany, Italy, Netherlands, Spain, Sweden, UK only) • Acer Assist • Acer Identity Card	• Acer Backup Manager • Acer ePower Management • Acer eRecovery Management • Acer Optical Drive Power Management • Microsoft® Office Personal 2007 (Service Pack 2) (Japan only, subject to customer request) • Microsoft® Office Ready (Service Pack 2) • Google Toolbar™ • Adobe® Flash® Player 10 • Adobe® Reader® 9.1 • eSobi™ • Norton™ Online Backup • McAfee® Internet Security Suite Trial • Corel® WinDVD • NTI Media Maker™ • Acer 3G Connection Manager • Acer Crystal Eye • Acer Video Conference Manager • Microsoft® Silverlight™ • Skype™ • Windows Live™ Essentials - Wave 3.2 (Mail, Photo Gallery, Live™ Messenger, Movie Maker, Writer) • Acer Accessory Store1 (Belgium, France, Germany, Italy, Netherlands, Spain, Sweden, UK only) • Acer Assist • Acer Identity Card

Downloaded from www.Manualslib.com manuals search engine

• Acer Registration • Acer Updater • eBay® shortcut 2009 (Canada, France, Germany, Italy, Mexico, Spain, UK, US only) • Netflix shortcut1 (US only)	• Acer Registration • Acer Updater • eBay® shortcut 2009 (Canada, France, Germany, Italy, Mexico, Spain, UK, US only) • Netflix shortcut1 (US only)

Optional Items

Travelmate 4740G	Travelmate 4740ZG
• 1 GB / 2 GB / 4 GB DDR3 1066 MHz soDIMM module • 6-cell Li-ion battery pack • 3-pin 65 W AC adapter	• 1 GB / 2 GB / 4 GB DDR3 1066 MHz soDIMM module • 6-cell Li-ion battery pack • 3-pin 90 W AC adapter

Warranty

Travelmate 4740G	Travelmate 4740ZG
One-year International Travelers Warranty (ITW)	One-year International Travelers Warranty (ITW)

Environment

Travelmate 4740G	Travelmate 4740ZG

• Temperature:
  • Operating: 5° C to 35° C
  • Non-operating: -20° C to 65° C
• Humidity (non-condensing):
  • Operating: 20%~80%
  • Non-operating: 20%~80%
	• Temperature:
	  • Operating: 5° C to 35° C
	  • Non-operating: -20° C to 65° C
	• Humidity (non-condensing):
	  • Operating: 20%~80%
	  • Non-operating: 20%~80%

Downloaded from www.Manualslib.com manuals search engine

Your Acer Notebook Tour

NOTES: Case color may vary from that shown in the pictures.

Top View

#	Icon	Item	Description
1		Acer Crystal Eye webcam	Web camera for video communication. (only for certain models)
2		Microphone	Internal microphone for recording sound.
3		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output (configuration may vary by model).
4		Speakers	Left and right speakers deliver stereo audio output.
5		Keyboard	For entering data into your computer.
6		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
7		Power indicator	Indicates the computer's power status.
		Battery indicator	Indicates the computer's battery status. 1. Charging: The light shows amber when the battery is charging. 2. Fully charged: The light shows blue when in AC mode.
8		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.
9		Palmrest	Comfortable support area for your hands when you use the computer.

Downloaded from www.Manualslib.com manuals search engine

#	Icon	Item	Description
10		Communication indicator	Indicates the computer's communication status. (Function may vary by configuration.)
		HDD indicator	Indicates when the hard disk drive is active.
11		Power button	Turns the computer on and off.

Hotkeys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness and volume output.

To activate hotkeys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.

Hotkey	Icon	Function	Description
<Fn> + <F3>		Communication key	Enables / disables the computer's communication functions. (Function may vary by configuration.)
<Fn> + <F4>		Sleep	Puts the computer in Sleep mode.
<Fn> + <F5>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<Fn> + <F6>		Display off	Turns the display screen backlight off to save power. Press any key to return.
<Fn> + <F7>		Touchpad toggle	Turns the internal touchpad on and off.
<Fn> + <F8>		Speaker toggle	Turns the speakers on and off.
<Fn> + <F11>	NumLk	Num Lock	Turns the embedded numeric keypad on or off.
<Fn> + <F12>	Scr Lk	Scroll Lock	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.
<Fn> + <▷>		Brightness up	Increases the screen brightness.
<Fn> + <◁>		Brightness down	Decreases the screen brightness.
<Fn> + <△>		Volume up	Increases the sound volume.
<Fn> + <▽>		Volume down	Decreases the sound volume.
<Fn> + <Home>		Play/Pause	Play or pause a selected media file.
<Fn> + <Pg Up>		Stop	Stop playing the selected media file.
<Fn> + <Pg Dn>		Previous	Return to the previous media file.
<Fn> + <End>		Next	Jump to the next media file.

Downloaded from www.Manualslib.com manuals search engine

Closed Front View

#	Icon	Item	Description
1		Multi-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD). **Note:** Push to remove/install the card. Only one card can operate at any given time.

Left View



#	Icon	Item	Description
1		DC-in jack	Connects to an AC adapter.
2		Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.
3		Ventilation slots	Enable the computer to stay cool, even after prolonged use.
4		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
5		USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).

Right View



#	Icon	Item	Description
1		Headphones/speaker/line-out jack with S/PDIF support	Connects to audio line-out devices (e.g., speakers, headphones).
		Microphone jack	Accepts inputs from external microphones.
2		USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
3		Optical drive	Internal optical drive; accepts CDs or DVDs.
4		Optical disk access indicator	Lights up when the optical drive is active.
5		Optical drive eject button	Ejects the optical disk from the drive.

Downloaded from www.Manualslib.com manuals search engine

#	Icon	Item	Description
6		Emergency eject hole	Ejects the optical drive tray when the computer is turned off. **Note:** Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.
7		Kensington lock slot	Connects to a Kensington-compatible computer security lock.

Base View



#	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Hard disk bay	Houses the computer's hard disk (secured with screws).
4		Memory compartment	Houses the computer's main memory.
5		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. **Note**: Do not cover or obstruct the opening of the fan.
6		Battery lock	Locks the battery in position.

Downloaded from www.Manualslib.com manuals search engine

Hardware Specifications and Configurations

Processor

Item	Specification
CPU type	• Intel Core i5-540M (2.53 GHz) • Intel Core i5-520M (2.40 GHz) • Intel Core i5-430M (2.26 GHz) • Intel Core i3-350M (2.26 GHz) • Intel Core i3-330M (2.13 GHz) • Intel Pentium P6000 (1.86 GHz)
Core logic	Mobile Intel HM55 Express Chipset
CPU package	PGA 988, BGA1288

System Chipsets

Item	Specification
North bridge	• TravelMate 4740G/4740ZG: NVIDIA N11M-GE1-B-A3 with DDR3-800 512 MB VRAM NVIDIA N11P-GE1-A3 with DDR3-800 1GB VRAM • TravelMate 4740/4740Z: Integrated in the Mobile Intel HM55 Express Chipset
South bridge	Mobile Intel HM55 Express Chipset

System Controllers

Item	Controller
Core logic	Mobile Intel HM55 Express Chipset
VGA	• TravelMate 4740G/4740ZG: NVIDIA N11M-GE1-B-A3 with DDR3-800 512 MB VRAM NVIDIA N11P-GE1-A3 with DDR3-800 1GB VRAM • TravelMate 4740/4740Z: Integrated in the Mobile Intel HM55 Express Chipset
LAN	Broadcom BCM57780
3G	Ericsson F3307 mobile broadband module 900MHz
Bluetooth	• Foxconn Bluetooth BRM 2046 BT2.1 (T60H928.33) f/w:861 • Foxconn Bluetooth ATH AR3011 • Foxconn Bluetooth BRM 2070 (T77H114.01) • Foxconn Bluetooth BRM 2046 BT3.0 (T60H928.33) f/w:861 • Foxconn Bluetooth ATH AR3011 (BT3.0) • Foxconn Bluetooth BRM 2070 (T77H114.01) BT 3.0
Wireless 802.11 b/g/n	• Foxconn Wireless LAN Atheros HB93 2x2 BGN (HM) • Liteon Wireless LAN Atheris HB93 2x2 BGN (HM) WN6602AH • Foxconn Wireless LAN Broadcomm 43225 2x2 BGN (HM) T77H103.00 • Foxconn Wireless LAN Atheros HB97 2x2 BGN (HM) • Foxconn Wirelss LAN Atheros HB95 1x1 BG (HM) • LAN Intel WLAN 112BN.HMWG MM#903341 • LAN Intel WLAN INT1000HBG • LAN Intel WLAN 622AN.HMWG
Memory card reader	Alcor AU6433
Audio codec	Realtek ALC272
Keyboard	ENE3930

Downloaded from www.Manualslib.com manuals search engine

BIOS

Item	Specification
BIOS vendor	Phoenix
BIOS version	1.05
Supported protocols	ACPI 1.0b/2.0/3.0 compliance, PCI 2.2, System/HDD Password Security Control, INT 13H Extenstions, PnP BIOS 1.0a SMBIOS 2.4, BIOS Boot Specification, Simple Boot Flag 1.0, Boot Block, PCI Bus Power Management Interface Specification, USB Specification 1.1/2.0, IEEE 1394 1.0, USB/1394 CD-ROM Boot Up support, PC Card Standard 1995 (PCMCIA 3.0 Compliant Device), IrDA 1.0, Intel AC97 CNR Specification, WfM 2.0, PXE 2.1, Boot Integrity Service Application Program Interface (BIS) 1.0, PC99a and Mobile PC2001 Compliant

Video

Item	Specification
Chipset	• TravelMate 4740G/4740ZG: NVIDIA N11M-GE1-B-A3 with DDR3-800 512 MB VRAM NVIDIA N11P-GE1-A3 with DDR3-800 1GB VRAM • TravelMate 4740/4740Z: Integrated in the Mobile Intel HM55 Express Chipset
Memory size	• TravelMate 4740G/4740ZG model: DDR3-800 512 MB or 1GB VRAM

Ethernet

Item	Specification
LAN Chipset	Broadcom BCM57780
Supports LAN protocol	10/100/1000 Mbps
LAN connector type	RJ45
LAN connector location	Left side
Features	• Integrated 10/100 BASE-T transceiver • Wake on LAN support compliant with ACPI 2.0 • PCIE

Wireless LAN

Item	Specification
Chipset	• Foxconn Wireless LAN Atheros HB93 2x2 BGN (HM) • Liteon Wireless LAN Atheris HB93 2x2 BGN (HM) WN6602AH • Foxconn Wireless LAN Broadcomm 43225 2x2 BGN (HM) T77H103.00 • Foxconn Wireless LAN Atheros HB97 2x2 BGN (HM) • Foxconn Wirelss LAN Atheros HB95 1x1 BG (HM) • LAN Intel WLAN 112BN.HMWG MM#903341 • LAN Intel WLAN INT1000HBG • LAN Intel WLAN 622AN.HMWG
Protocol	802.11 b/g/n
Interface	PCI Express mini-card

3G Module

Item	Specification
Chipset	Ericsson F3307 mobile broadband module 900MHz
Data Speeds	• HSPA Data speed — D/L 7.2Mbps, U/L 2.0Mbps • EDGE/GPRS Data speed — D/L: 247.4Kbps, U/L: 123.7Kbps
Interface	PCI Express mini-card

Downloaded from www.Manualslib.com manuals search engine

Bluetooth

Item	Specification
Chipset	• Foxconn Bluetooth BRM 2046 BT2.1 (T60H928.33) f/w:861 • Foxconn Bluetooth ATH AR3011 • Foxconn Bluetooth BRM 2070 (T77H114.01) • Foxconn Bluetooth BRM 2046 BT3.0 (T60H928.33) f/w:861 • Foxconn Bluetooth ATH AR3011 (BT3.0) • Foxconn Bluetooth BRM 2070 (T77H114.01) BT 3.0
Data throughput	Up to 24 Mbps
Protocol	Bluetooth 2.1
Interface	USB 2.0
Connector type	USB

System Memory

Item	Specification
Memory controller	Built-in
Vendor & model name	Elpida • SO-DIMM DDRIII 1066 1GB EBJ10UE8BDS0-AE-F LF 128*8 0.065um • SO-DIMM DDRIII 1333 1GB EBJ10UE8BDS0-DJ-F LF 128*8 0.065um • SO-DIMM DDRIII 1066 2GB EBJ21UE8BDS0-AE-F LF 128*8 0.065um • SO-DIMM DDRIII 1333 2GB EBJ21UE8BDS0-DJ-F LF 128*8 0.065um • SO-DIMM DDRIII 1333 4GB EBJ41UF8BAS0-DJ-F LF 256*8 0.055um Hynix • SO-DIMM DDRIII 1333 1GB HMT112S6TFR8C-H9 LF 128*8 0.055u • SO-DIMM DDRIII 1333 2GB HMT125S6TFR8C-H9 LF 128*8 0.055um Kingston • Micron • SO-DIMM DDRIII 1066 1GB MT8JSF12864HZ-1G1F1 LF 128*8 0.065um • SO-DIMM DDRIII 1066 2GB MT16JSF25664HZ-1G1F1 LF 128*8 0.065um Nanya • SO-DIMM DDRIII 1333 2GB NT2GC64B8HC0NS-CG LF 128*8 0.065um Samsung • SO-DIMM DDRIII 1066 1GB M471B2873EH1-CF8 LF 64*16 0.055um • SO-DIMM DDRIII 1333 1GB M471B2873FHS-CH9 LF 128*8 46nm • SO-DIMM DDRIII 1066 2GB M471B5673EH1-CF8 LF 128*8 0.055um • SO-DIMM DDRIII 1333 2GB M471B5673FH0-CH9 LF 128*8 46nm • SO-DIMM DDRIII 1333 4GB M471B5273CH0-CH9 LF 256*8 46nm
Memory size	0 MB (no on-board memory)
SO-DIMM socket number	2 sockets
Supports memory size per socket	4 GB
Supports maximum memory size	8 GB
Supports SO-DIMM type	DDR3 synchronous DRAM
Supports DIMM Speed	1066/1333 MT/s
Supports SO-DIMM package	204-pin SO-DIMM
Memory module combinations	You can install memory modules in any combinations as long as they match the above specifications.

Downloaded from www.Manualslib.com manuals search engine

Memory Combinations

Slot 1	Slot 2	Total Memory
0 GB	1 GB	1 GB
0 GB	2 GB	2 GB
0 gb	4 GB	4 GB
1 GB	0 GB	1 GB
1 GB	1 GB	2 GB
1 GB	2 GB	3 GB
1 GB	4 GB	5 GB
2 GB	0 GB	2 GB
2 GB	1 GB	3 GB
2 GB	2 GB	4 GB
2 GB	4 GB	5 GB
4 GB	0 GB	4 GB
4 GB	1 GB	5 GB
4 GB	2 GB	6 GB
4 GB	4 GB	8 GB

NOTE: Above table lists some system memory configurations. You may combine DIMMs with various capacities to form other combinations. On above table, the configuration of slot 1 and slot 2 could be reversed.

Hard Disk Drive

Item	Specification				
Vendor & Model Name	Seagate ST9160314AS Toshiba MK1665GSX HGST HTS545016B9A300 WD WD1600BEVT-22A23T0	Seagate ST9250315AS Toshiba MK2565GSX HGST HTS545025B9A300 WD WD2500BEVT-22A23T0	Seagate ST9320325AS Toshiba MK3265GSX HGST HTS545032B9A300 WD WD3200BEVT-22A23T0	Seagate ST9500325AS Toshiba MK5065GSX HGST HTS545050B9A300 WD WD5000BEVT-22A0RT0	Toshiba MK6465GSX WD WD6400BEVT-22A0RT0
Capacity (GB)	160	250	320	500	640
Bytes per sector	512	512	512	512	512
Data heads	3/4	4	4	4	4
Drive Format					
Disks	2	1	2	2	2
Spindle speed (RPM)	5400	5400	5400	5400	5400
Performance Specifications					
Buffer size (MB)	8	8	8	8	8
Interface	SATA	SATA	SATA	SATA	SATA
Max. media transfer rate (disk-buffer, Mbytes/s)	540	540	850	3.0 GB/s Max. Buffer to Host	3.0 GB/s

Downloaded from www.Manualslib.com manuals search engine

Hard Disk Drive

Item	Specification				
DC Power Requirements					
Voltage tolerance	5V (DC) +/- 5%	5V (DC) +/- 5%	5V (DC) +/- 5%	5V (DC) +/- 5%	5V (DC) +/- 5%

LCD Panel

Item	Specification
Vendor & model name	AUO • 14" WXGA None Glare B140XW01 V9 0A LF 200nit 8ms 400:1 • 14" WXGA Glare B140XW01 V8 0A LF 220nit 8ms 500:1 (power saving) LG • 14" WXGA Glare LP140WH1-TLA2 LF 220nit 8ms 500:1 Samsung • 14" WXGA None Glare LTN140AT01-001 LF 220nit 8ms 300:1 • 14" WXGA Glare LTN140AT01-G03 LF 220nit 8ms 500:1 CMO • 14" WXGA Glare N140B6-L02 C2 LF 220nit 8ms 400:1
Screen Diagonal	14 inches
Resolution support	• 1366 x 768 • 1360 x 768 • 1280 x 768 • 1280 x 720 • 1024 x 768 • 800 x 600
Pixel Pitch (mm)	0.2265
Pixel Arrangement	R.G.B. Vertical Stripe
Display Mode	Normally White
Typical White Luminance (NIT) also called Brightness	200 - 220
Contrast Ratio	500:1
Response Time msec	8
Power consumption (W)	3.8 - 4.2
Viewing Angle (U/D/R/L)	20/45/45/45
Interface	1ch LVDS
Supply voltage (V)	3.3
Temperature Range(° C) Operating Storage (shipping)	 0 to +50 -40 to +60

Webcam

Item	Specification
Vendor & model name	Chicony • CH9665SN (CNF9157) Suyin • SY9665SN Liteon • LT6AASP (09P2BF127)
Resolution	1.3 M
DV capability	Yes

Downloaded from www.Manualslib.com manuals search engine

AC Adapter

Item	Specification
Vendor	Delta • 65 W ADP-65JH DB • 90 W ADP-90CD DB Liteon • 65 W PA-1650-22AC • 90 W PA-1900-34AR Hipro • 65 W HP-A0652R3B • 90 W HP-A0904A3 B1LF
Input	90 - 264 Vac
Output	19 V / 3.42 - 4.74 A

Battery Pack

Item	Specification
Vendor	Panasonic/Sanyo/Sony/Simplo
Battery Type	Li-ion
Pack capacity	6-cell 4400 mAh
Number of battery cell	6
Package configuration	3 cells in series, 2 series in parallel

System Power Management

ACPI mode	Power Management
Mech. Off (G3)	All devices in the system are turned off completely.
Soft Off (G2/S5)	OS initiated shutdown. All devices in the system are turned off completely.
Working (G0/S0)	Individual devices such as the CPU and hard disc may be power managed in this state.
Suspend to RAM (S3)	• CPU set power down • VGA Suspend • PCMCIA Suspend • Audio Power Down • Hard Disk Power Down • CD-ROM Power Down • Super I/O Low Power mode
Save to Disk (S4)	Also called Hibernation Mode. System saves all system states and data onto the disc prior to power off the whole system.

Physical Specifications

Item	Specification
Dimension (W×D×H)	343mm x 245mm x 26.1 - 32.6mm
Weight	< 2.2kg

Environmental Requirements

Item	Specification
Operating temperature	5 to 35 °C (41 to 95 °F)
Operating humidity	20% to 80% RH non-condensing

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

System Utilities

Phoenix SecureCore Setup Utility

Phoenix SecureCore Setup Utility is a hardware configuration program built into your system's Basic Input/ Output System (BIOS). Since most systems are already properly configured and optimized, there is normally no need to run this utility.

You will need to run this utility under the following conditions:

- When changing the system configuration including:
  - Setting the system time and date
  - Configuring the hard drives
  - Specifying the boot device sequence
  - Configuring the power management modes
  - Setting up system passwords or making other changes to the security setup
- When a configuration error is detected by the system and you are prompted ("**Run Setup**" message) to make changes to the BIOS settings.

IMPORTANT: If you repeatedly receive "**Run Setup**" messages, the RTC battery located on the mainboard (RTC1) may be defective. In this case, the system cannot retain configuration values in CMOS. Replace the RTC battery with a new one.

NOTE: For ease of reading, Phoenix SecureCore Setup Utility will be simply referred to as "Setup" or "Setup Utility" in this Service Guide.

In the descriptive tables following each of the menu screen illustrations, settings in **boldface** are the default and suggested parameter settings.

The Setup Utility loads the configuration values in a battery-backed nonvolatile memory called CMOS RAM. This memory area is not part of the system RAM, which allows configuration data to be retained when power is turned off. The values take effect when the system is booted. POST uses these values to configure the hardware. If the values and the actual hardware do not agree, POST generates an error message. You must run this utility to change the BIOS settings from the default or current configuration.

Downloaded from www.Manualslib.com manuals search engine

Accessing the Setup Utility

1. Turn on the system.

   If the system is already turned on, save your data and close all open applications, then restart the computer.

2. During POST, press <**F2**>.

   If you fail to press <**F2**> before POST is completed, you will need to restart the computer. Use the **left** and **right** arrow keys to move between selections on the menu bar


Phoenix SecureCore(tm) Setup Utility
Information
Main
Security
Boot
Exit
CPU Type: Intel (R) Core (TM) i5 CPU M 430 @2.27 GHz
CPU Speed: 2260 MHZ
IDE0 Model Name: Hitachi HTS545032B9A300-(S1)
IDE0 Serial Number: 100217PBPC061DCAKXLL
ATAPI Model Name: Optiarc DVD RW AD-7585H-(S5)
System BIOS Version: V1.04
VGA BIOS Version: 70.18.49.00.07
KBC Version: 01.05
Serial Number: 914JD01002G009B01EB2000
Asset Tag Number: No Asset Tag
Product Name: TravelMate 4740
Manufacturer Name: Acer
UUID: 373dd280-2d84-11df-9ce1-b8c80ef75913
F1 Help ↑↓ Select Item F5/F6 Change Values F9 Setup Defaults
Esc Exit ↔ Select Menu Enter Select ▸Sub-Menu F10 Save and Exit

Downloaded from www.Manualslib.com manuals search engine

Navigating through the Setup Utility

Use the keys listed in the legend bar on the bottom of the Setup screen to work your way through the various menu and submenu screens of the Setup Utility. The table below lists these legend keys and their respective functions.

Key	Function
Left and Right arrow	To move between selections on the menu bar.
Up and Down arrow	To move the cursor to the field you want.The currently selected field will be highlighted. The right side of each menu screen displays a field help panel—Item Specific Help panel. This panel displays the help text for the currently selected field. It updates as you move the cursor to each field. To view a submenu screen, use the up and down keys to move the cursor to the submenu you want, then press **Enter**.
F5 and F6	To select a value for the currently selected field (only if it is user-configurable). Press these keys repeatedly to display all possible entries. A parameter that is enclosed in square brackets [ ] is user-configurable. Grayed-out parameters are not user-configurable for one of the following reasons: ❑ The field value is auto-configured or auto-detected.· ❑ The field value is informational only. ❑ The field is password-protected.
Enter	To select a field value (a pop-up menu displays) or submenu screen.
Esc	If you press this key: ❑ On one of the primary menu screens, the Exit menu displays. ❑ On a submenu screen, the previous screen displays. ❑ When you are making selections from a pop-up menu, closes the pop-up without making a selection.
F1 or Alt-H	To bring up the General Help window. The General Help window describes other Setup navigation keys that are not displayed on the legend bar.
F9	Press to load default system values.
F10	Press to save changes and close the Setup Utility.

BIOS Setup Utility Menus

The Setup Utility has five menus for configuring the various system functions. These include:

- Information
- Main
- Security
- Boot
- Exit

IMPORTANT: The screenshots used in this section are for illustration only. The values displayed may not be the same as those in your system. Actual screen information varies by model, installed features, and location.

In the descriptive table following each of the screenshot, settings in boldface are the default settings.

Downloaded from www.Manualslib.com manuals search engine

Information

The Information menu displays a summary of your system hardware information. These information are necessary for troubleshooting and may be required when asking for technical support.


Phoenix SecureCore(tm) Setup Utility
Information
Main
Security
Boot
Exit
CPU Type: Intel (R) Core (TM) i5 CPU M 430 @2.27 GHz
CPU Speed: 2260 MHZ
IDE0 Model Name: Hitachi HTS545032B9A300-(S1)
IDE0 Serial Number: 100217PBPC061DCAKXLL
ATAPI Model Name: Optiarc DVD RW AD-7585H-(S5)
System BIOS Version: V1.04
VGA BIOS Version: 70.18.49.00.07
KBC Version: 01.05
Serial Number: 914JD01002G009B01EB2000
Asset Tag Number: No Asset Tag
Product Name: TravelMate 4740
Manufacturer Name: Acer
UUID: 373dd280-2d84-11df-9ce1-b8c80ef75913
F1 Help ↑↓ Select Item F5/F6 Change Values F9 Setup Defaults
Esc Exit ↔ Select Menu Enter Select ▶Sub-Menu F10 Save and Exit

Parameter	Description
CPU Type	Displays the processor model and speed.
CPU Speed	Displays the processor speed.
IDE0 Model Name	Displays the model name of the hard drive installed on the primary IDE master.
IDE0 Serial Number	Displays the serial number of the hard drive installed on the primary IDE master.
ATAPI Model Name	Displays the model name of the installed optical drive.
System BIOS Version	Displays system BIOS version.
VGA BIOS Version	Displays the VGA firmware version of the system.
KBC Version	Displays the keyboard controller version.
Serial Number	Displays the system serial number.
Asset Tag Number	Displays the system asset tag number.
Product Name	Displays the official model name of the system.
Manufacturer Name	Displays the name of the system manufacturer.
UUID	Displays the system's UUID (universally unique identifier). UUID is an identifier standard used in software construction, standardized by the Open Software Foundation (OSF) as part of the Distributed Computing Environment (DCE).

Downloaded from www.Manualslib.com manuals search engine

Main

Use the Main menu to set the system time and date, and other basic options.



Parameter	Description	Format/Options
System Time	Displays the system time. The time is expressed in a 24-hour format.	HH:MM:SS (hour:minute:second)
System Date	Displays the system date.	MM/DD/YYYY (month/day/year)
Total Memory	Displays the size of system memory detected during boot-up.	
Video Memory	Displays the size of video memory detected during boot-up.	
Quiet Boot	Enables or disables the Quiet Boot function. When enabled, BIOS setup is in graphical mode and displays only the system brand logo during POST and while booting. When disabled, BIOS setup is in conventional text mode and displays the system Summary Screen.	**Enabled** Disabled
Network Boot	When enabled, a remote host with appropriate boot image can boot this system. (only works with an Ethernet device.)	**Enabled** Disabled
F12 Boot Menu	Enables or disables the Boot menu during POST.	Enabled **Disabled**
D2D Recovery	Enables or disables the D2D Recovery function. This function allows the user to create a hidden partition on the hard drive to store the operation system. User can then use this partition to restore the system to factory defaults by pressing the <Alt> + <F10> keys during system boot-up.	**Enabled** Disabled
SATA Mode	Select the SATA controller operating mode. When set to AHCI (Advanced Host Controller Interface), the SATA controller enables its AHCI and RAID features when the system boots up. When set to IDE, the SATA controller disables its AHCI and RAID functions when the system boots up. **Note:** If you do not intend to use the AHCI or RAID features set this parameter to IDE to speed up the boot-up time.	**AHCI** IDE

Downloaded from www.Manualslib.com manuals search engine

Security

Use the Security menu option to set system passwords to protect your system from unauthorized use.


Phoenix SecureCore(tm) Setup Utility
Information
Main
Security
Boot
Exit
Item Specific Help
Supervisor Password Is: Clear
User Password Is: Clear
HDD Password Is: Clear
Set Supervisor Password [Enter]
Set User Password [Enter]
Set HDD Password [Enter]
Password on Boot: [Disabled]
Supervisor Password controls access of the whole setup utility. It can be used to boot up when Password on boot is enabled.
F1 Help ↑↓ Select Item F5/F6 Change Values F9 Setup Defaults
Esc Exit ↔ Select Menu Enter Select ▸Sub-Menu F10 Save and Exit

Parameter	Description	Option
Supervisor Password Is	Displays the supervisor password status.	Clear Set
User Password Is	Displays the user password status.	Clear Set
HDD Password Is	Displays the hard drive password status.	Clear Set
Set Supervisor Password	Press **Enter** to set a supervisor password. When set, this password will allow the user to access and change all settings in the Setup Utility.	
Set User Password	Press **Enter** to set a user password. When set, this password will restrict a user's access to the Setup menus. Only the following menus will be accessible: • System Time and System Date • All Exit menu options excluding Load Setup Defaults **Note:** A supervisor password must first be set before creating a user password. If Password on Boot is enabled, the user must enter the user password each time the notebook is turned on or wakes from Sleep.	
Set HDD Password	Press **Enter** to set password for accessing the hard disk drive (HDD) password. It will be required during boot-up or when waking from hibernation mode.	
Password on Boot	Referred to as the power-on password. When enabled, the user or supervisor password will be required to boot up the system. **Note:** A supervisor password must first be set before creating a user password.	Enabled **Disabled**

CAUTION: When you are prompted to enter a password, you have three tries before the system halts. Don't forget your password.

Downloaded from www.Manualslib.com manuals search engine

Setting a Password

Follow these steps as you set the user, the supervisor, or the HDD password:

1. Use the **up**/**down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set HDD Password), then press **Enter**. A Password box will appear.
2. Type a password then press **Enter**.

   The password may consist of up to 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive).
3. Retype the password to verify the first entry then press **Enter** again.
4. Press <**F10**>.
5. Select **Yes** to save the new password and close the Setup Utility.

Changing a Password

Follow these steps as you change the user, the supervisor, or the HDD password:

1. Use the **up**/**down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set HDD Password), then press **Enter**.
2. Type the current password then press **Enter**.
3. Type a new password then press **Enter**.
4. Retype the new password to verify the first entry then press **Enter**.

   You will be prompted to save the new password.
5. Press **Enter**.
6. Press <**F10**> to save the password and close the Setup Utility or you can proceed to setting a user password.

Removing a User and Supervisor Password

1. Use the **up**/**down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set HDD Password), then press **Enter**.
2. Enter the current password then press **Enter**.
3. Press **Enter** twice without entering anything in the New Password and Confirm New Password fields.
4. After doing this, the system automatically sets the related password parameter to **Clear**.

Removing a HDD Password

If you key in the wrong HDD password thrice, the “HDD password error code” will appear on the screen. .



To regain access to your system if you lose the HDD password, you need to generate a master password and unlock the hard drive. Go to page 86 for instructions.

Downloaded from www.Manualslib.com manuals search engine

Resetting a Password

If you have forgotten the user password, the system will continue to function normally but you will have limited access to the Setup Utility.

If you have enabled the Password on Boot field and you forget the supervisor password, you will not be able to boot up the system. The same thing applies if you forget the HDD password.

To clear a lost user or supervisor password you need to short the clear password hardware gap located on the mainboard. Go to page 85 for instructions.

Downloaded from www.Manualslib.com manuals search engine

Boot

Use the Boot menu to set the preferred drive sequence in which the Setup Utility attempts to boot the operating system.


Phoenix SecureCore(tm) Setup Utility
Information
Main
Security
Boot
Exit
Boot priority order:
1: IDE0: Hitachi HTS545032B9A300-(S1)
2: IDE CD/DVD: Optiarc DVD RW AD-7585H-(S
3: Network Boot: MBA v12.2.2 Slot 0300
4: USB HDD:
5: USB FDD:
6: USB Key:
7: USB CD/DVD:
Item Specific Help
Use <↑> or <↓> to select a device, then press <F6> to move it up the list, or <F5> to move it down the list. Press <Esc> to escape the menu.
F1 Help ↑↓ Select Item F5/F6 Change Values F9 Setup Defaults
Esc Exit ↔ Select Menu Enter Select ▸Sub-Menu F10 Save and Exit

To set boot drive sequence:

1. Press the **up** or **down** arrow keys to select a bootable device.
2. Press <**F5**> or <**F6**> to move the selected device up or down the boot sequence.
3. Press <**F10**> to save the changes you made and close the Setup Utility.

Downloaded from www.Manualslib.com manuals search engine

Exit

The Exit menu lists options for quitting from the BIOS Setup Utility.



Parameter	Description
Exit Saving Changes	Save changes made and closes the utility. Keyboard shortcut: **F10**
Exit Discarding Changes	Discards changes made and closes the utility.
Load Setup Defaults	Loads the factory default settings for all Setup parameters. Keyboard shortcut: **F9**
Discard Changes	Discards all changes made to the utility and loads previous configuration settings.
Save Changes	Save all changes made to the utility.

Downloaded from www.Manualslib.com manuals search engine

Updating the BIOS

The BIOS flash memory update is required for the following conditions:

- New versions of system programs
- New features or options
- Restore a BIOS when it becomes corrupted.

NOTE: Observe the following when using the Flash utility to update the system BIOS flash ROM.

- If you do not have a Crisis Recovery disk at hand, then you should create a **Crisis Recovery Disk** (See “Creating the BIOS Crisis Recovery Disk in Windows” on page 87) before you use the Flash utility.
- Do not install memory-related drivers (XMS, EMS, DPMI) when you use the Flash utility.
- Make sure the battery pack is installed to the system and that the system is connected to a UPS unit when you run the Flash utility. If the battery pack does not contain enough power to finish BIOS flash, the system may not boot because the BIOS is not completely loaded.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Machine Disassembly and Replacement

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

Disassembly Requirements

To disassemble the notebook computer, you need the following tools:

- Wrist grounding strap and conductive mat for preventing electrostatic discharge
- Flat screwdriver
- Philips screwdriver
- Hex screwdriver
- Plastic flat screwdriver
- Plastic tweezers

NOTE: The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

Downloaded from www.Manualslib.com manuals search engine

General Information

Pre-disassembly Instructions

Before proceeding with the disassembly procedure, make sure that you do the following:

1. Turn off the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.

3. Place the system on a flat, stable surface.
4. Remove the battery pack.

Disassembly Process

The disassembly process is divided into the following stages:

- External module disassembly
- Main unit disassembly
- LCD module disassembly

The flowcharts provided in the succeeding disassembly sections illustrate the entire disassembly sequence. Observe the order of the sequence to avoid damage to any of the hardware components. For example, if you want to remove the mainboard, you must first remove the keyboard, then disassemble the inside assembly frame in that order.

Main Screw List

Code	Type	Color	Part No.
A	M2 x L5	Black	86.00M90.525
B	M2 x L3	Black	86.00F80.723
C	M3 x L4	Silver	86.9A524.4R0
D	M2.5 x L6	Black	86.00E33.736
E	M2 x L2	Black	86.00E09.622
F	M2.5 x L5	Black	86.00F87.735
G	M2.5 x L4	Black	86.00H36.534

Downloaded from www.Manualslib.com manuals search engine

External Module Disassembly Process

External Modules Disassembly Flowchart

The flowchart below gives you a graphic representation on the entire disassembly sequence and instructs you on the components that need to be removed during servicing. For example, if you want to remove the mainboard, you must first remove the keyboard, then disassemble the inside assembly frame in that order.



Screw List

Code	Part Number	Type	Color
A	86.00M90.525	M2 x L5	Black
B	86.00F80.723	M2 x L3	Black
C	86.9A524.4R0	M3 x L4	Silver

Downloaded from www.Manualslib.com manuals search engine

Removing the Battery Pack

1. Turn base unit over.
2. Slide the battery lock to the unlock position.
3. Slide and hold the battery release latch to the release position.
4. Remove the battery pack out of the unit.

IMPORTANT: The battery is highlighted with a yellow oval in the above image. Follow local regulations for battery disposal.

Removing the Card Reader Dummy Card

1. See “Removing the Battery Pack” on page 38.
2. Push against the card, as if you were pushing it further into the slot, letting the card spring out.
3. Remove the card from the slot.

Downloaded from www.Manualslib.com manuals search engine

Removing the Back Cover

1. See “Removing the Battery Pack” on page 38.
2. Loosen the four captive screws (A) securing the back cover. These screws cannot be removed.

Type	Quantity	Color	Torque	Part No.
M2 x L5	4	Black	1.6 kgf-cm	86.00M90.525

3. Insert a plastic scribe on the cover’s notch to release the cover, then remove the cover.

Removing the Hard Disk Drive Module

1. See “Removing the Battery Pack” on page 38.
2. See “Removing the Back Cover” on page 39.

Downloaded from www.Manualslib.com manuals search engine

3. Remove the screw (B) securing the hard disk drive module.

Type	Quantity	Color	Torque	Part Number
M2 x L3	1	Black	1.6 kgf-cm	86.00F80.723

4. Grasp the black mylar tab and use it to disengage the hard drive from its connector, then remove the drive from its compartment.

NOTE: To prevent damage to device, avoid pressing down on it or placing heavy objects on top of it.

5. Remove the two screws (C) securing the hard disk drive bracket.



Type	Quantity	Color	Torque	Part Number
M3 x L4	2	Silver	3.0 kgf-cm	86.9A524.4R0

Downloaded from www.Manualslib.com manuals search engine

6. Detach the bracket from the hard disk.

Removing the DIMM Modules

1. See “Removing the Battery Pack” on page 38.
2. See “Removing the Back Cover” on page 39.
3. Push out the latches on both sides of the DIMM socket to release the DIMM and remove the DIMM modules.

Removing the WLAN Module

1. See “Removing the Battery Pack” on page 38.
2. See “Removing the Back Cover” on page 39.
3. Detach the bar code sticker covering the antenna cables.

Downloaded from www.Manualslib.com manuals search engine

4. Disconnect the black antenna from the main connector and the white antenna from the auxiliary connector on the WLAN module.

5. Move the antenna cables away from the WLAN module.
6. Remove the screw (B) securing the WLAN module.

Type	Quantity	Color	Torque	Part Number
M2 x L3	1	Black	1.6 kgf-cm	86.00F80.723

7. Detach the module out of the slot.

NOTE: When attaching the antennas back to the WLAN module, make sure the cables are arranged properly.

Downloaded from www.Manualslib.com manuals search engine

Main Unit Disassembly Process

Main Unit Disassembly Flowchart



Screw List

Code	Part Number	Type	Color
B	86.00F80.723	M2 x L3	Black
D	86.00E33.736	M2.5 x L6	Black
E	86.00E09.622	M2 x L2	Black

Downloaded from www.Manualslib.com manuals search engine

Removing the Optical Drive

1. See “Removing the Battery Pack” on page 38.
2. Remove the screw (D) securing the optical drive.

Type	Quantity	Color	Torque	Part Number
M2.5 x L6	1	Black	3.0 kgf-cm	86.00E33.736

3. Slide the optical drive out of the drive bay.

4. Remove the screw (B) that secures the optical drive bracket, then detach the bracket from the drive.



Type	Quantity	Color	Torque	Part Number
M2 x L3	1	Black	1.6 kgf-cm	86.00F80.723

Downloaded from www.Manualslib.com manuals search engine

Removing the Keyboard

1. See “Removing the Battery Pack” on page 38.
2. Use a plastic flat-blade screwdriver to push the latches on the top side of the keyboard.

3. Raise the top of the keyboard slightly, then carefully slide it toward LCD panel to release the keyboard retaining tabs from the upper case.
4. Flip the keyboard over onto the touchpad area to access the keyboard cable.
5. Open the keyboard cable connector, then disconnect the cable.



Removing the Upper Case

1. See “Removing the Battery Pack” on page 38.
2. See “Removing the Back Cover” on page 39.
3. See “Removing the Hard Disk Drive Module” on page 39.
4. See “Removing the DIMM Modules” on page 41.
5. See “Removing the WLAN Module” on page 41.
6. See “Removing the Optical Drive” on page 44.
7. See “Removing the Keyboard” on page 45.

Downloaded from www.Manualslib.com manuals search engine

8. Disconnect the following system cables from their mainboard connectors.

- Speaker cable

- Power board cable

- Touchpad board cable



Downloaded from www.Manualslib.com manuals search engine

9. Remove the two screws (D) from the upper case.

Type	Quantity	Color	Torque	Part Number
M2.5 x L6	2	Black	3.0 kgf-cm	86.00E33.736

10. Turn the unit over to the base side.

11. Remove the five screws (B) securing the upper case to the lower case.



Type	Quantity	Color	Torque	Part Number
M2 x L3	5	Black	1.6 kgf-cm	86.00F80.723

Downloaded from www.Manualslib.com manuals search engine

12. Remove the three screws (E) securing the upper case to the lower case.

Type	Quantity	Color	Torque	Part Number
M2 x L2	3	Black	1.6 kgf-cm	86.00E09.622

13. Remove the eleven screws (D) securing the upper case to the lower case.

Type	Quantity	Color	Torque	Part Number
M2.5 x L6	11	Black	3.0 kgf-cm	86.00E33.736

14. Pry loose the upper case from the lower case and remove the upper case.



Downloaded from www.Manualslib.com manuals search engine

Removing the Power Button Board

1. Perform the “Removing the Upper Case” procedure on page 45.
2. Disconnect the power board cable from the power board.



3. Remove the screw (B) securing the power board, then remove the power board..



Type	Quantity	Color	Torque	Part Number
M2 x L3	1	Black	1.6 kgf-cm	86.00F80.723

Downloaded from www.Manualslib.com manuals search engine

Removing the Speakers

1. Perform the “Removing the Upper Case” procedure on page 45.
2. Detach the mylar tape securing the speaker cables.

3. Release the cables from the upper case latches.



4. Remove the four screws (B) securing the left and right speakers.



Type	Quantity	Color	Torque	Part Number
M2 x L3	4	Black	1.6 kgf-cm	86.00F80.723

5. Remove the speakers.

Downloaded from www.Manualslib.com manuals search engine

Removing the Touchpad Board

1. Perform the “Removing the Upper Case” procedure on page 45.
2. Release the latch and disconnect the cable from the touchpad board.



3. Carefully pry loose the touchpad board from the upper case to detach it.



CAUTION: The touchpad board is glued to the upper case. Remove the touchpad board only if it is defective.

IMPORTANT: A circuit board that is >10 cm² has been highlighted with the yellow rectangle as above image shows. Follow local regulations for disposing this type of circuit board.

Removing the LCD Module

1. Perform the “Removing the Upper Case” procedure on page 45.

Downloaded from www.Manualslib.com manuals search engine

2. Disconnect the LCD cable from its mainboard connector.

3. Disconnect the microphone cable from its mainboard connector.



4. Release the microphone and antenna cables from the adhesive tabs securing them, then pull them out from underneath the system.



5. Move the LCD, microphone, antenna cables away from the LCD hinge screws.

Downloaded from www.Manualslib.com manuals search engine

6. Remove the four screws (D) securing the LCD module.

Type	Quantity	Color	Torque	Part Number
M2.5 x L6	4	Black	3.0 kgf-cm	86.00E33.736

7. Lift the LCD module up and away from the base unit.

Proceed to page 60 for instructions on how to disassemble the LCD module.

Removing the USB Board

1. Perform the “Removing the Upper Case” procedure on page 45.
2. Disconnect the USB cable from its connector.



Downloaded from www.Manualslib.com manuals search engine

3. Remove the USB board.



IMPORTANT: A circuit board that is >10 cm² has been highlighted with the yellow rectangle as above image shows. Follow local regulations for disposing this type of circuit board.

Removing the Bluetooth Module

1. Perform the “Removing the USB Board” procedure on page 53.
2. Disconnect the Bluetooth cable from its mainboard connector.



TravelMate 4740/4740Z

3. Detach the cable from the base enclosure, then remove the Bluetooth module.



TravelMate 4740/4740Z

Downloaded from www.Manualslib.com manuals search engine

Removing the Mainboard

1. Perform the “Removing the Bluetooth Module” procedure on page 54.
2. Disconnect the USB board cable from its mainboard connector.



3. Remove the screw (D) securing the mainboard.



Type	Quantity	Color	Torque	Part Number
M2.5 x L6	4	Black	1.6 kgf-cm	86.00E33.736

IMPORTANT: A circuit board that is >10 cm² has been highlighted with the yellow square as above image shows. Follow local regulations for disposing this type of circuit board.

The CMOS battery has been highlighted with a yellow circle in the previous image. Detach the RTC battery and follow the local regulations for disposing it.

4. Carefully pull the mainboard out of the base enclosure, then flip it over.

Downloaded from www.Manualslib.com manuals search engine

5. Disconnect the DC-input cable from the mainboard, then remove the mainboard.



TravelMate 4740G/4740ZG



TravelMate 4740/4740Z

Removing the Heatsink Fan Module

1. Perform the “Removing the Mainboard” procedure on page 55.
2. Turn the mainboard over to access the heatsink fan cable.
3. Disconnect the heatsink fan cable from its mainboard connector.

TravelMate 4740G/4740ZG

TravelMate 4740/4740Z

4. Loosen the heatsink screws. Follow the sequence indicated on the below images.



TravelMate 4740G/4740ZG



TravelMate 4740/4740Z

NOTE: The TravelMate 4740G/4740ZG system may be shipped with NVIDIA N11M-GE1-B-A3 or N11P-GE1-A3 module.

Downloaded from www.Manualslib.com manuals search engine

5. Remove the heatsink fan module from the mainboard.



TravelMate 4740G/4740ZG

TravelMate 4740/4740Z

Removing the Processor

1. Perform the “Removing the Heatsink Fan Module” procedure on page 56.
2. Detach the barcode sticker on top of the processor.

3. Use a flat-blade screwdriver to turn the processor socket lock counter-clockwise to the unlock position, then hold the processor by its edges and carefully remove it from its socket.



TravelMate 4740G/4740ZG



TravelMate 4740/4740Z

CAUTION: DO NOT lay the processor on its base to avoid bending or damaging the pins underneath it.

Downloaded from www.Manualslib.com manuals search engine

IMPORTANT: When installing a processor:

- Note the golden arrow on the corner to make sure the processor is properly oriented over the socket.

- Moisten a soft cloth with isopropyl alcohol and clean the processor die to remove any thermal grease residue. Wipe the die surface several times to make sure that no particles or dust contaminants are evident. Allow the alcohol to evaporate before continuing. Apply just enough thermal grease to evenly coat the surface of the processor die.

Downloaded from www.Manualslib.com manuals search engine

LCD Module Disassembly Process

LCD Module Disassembly Flowchart



Screw List

Code	Part Number	Type	Color
B	86.00F80.723	M2 x L3	Black
F	86.00F87.735	M2.5 x L5	Black
G	86.00H36.534	M2.5 x L4	Black

Downloaded from www.Manualslib.com manuals search engine

Removing the LCD Bezel

1. Perform the “Removing the LCD Module” procedure on page 51.
2. Remove the two screw covers from the LCD bezel.

3. Remove the two screws (F) securing the LCD bezel. .

Type	Quantity	Color	Torque	Part Number
M2.5 x L5	2	Black	3.0 kgf-cm	86.00F87.735

4. Carefully pry loose the bezel from the LCD case. Start on the top side, continue to the left and right sides, and finally the bottom side. Remove the bezel.

Downloaded from www.Manualslib.com manuals search engine

Removing the LCD Panel

1. Perform the “Removing the LCD Bezel” procedure on page 60.
2. Remove the six screws (G) securing the LCD panel.

TravelMate 4740G/4740ZG

TravelMate 4740/4740Z

Type	Quantity	Color	Torque	Part Number
M2.5 x L4	6	Black	3.0 kgf-cm	86.00H36.534

3. Detach the LCD-webcam cable from the LCD’s underside.

4. Remove the LCD panel.



5. Turn the LCD on its front to access the LCD-webcam cable.

Downloaded from www.Manualslib.com manuals search engine

6. Disconnect the LCD-webcam cable from the LCD PCB.



Removing the LCD Hinges

1. Perform the “Removing the LCD Panel” procedure on page 61.
2. Remove the four screws (B) securing the left and right LCD hinges, then remove the LCD hinges from the LCD case.

Type	Quantity	Color	Torque	Part Number
M2 x L3	4	Black	1.6 kgf-cm	86.00F80.723

Removing the Webcam Module

1. Perform the “Removing the LCD Hinges” procedure on page 62.
2. Disconnect the CCD board cable.
3. Pry loose the webcam module from the LCD case to remove it.



NOTE: The webcam module is glued to the LCD case. Remove the module only if it is defective.

Downloaded from www.Manualslib.com manuals search engine

Removing the Microphone

1. Perform the “Removing the LCD Hinges” procedure on page 62.
2. Release the microphone cable from the adhesive tabs securing them, then remove the microphone from the LCD case.



TravelMate 4740G/4740ZG



TravelMate 4740/4740Z

Removing the WLAN Antennas

1. Perform the “Removing the LCD Hinges” procedure on page 62.
2. Release the antenna cables from the retaining latches securing them, then carefully pry the cables loose from the LCD case to remove the antennas.



TravelMate 4740G/4740ZG



TravelMate 4740/4740Z

NOTE: There is no need to remove the antenna unless you really need to replace it.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Troubleshooting

Use the following procedure as a guide for system problems.

NOTE: The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.

1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
3. Use the following table with the verified symptom to determine which page to go to.

Symptoms (Verified)	Go To
Power failure. (The power indicator does not go on or stay on.)	“Power System Check” on page 67.
POST does not complete. No beep or error codes are indicated.	“Power-On Self-Test (POST) Error Message” on page 68 “Undetermined Problems” on page 80
POST detects an error and displayed messages on screen.	“” on page 69
Other symptoms (i.e. LCD display problems or others).	“Power-On Self-Test (POST) Error Message” on page 68
Symptoms cannot be re-created (intermittent problems).	Use the customer-reported symptoms and go to “Power-On Self-Test (POST) Error Message” on page 68 “Intermittent Problems” on page 79 “Undetermined Problems” on page 80

Downloaded from www.Manualslib.com manuals search engine

System Check Procedures

External Diskette Drive Check

Use the following procedure to isolate a problem in diskette drive controller, driver, or diskette. A write-enabled, diagnostic diskette is required.

NOTE: Make sure that the diskette does not have more than one label attached to it. Multiple labels can cause damage to the drive or cause the drive to fail.

1. Boot from the diagnostics diskette and start the diagnostics program.
2. See if FDD Test is passed as the program runs to FDD Test.
3. Follow the onscreen instructions.

If an error occurs with the internal diskette drive, reconnect the diskette connector on the mainboard. If the error persists, do the following:

1. Reconnect the external diskette drive.
2. Replace the external diskette drive.
3. Replace the mainboard.

External Optical Drive Check

Use the following procedure to isolate a possible problem in an optical drive controller, drive, or optical drive.

NOTE: Make sure that the optical drive does not have any label attached to it. The label may damage the drive or cause drive failure.

1. Boot from the diagnostics diskette and start the diagnostics program.
2. Run the CD-ROM Test and see if the test completes successfully.
3. Follow the onscreen instructions.

   If an error occurs, reconnect the drive connector on the mainboard.

   If the error still remains:

1. Reconnect the external optical drive to a USB jack.
2. Replace the external optical drive.
3. Replace the mainboard.

Keyboard or Auxiliary Input Device Check

If the internal keyboard does not work or an unexpected character appears, make sure that the flexible cable extending from the keyboard is correctly seated in the connector on the mainboard. If the keyboard cable is connected correctly, run the Keyboard Test.

IMPORTANT: Disconnect any external keyboards before testing the built-in or internal keyboard.

If the tests detect a keyboard problem, do the following in sequence:

1. Reconnect the keyboard cable to the mainboard.
2. Replace the keyboard.
3. Replace the mainboard.

IMPORTANT: Do not replace a non-defective FRU.

The following auxiliary input devices are supported by this system:

- Numeric keypad
- External keyboard

If any of these devices do not function, reconnect the cable and repeat above procedures.

Downloaded from www.Manualslib.com manuals search engine

Memory Check

Memory errors can stop your programs, show error messages on the screen, or hang the system.

NOTE: Make sure that each memory card is properly installed into the connector. A loose connection can cause an error.

1. Boot from the diagnostics diskette and start the diagnostic program.
2. Run the Memory Test and see if the test completes successfully.
3. Press <**F2**> in the test items.
4. Follow the onscreen instructions.

Power System Check

Turn on the system using each of the following power sources:

- Remove the battery pack, connect the power adapter, then make sure that the system turns on using AC power.
- Disconnect the power adapter, install a charged battery pack; then make sure that power is supplied by the battery pack.

If you suspect a power problem, complete the appropriate power supply check:

- “Check the Power Adapter” on page 67.
- “Check the Battery Pack” on page 68.

Check the Power Adapter

Unplug the power adapter cable from the system and measure the output voltage at the plug of the power adapter cable. See the following figure.



Pin 1: +19 to +20.5V
Pin 2: 0V, Ground

1. If the voltage is not correct, replace the power adapter.
2. If the voltage is within the range, do the following:
   - Replace the mainboard.
   - If the problem is not corrected, see “Undetermined Problems” on page 80.
   - If the power on indicator does not light up, check the power adapter’s power cord for correct continuity and installation.
   - If the operational charge does not work, see “Check the Battery Pack” on page 68.

NOTE: An audible noise from the power adapter does not always indicate a defect.

Downloaded from www.Manualslib.com manuals search engine

Check the Battery Pack

To check the battery pack using software:

1. Open Power Management in the Windows Control Panel.
2. In Power Meter, make sure that the parameters shown for Current Power Source and Total Battery Power Remaining are correct.
3. Repeat the steps 1 and 2 for both battery and adapter. This helps you identify first the problem is on recharging or discharging.

To check the battery pack using hardware:

1. Turn off the system.
2. Remove the battery pack and measure the voltage between battery terminals 1(+) and 6 (ground).
3. If the voltage is still less than 7.5 Vdc after recharging, replace the battery.

IMPORTANT: To check the battery charge operation, use a discharged battery pack or a battery pack that has less than 50% of the total power remaining when installed in the system.

If the battery status indicator does not light up, remove the battery pack and let it return to room temperature. Re-install the battery pack.

If the charge indicator still does not light up, replace the battery pack. If the charge indicator still does not light up, replace the DC/DC charger board.

Touchpad Check

If the touchpad does not work, do the following actions in sequence to correct the problem.

1. Reconnect the touchpad cables.
2. Replace the touchpad.
3. Replace the mainboard.

IMPORTANT: Do not replace a non-defective FRU.

After you use the touchpad, the pointer may drift on the screen for a short time. This self-acting pointer movement can occur when a slight, steady pressure is applied to the touchpad pointer. This symptom is not a hardware problem. No actions are necessary to be taken if the pointer movement stops in a short period of time.

Power-On Self-Test (POST) Error Message

The POST error message index lists the error message and their possible causes.

NOTE: Perform the FRU replacement or actions in the sequence shown in FRU/Action column, if the FRU replacement does not solve the problem, put the original part back in the system. Do not replace a non-defective FRU.

This index can also help you determine the next possible FRU to be replaced when servicing the system.

If the symptom is not listed, see “Undetermined Problems” on page 80.

The following lists the error messages that the BIOS displays on the screen and the error symptoms classified by function.

IMPORTANT: Most of the error messages occur during POST. Some of them display information about a hardware device, such as the amount of memory installed. Others may indicate a problem with a device, such as the way it has been configured.

IMPORTANT: If the system fails after you make changes in the BIOS Setup Utility menus, reset the system, enter Setup and install Setup defaults or correct the error.

Downloaded from www.Manualslib.com manuals search engine

Index of Error Messages

Error Codes

Error Codes	Error Messages
006	Equipment Configuration Error Causes: 1. CPU BIOS Update Code Mismatch 2. IDE Primary Channel Master Drive Error (The causes are shown before “Equipment Configuration Error”)
010	Memory Error at xxxx:xxxx:xxxxh (R:xxxxh, W:xxxxh)
070	Real Time Clock Error
071	CMOS Battery Bad
072	CMOS Checksum Error
110	System Disabled An incorrect password was entered.
<No error code>	Battery Critical Low In this situation BIOS issues four short beeps, then shuts the system down. No message is displayed.
<No error code>	Thermal Critical High In this situation BIOS shuts the system down. No message is displayed.

Error Messages

Error Messages	FRU/Action in Sequence
Failure Fixed Disk	❑ Reconnect hard disk drive connector. ❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the hard disk drive. ❑ Test or replace the mainboard.
Stuck Key	See “Keyboard or Auxiliary Input Device Check” on page 66.
Keyboard error	See “Keyboard or Auxiliary Input Device Check” on page 66.
Keyboard Controller Failed	See “Keyboard or Auxiliary Input Device Check” on page 66.
Keyboard locked - Unlock key switch	Unlock the external keyboard
Monitor type does not match CMOS - Run Setup	Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system.
Shadow RAM Failed at offset: nnnn	❑ Test or replace the BIOS ROM. ❑ Test or replace the mainboard.
System RAM Failed at offset: nnnn	❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
Extended RAM Failed at offset: nnnn	❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
System battery is dead - Replace and run Setup	Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system.

Downloaded from www.Manualslib.com manuals search engine

Error Messages	FRU/Action in Sequence
System CMOS checksum bad - Default configuration used	Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system.
System timer error	❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Real time clock error	❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Previous boot incomplete - Default configuration used	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Memory size found by POST differed from CMOS	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
Diskette drive A error	Make sure that the drive is defined with the proper diskette type in the BIOS Setup Utility.
Incorrect Drive A type - run SETUP	Make sure that the drive is defined with the proper diskette type in the BIOS Setup Utility.
System cache error - Cache disabled	Test or replace the mainboard.
CPU ID:	Test or replace the mainboard.
DMA Test Failed	❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
Software NMI Failed	❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
Fail-Safe Timer NMI Failed	❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.
Device Address Conflict	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Allocation Error for device	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Failing Bits: nnnn	❑ Test or replace the SO-DIMM. ❑ Test or replace the BIOS ROM. ❑ Test or replace the mainboard.
Fixed Disk n	None

Downloaded from www.Manualslib.com manuals search engine

Error Messages	FRU/Action in Sequence
Invalid System Configuration Data	❑ Test or replace the BIOS ROM. ❑ Test or replace the mainboard.
I/O device IRQ conflict	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the RTC battery, run the BIOS Setup Utility to reconfigure system time, then reboot the system. ❑ Test or replace the mainboard.
Operating system not found	❑ Run the BIOS Setup Utility and see if fixed disk and drive A: are properly identified. ❑ Test or replace the diskette drive. ❑ Test or replace the hard disk drive. ❑ Test or replace the mainboard.

No Beep Error Messages

No Beep Error Messages	FRU/Action in Sequence
No beep, power-on indicator turns off and LCD is blank.	❑ Test the power source (battery pack and power adapter). See “Power System Check” on page 67. ❑ Make sure that every connector is connected tightly and correctly. ❑ Reconnect the SO-DIMM. ❑ Test or replace the LED board. ❑ Test or replace the mainboard.
No beep, power-on indicator turns on and LCD is blank.	❑ Test the power source (battery pack and power adapter). See “Power System Check” on page 67. ❑ Reconnect the LCD connector. ❑ Check the hard disk drive. ❑ Check the LCD cable. ❑ Test or replace the LCD. ❑ Test or replace the mainboard.
No beep, power-on indicator turns on and LCD is blank. But you can see POST on an external CRT.	❑ Reconnect the LCD connector. ❑ Check the LCD cable. ❑ Test or replace the LCD. ❑ Test or replace the mainboard.
No beep, power-on indicator turns on and a blinking cursor shown on LCD during POST.	❑ Make sure that every connector is connected tightly and correctly. ❑ Test or replace the mainboard.
No beep during POST but system runs correctly.	❑ Test or replace the speaker. ❑ Test or replace the mainboard.

Downloaded from www.Manualslib.com manuals search engine

Phoenix BIOS Beep Codes

Code	Beeps	POST Routine Description
02h		Verify Real Mode
03h		Disable Non-Maskable Interrupt (NMI)
04h		Get CPU type
06h		Initialize system hardware
08h		Initialize chipset with initial POST values
09h		Set IN POST flag
0Ah		Initialize CPU registers
0Bh		Enable CPU cache
0Ch		Initialize caches to initial POST values
0Eh		Initialize I/O component
0Fh		Initialize the local bus IDE
10h		Initialize Power Management
11h		Load alternate registers with initial POST values
12h		Restore CPU control word during warm boot
13h		Initialize PCI Bus Mastering devices
14h		Initialize keyboard controller
16h	1-2-2-3	BIOS ROM checksum
17h		Initialize cache before memory autosize
18h		8254 timer initialization
1Ah		8237 DMA controller initialization
1Ch		Reset Programmable Interrupt Controller
20h	1-3-1-1	Test DRAM refresh
22h	1-3-1-3	Test 8742 Keyboard Controller
24h		Set ES segment register to 4 GB
26h		Enable A20 line
28h		Autosize DRAM
29h		Initialize POST Memory Manager
2Ah		Clear 215 KB base RAM
2Ch	1-3-4-1	RAM failure on address line xxxx
2Eh	1-3-4-3	RAM failure on data bits xxxx of low byte of memory bus
2Fh		Enable cache before system BIOS shadow
30h	1-4-1-1	RAM failure on data bits xxxx of high byte of memory bus
32h		Test CPU bus-clock frequency
33h		Initialize Phoenix Dispatch Manager
36h		Warm start shut down
38h		Shadow system BIOS ROM
3Ah		Autosize cache
3Ch		Advanced configuration of chipset registers
3Dh		Load alternate registers with CMOS values
42h		Initialize interrupt vectors
45h		POST device initialization

Downloaded from www.Manualslib.com manuals search engine

Code	Beeps	POST Routine Description
46h	2-1-2-3	Check ROM copyright notice
48h		Check video configuration against CMOS
49h		Initialize PCI bus and devices
4Ah		Initialize all video adapters in system
4Bh		QuietBoot start (optional)
4Ch		Shadow video BIOS ROM
4Eh		Display BIOS copyright notice
50h		Display CPU type and speed
51h		Initialize EISA board
52h		Test keyboard
54h		Set key click if enabled
58h	2-2-3-1	Test for unexpected interrupts
59h		Initialize POST display service
5Ah		Display prompt “Press F2 to enter SETUP”
5Bh		Disable CPU cache
5Ch		Test RAM between 512 and 640 KB
60h		Test extended memory
62h		Test extended memory address lines
64h		Jump to User Patch1
66h		Configure advanced cache registers
67h		Initialize Multi Processor APIC
68h		Enable external and CPU caches
69h		Setup System Management Mode (SMM) area
6Ah		Display external L2 cache size
6Bh		Load custom defaults (optional)
6Ch		Display shadow-area message
6Eh		Display possible high address for UMB recovery
70h		Display error messages
72h		Check for configuration errors
76h		Check for keyboard errors
7Ch		Set up hardware interrupt vectors
7Eh		Initialize coprocessor if present
80h		Disable onboard Super I/O ports and IRQs
81h		Late POST device initialization
82h		Detect and install external RS232 ports
83h		Configure non-MCD IDE controllers
84h		Detect and install external parallel ports
85h		Initialize PC-compatible PnP ISA devices
86h		Re-initialize onboard I/O ports
87h		Configure Motherboard Configurable Devices (optional)
88h		Initialize BIOS Area
89h		Enable Non-Maskable Interrupts (NMIs)

Downloaded from www.Manualslib.com manuals search engine

Code	Beeps	POST Routine Description
8Ah		Initialize Extended BIOS Data Area
8Bh		Test and initialize PS/2 mouse
8Ch		Initialize floppy controller
8Fh		Determine number of ATA drives (optional)
90h		Initialize hard-disk controllers
91h		Initialize local-bus hard-disk controllers
92h		Jump to UserPatch2
93h		Build MPTABLE for multi-processor boards
95h		Install CD ROM for boot
96h		Clear huge ES segment register
97h		Fixup Multi Processor table
98h	1-2	Search for option ROMs. One long, two short beeps on checksum failure.
99h		Check for SMART drive (optional)
9Ah		Shadow option ROMs
9Ch		Set up Power Management
9Dh		Initialize security engine (optional)
9Eh		Enable hardware interrupts
9Fh		Determine number of ATA and SCSI drives
A0h		Set time of day
A2h		Check key lock
A4h		Initialize Typematic rate
A8h		Erase F2 prompt
AAh		Scan for F2 key stroke
ACh		Enter SETUP
AEh		Clear Boot flag
B0h		Check for errors
B2h		POST done- prepare to boot operating system
B4h	1	One short beep before boot
B5h		Terminate QuietBoot (optional)
B6h		Check password (optional)
B9h		Prepare Boot
BAh		Initialize DMI parameters
BBh		Initialize PnP Option ROMs
BCh		Clear parity checkers
BDh		Display MultiBoot menu
BEh		Clear screen (optional)
BFh		Check virus and backup reminders
C0h		Try to boot with INT 19
C1h		Initialize POST Error Manager (PEM)
C2h		Initialize error logging
C3h		Initialize error display function

Downloaded from www.Manualslib.com manuals search engine

Code	Beeps	POST Routine Description
C4h		Initialize system error handler
C5h		PnPnd dual CMOS (optional)
C6h		Initialize notebook docking (optional)
C7h		Initialize notebook docking late
C8h		Force check (optional)
C9h		Extended checksum (optional)
D2h		Unknown interrupt
E0h		Initialize the chipset
E1h		Initialize the bridge
E2h		Initialize the CPU
E3h		Initialize the system timer
E4h		Initialize system I/O
E5h		Check force recovery boot
E6h		Checksum BIOS ROM
E7h		Go to BIOS
E8h		Set Huge Segment
E9h		Initialize Multi Processor
EAh		Initialize OEM special code
EBh		Initialize PIC and DMA
ECh		Initialize Memory type
EDh		Initialize Memory size
EEh		Shadow Boot Block
EFh		System memory test
F0h		Initialize interrupt vectors
F1h		Initialize Run Time Clock
F2h		Initialize video
F3h		Initialize System Management Mode
F4h	1	Output one beep before boot
F5h		Boot to Mini DOS
F6h		Clear Huge Segment
F7h		Boot to Full DOS

Downloaded from www.Manualslib.com manuals search engine

Symptom-to-FRU Error Messages

LCD-Related Symptoms

Symptom / Error	Action in Sequence
❑ LCD backlight doesn't work ❑ LCD is too dark ❑ LCD brightness cannot be adjusted ❑ LCD contrast cannot be adjusted	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Reconnect the LCD connector. ❑ Test or replace the keyboard (if contrast and brightness function key doesn’t work). ❑ Test or replace the LCD cable. ❑ Test or replace the LCD. ❑ Test or replace the mainboard.
❑ Unreadable LCD screen ❑ Missing pels in characters ❑ Abnormal screen ❑ Wrong color displayed	❑ Reconnect the LCD connector. ❑ Test or replace the LCD cable. ❑ Test or replace the LCD. ❑ Test or replace the mainboard.
LCD has extra horizontal or vertical lines displayed.	❑ Test or replace the LCD cable. ❑ Test or replace the LCD. ❑ Test or replace the mainboard.

Power-Related Symptoms

Symptom / Error	Action in Sequence
System shuts down during operation	❑ Test the power source (battery pack and power adapter). See “Power System Check” on page 67. ❑ Test or replace the battery pack. ❑ Test or replace the power adapter. ❑ Test or replace the mainboard.
System doesn’t power-on.	❑ Test the power source (battery pack and power adapter). See “Power System Check” on page 67. ❑ Test or replace the battery pack. ❑ Test or replace the power adapter. ❑ Test or replace the mainboard.
System doesn’t turn off.	❑ Test the power source (battery pack and power adapter). See “Power System Check” on page 67. ❑ Press and hold the power button for more than 4 secs. ❑ Test or replace the mainboard.
The battery can’t be charged	❑ Test the battery pack. See “Check the Battery Pack” on page 68. ❑ Test or replace the battery pack. ❑ Test or replace the mainboard.

Memory-Related Symptoms

Symptom / Error	Action in Sequence
Memory count (size) appears different from actual size.	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Test or replace the SO-DIMM. ❑ Test or replace the mainboard.

Downloaded from www.Manualslib.com manuals search engine

Speaker-Related Symptoms

Symptom / Error	Action in Sequence
No sound comes from the system when running Windows multimedia programs.	❑ Reinstall the audio driver. ❑ Test or replace the speakers. ❑ Test or replace the mainboard.
Internal speakers make noise or emit no sound.	❑ Test or replace the speakers. ❑ Test or replace the mainboard.

Power Management-Related Symptoms

Symptom / Error	Action in Sequence
System will not enter hibernation.	❑ Test or replace the keyboard (if control is from the keyboard). ❑ Test or replace the hard disk drive. ❑ Test or replace the mainboard.
System doesn't enter hibernation mode and four short beeps every minute.	❑ Press <**Fn**> + <**O**> and see if the system enters hibernation mode. ❑ Test or replace the touchpad ❑ Test or replace the keyboard ❑ Check the hard disk connection to the mainboard. ❑ Test or replace the hard disk drive. ❑ Test or replace the mainboard.
System doesn’t enter standby mode after closing the LCD.	Test or replace the mainboard.
System doesn't resume from hibernation mode.	❑ Check the hard disk connection to the mainboard. ❑ Test or replace the hard disk drive. ❑ Test or replace the mainboard.
System doesn't resume from standby mode after opening the LCD.	Test or replace the mainboard.
Battery fuel gauge in Windows doesn’t go higher than 90%.	❑ Remove battery pack and let it cool for 2 hours. ❑ Refresh battery (use only battery until the notebook turns off, then charge the battery). ❑ Test or replace the battery pack. ❑ Test or replace the mainboard.
System hangs intermittently.	❑ Reconnect the hard disk drive and external optical drive. ❑ Check the hard disk connection to the mainboard. ❑ Test or replace the mainboard.

Peripheral Devices-Related Symptoms

Symptom / Error	Action in Sequence
System configuration does not match the installed devices.	❑ Run “Load Setup Defaults” using the BIOS Setup Utility, then reboot the system. ❑ Reconnect the hard disk drive and external optical drive.
External display does not work correctly.	❑ Press <**Fn**> + <**F5**> repeatedly to switch between LCD, external display, and both displays. ❑ Test or replace the mainboard.
USB does not work correctly	❑ Test or replace the USB board. ❑ Test or replace the mainboard.

Downloaded from www.Manualslib.com manuals search engine

Peripheral Devices-Related Symptoms

Symptom / Error	Action in Sequence
Print problems.	❑ Run the printer self test. ❑ Reinstall the printer driver. ❑ Test or replace the printer cable. ❑ Test or replace the printer. ❑ Test or replace the mainboard.

Keyboard/Touchpad-Related Symptoms

Symptom / Error	Action in Sequence
Keyboard (one or more keys) does not work.	❑ Reconnect the keyboard cable. ❑ Test or replace the keyboard. ❑ Test or replace the mainboard.
Touchpad does not work.	❑ Reconnect the touchpad cable. ❑ Test or replace the touchpad board. ❑ Test or replace the mainboard.

IMPORTANT: If you cannot find a symptom or an error in this list and the problem remains, see “Undetermined Problems” on page 80.

Downloaded from www.Manualslib.com manuals search engine

Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the mainboard in loop mode at least 10 times.
    - If no error is detected, do not replace the FRU.
    - If any error is detected, replace the FRU.
2. Rerun the test to verify that there are no more errors.

Downloaded from www.Manualslib.com manuals search engine

Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative. Use these procedures to isolate the failing FRU (do not isolate non-defective FRU).

IMPORTANT: Verify that all attached devices are supported by the system.

IMPORTANT: Verify that the power supply being used at the time of the failure is operating correctly. (See "Power System Check" on page 67.)

To isolate the failing FRU:

1. Turn off the system.
2. Visually check FRU parts for damage. If you identify any damage, replace the FRU.
3. Remove or disconnect all of the following devices:
   - Non-Acer devices
   - Printer, mouse, and other external devices
   - Battery pack
   - Hard disk drive
   - SO-DIMM
   - External optical drive
4. Turn on the system.
5. Determine if the problem has changed.
   - If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
   - If the problem does recur, replace the following FRUs one at a time.
     - Mainboard
     - LCD assembly

IMPORTANT: Do not replace a non-defective FRU.

Downloaded from www.Manualslib.com manuals search engine

System Architecture

Block Diagram



Downloaded from www.Manualslib.com manuals search engine

Mainboard Layout

Top View



No.	Code	Connector	No.	Code	Connector
1	LCD1	LCD cable connector	6	BT1	Bluetooth module cable connector
2	SPK1	Speaker cable connector	7	USBCN1	USB board cable connector
3	AMIC1	Microphone cable connector	8	CARD1	Memory card reader
4	KB1	Keyboard cable connector	9	PWRCN1	Power cable connector
5	TPCN1	Touchpad cable connector			

Downloaded from www.Manualslib.com manuals search engine

Bottom View - TravelMate 4740G/4740ZG



No.	Code	Connector	No.	Code	Connector
1	MINI1	WLAN module slot	10	VGA1	ATI graphics controller
2	USB3	USB port	11	CPU1	Processor socket
3	HDMI1	HDMI out port	12	ODD1	SATA optical drive connector
4	CRT1	Monitor port	13	PCH1	Mobile Intel HM55 Express Chipset
5		Cooling fan cable connector	14	MINI2	3G module slot
6	RJ45	Ethernet jack	15	SATA1	SATA hard drive connector
7	DCIN1	DC power cable connector	16	G111	Clear password hardware gap
8	BATT1	Battery connector	17	DM1-2	Memory slots 1 and 2
9	SIM1	SIM card slot			

Downloaded from www.Manualslib.com manuals search engine

Bottom View - TravelMate 4740/4740Z



No.	Code	Connector	No.	Code	Connector
1	MINI1	WLAN module slot	9	SIM1	SIM card slot
2	USB3	USB port	10	CPU1	Processor socket
3	HDMI1	HDMI out port	11	ODD1	SATA optical drive connector
4	CRT1	Monitor port	12	PCH1	Mobile Intel HM55 Express Chipset
5		Heatsink fan cable connector	13	SATA1	SATA hard drive connector
6	RJ45	Ethernet jack	14	MINI2	3G module slot
7	DCIN1	DC power cable connector	15	G111	Clear password hardware gap
8	BATT1	Battery connector	16	DM1-2	Memory slots 1 and 2

Downloaded from www.Manualslib.com manuals search engine

Clearing a BIOS Password

To clear a lost BIOS password (user or supervisor password) you need to short the G111 clear password hardware gap located below the keyboard.

Gap	Default Setting	Operation Description
G111	Open (Normal)	Short (Clear the BIOS user and supervisor passwords)

To clear a BIOS password:

1. Turn off the system and unplug all peripherals connected to it.
2. Unplug the AC adapter.
3. Remove the battery.
4. Remove the back cover. Refer to page 39 for detailed instructions.
5. Locate the **G111** gap.



6. Use an electrical conductivity tool to short the two contacts on the hardware gap together.
7. While resting the tool on the two contacts, plug one end of the AC adapter into the DC power jack and plug one end of the electrical outlet.
8. Press the power button to turn on the system.
9. After POST, remove the tool from the hardware gap.
10. Reinstall the back cover and the battery pack.
11. Restart the computer. Press <**F2**> during bootup to access the BIOS Setup utility.
12. Press <**F9**> to load the system defaults.
13. Press <**F10**> to save the changes you made and close the Setup Utility.

Downloaded from www.Manualslib.com manuals search engine

Unlocking the HDD

To regain access to your notebook computer if you lose the HDD password, you need to generate a master password and unlock your hard drive. Use the unlock6.exe utility to unlock the hard drive.

1. Open the system in a DOS environment.
2. Type the following command:

   A\>unlock6 XXXXX 00

   where XXXXX is the HDD password error code
3. Press **Enter** to display the command options.
4. Select option **2** (upper case ASCII code) then press **Enter**.
5. Write down the generated master password.
6. Restart the computer.
7. In the HDD password prompt, type the master password generated in step 5, then press **Enter**.

Downloaded from www.Manualslib.com manuals search engine

BIOS Recovery

An interruption during a BIOS flash procedure (e.g. a power outage) can corrupt the BIOS firmware, which will cause the system to become unbootable. You need to access and execute the boot block program to reboot the system and recover the regular BIOS firmware.

Observe the following when performing a BIOS recovery:

- Make sure the battery pack is installed to the system and that the system is connected to a UPS unit during the BIOS recovery and BIOS flash procedures.
- The BIOS crisis recovery disk should be prepared in a system running the Windows XP or Windows Vista OS.

Creating the BIOS Crisis Recovery Disk in Windows

1. Prepare a removable USB storage device with a capacity size greater than 10 MB.

   Note that all data on the USB storage device will be cleared during the creation of the crisis disk.
2. Set up a system running the Windows XP or Windows Vista OS and plug in the USB storage device into an available USB port.
3. Decompress the Crisis Package Source.
4. Select **WINCRIS.EXE**, then select **Run as administrator**.
5. Keep the default settings, then click the **Start** button.
6. When the pop-up warning dialog box appears, click **OK** to create the crisis disk.
7. Click **No** if you do not want to create another crisis disk.
8. Eject and reconnect the USB removable storage device, and make sure it contains the following three files:
   - BIOS.WPH
   - MINIDOS.SYS
   - PHLASH16.EXE

Performing a BIOS Recovery

1. Shut down the BIOS failed-computer.
2. Connect the USB storage device containing the Crisis Recovery disk files to the failed system.
3. Press and hold the <**Fn**> + <**Esc**> keys (this is the BIOS recovery hotkey), then press the power button.

   The BIOS recovery process begins. When the process is complete the system will automatically reboot.
4. Disconnect the USB storage device from the system.
5. Perform a BIOS flash procedure to update the BIOS firmware. Refer to Running the Flash Utility section below.

Running the Flash Utility

1. Rename the BIOS file as “XXXXXXX.FD”
2. Copy the “XXXXXXX.FD” file to a bootable USB device containing the Crisis Recovery disk files.
3. Turn off the system.
4. Insert the USB storage device containing the renamed BIOS file and the Crisis Recovery disk files to any USB port.
5. Press and hold the <**Fn**> + <**Esc**> keys (this is the BIOS recovery hotkey), then press the **power** button.
6. Release the <**Fn**> + <**Esc**> keys after POST.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

FRU (Field Replaceable Unit) List

This chapter gives you the FRU (Field Replaceable Unit) listing of the Acer TravelMate 4740/4740G/4740Z/4740ZG computer global configurations. Refer to this list when ordering for repair parts or for RMA (Return Merchandise Authorization).

Part number changes will not be noted in this printed Service Guide. The part numbers listed in this Service Guide may differ from those given to regional AUTHORIZED SERVICE PROVIDERS. You MUST use the local FRU list provided by your regional office to order FRU parts for repair and service of customer machines. Make sure that you are using the most up-to-date information available on your regional web site or channel when ordering FRU parts.

NOTE: Follow the local government regulations, or the rules set by your regional office on how to return or dispose of defective parts.

Downloaded from www.Manualslib.com manuals search engine

Exploded Diagram



No.	Component	Part No.
1	LCD cover	60.TVQ01.004
2	LCD bezel	60.TVQ01.003
3	Upper case	60.TVQ01.002
4	Lower case	60.TVQ01.001
5	Optical drive bezel	42.TVQ01.003
6	Back cover	42.TVQ01.001
7	Left hinge bracket	33.TVQ01.002
8	Right hinge bracket	33.TVQ01.003
9	Webcam module	56.18007.471
10	LCD-webcam cable	50.4GW01.032
11	LCD panel	6M.TVQ01.003
12	Battery pack	BT.00607.127
13	Optical drive	6M.TVQ01.001
14	Bluetooth module	56.25032.011
15	USB board cable	55.N9B01.002
16	Bluetooth board cable	50.4JD07.021
17	Hard disk drive module	KH.25008.025
18	Hard disk drive bracket	33.TVQ01.001
19	Card reader dummy card	42.TVQ01.002

Downloaded from www.Manualslib.com manuals search engine

FRU List

TravelMate 4740/4740Z Series FRU List

System model: LX.TVQ02.001 TM4740-352G25MN EMEA W7HP64RCY1ES61

Category	Part Name	Description	Acer Part No.
ADAPTER			
	ADAPTER 65W 19V 3PIN LITEON PA-1650-22AC LV5 LED LF YELLOW	ADP 65W 19V 3P PA-1650-22AC LV	AP.0650A.012
BATTERY			
	BATTERY PACK LI+ 6CELL 2.2MAH SIMPLO 934T2079F	BTY PACK LI+ LG 6C 2.2AH SMP	BT.00607.127
BOARDS			
	CARDREADER&USB BOARD & CABLE	JE40-CP USB BD 09736-2 D	55.N9B01.002
	POWER BUTTON BOARD	BA40-CP POWER BD 09768-1 D	55.TVQ01.001
	BLUETOOTH BOARD FOXCONN BCM2046 V2.1 FW 861	BT MDL BCM2046 V2.1 FW 861	56.25032.011
	TOUCHPAD BOARD SYNAPTIC TM-01191-004	TOUCHPAD SYNAPTIC TM-01191-004	56.17010.291
	WIRELESS LAN BOARD 802.11BGN LITEON ATHEROS AR9283 HB93 2X2 BGN WN6602AH	WLAN 802.11BGN ATHEROS AR9283(HB93)2X2	54.03346.251
CABLES			
	BLUETOOTH CABLE	BA40 BT CABLE MEC	50.4JD07.021
	DC-IN CABLE 65W	C.A. DC-IN 65W	50.4GW04.011
	POWER CORD 3A 250V 3PIN UK	CODE UK 2.5A 250V 3P BK	27.03118.001
	LED LCD/CCD CABLE	C.A. LVDS HT HM42	50.4GW01.032

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
CASE/COVER/BRACKET ASSEMBLY			
	UNITLOAD COVER	ASSY 60 BIG DOOR BA40	42.TVQ01.001
	LOWER CASE W/USB BOARD CABLE	ASSY 60 L-CASE BA40	60.TVQ01.001
	CARDREADER DUMMY CARD	CARD READER DUMMY BA40	42.TVQ01.002
	UPPER CASE SILVER W/ SPEAKER & POWER BUTTON BOARD CABLE & TOUCHPAD CABLE **Note:** Upper case shown here is black.	BA40_U-CASE_60_ASM	60.TVQ01.002
	OPTICAL BRACKET	BRKT SJV41 ODD BRK	33.PUD01.001
	DVD-RW SUPER-MULT BEZEL	ASSY 60 ODD BEZEL BA40 SUPER-MULTI	42.TVQ01.003
	HDD BRACKET	BA40 60 HDD BKT	33.TVQ01.001
	HDD CONNECTOR SOCKET SATA 22PIN	SKT SATA 22P C11724-122A5-Y	20.PUD01.001
	LCD BEZEL SILVER 14" W/CAMERA HOLE	60 ASSY LCD BEZEL CCD BA40	60.TVQ01.003
	LCD BRACKET LEFT W/ HINGE	CHASSIS HINGE L BA40 SZS	33.TVQ01.002
	LCD BRACKET RIGHT W/ HINGE	CHASSIS HINGE R BA40 SZS	33.TVQ01.003
	LED LCD COVER 14" PANEL SILVER PAINTING W/ANTENNA*2 & MICROPHONE NONE 3G **Note:** LCD cover shown here is black.	60 ASSY LCD PANEL NON 3G BA40	60.TVQ01.004
SPEAKER			
	SPEAKER	SPEAKER FG BA40	23.TVQ01.001
PROCESSOR			

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
	CPU INTEL CORE I3 350M PGA 2.26G 35W ARRANDALE TJ90 VT 3M L3	IC CPU ARRANDALE I3-350M 2.26	KC.35001.DMP
DVD-RW DRIVE			
	DVD-RW SUPER-MULTI MODULE 8X SATA WINDOWS7	ODD NSM8XS SUPER-MULTI DRIVE FOR BA40_CP	6M.TVQ01.001
	ODD HLDS SUPER-MULTI DRIVE 12.7MM TRAY DL 8X GT30N LF W/O BEZEL SATA FOR HF+WINDOWS7	ODD SM12.7 HF+W7 HLDS GT30N	KU.0080F.006
HDD/HARD DISK DRIVE			
	HDD 2.5" 5400RPM 250GB SEAGATE ST9250315AS WYATT SATA LF F/W:0001SDM1	HDD 250GB SEAGATE ST9250315AS	KH.25008.025
HEATSINK			
	CPU HEATSINK W/FAN	ASSY THERMAL JE40 CP_UMA AVC	60.4GY13.001
KEYBOARD			
	KEYBOARD 89KEYS TM4T_A10B TM4T INTERNAL 14 STANDARD BLACK NONE Y2010 ACER LEGEND TEXTURE UK	KB NSK-ATK0U UK 89KEY TM4T	KB.I140A.256
LCD			
	LED LCD MODULE 14"WXGA NONE GLARE PAINTING SILVER W/ MICROPHONE&ANTENNA*2 NONE 3G	LCD 14"WXGA ANT*2 W/MIC	6M.TVQ01.003
	LED LCD AUO 14" WXGA NONE GLARE B140XW01 V9 0A LF 200NIT 8MS 400:1	LCD 14"HD AU B140XW01 V9 NG	LK.14006.013
CAMERA			
	CAMERA 1.3M SUYIN SY9665SN HF1315-S32B-OV01	CAMERA 1.3M HF1315-S32B-OV01	56.18007.471
MICROPHONE			
	MICROPHONE	MICROPHONE CABLE BA40 XINGMENG	23.42334.001

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
MAINBOARDS			
	MAINBOARD JE40CP UMA HM55 LF W/RTC BATTERY W/O CPU&MEMORY	JE40-CP PD MB UMA NON3G 09920-2 D	MB.TVQ01.001
MEMORY			
	SODIMM 2GB DDRIII 1066MHZ ELPIDA EBJ21UE8BDS0-AE-F LF 128*8 0.065UM	SODIMM 2G EBJ21UE8BDS0-AE-F	KN.2GB0B.012
MISCELLANEOUS			
SCREWS	LCD BEZEL SCREW MYLAR	MYLAR BEZEL SCREW MYLAR DOWN BA40	40.4JD17.011
	SCREW M2*L3 BLACK ZN	M2*L3 BLACK ZN	86.FR901.001
	SCREW M2.5*L5 BLACK ZN+NYLOK	M2.5*L5 BLACK ZN+NYLOK	86.TK501.001
	SCREW M2.5X4L NI NYLOK	SCRW M2.5X4L NI NYLOK	86.00H36.534
	SCREW M2.5*L6 NYLOK CR3+	SCREW M2.5*L6 NYLOK CR3+	86.00E33.736
	SCREW	SCREW M3x4(86.9A524.4R0)	86.9A524.4R0

Downloaded from www.Manualslib.com manuals search engine

TravelMate 4740G/4740ZG Series FRU List

System model: LX.TVS02.001 TM4740G-352G32MI#EMEA W7HP64RURRU1RU61

Category	Part Name	Description	Acer Part No.
ADAPTER			
	ADAPTER 90W 19V 3PIN HIPRO HP-A0904A3 B1LF LV5 LED LF BLUE	ADP 90W 19V 3P HP-A0904A3 B1LF	AP.09003.021
BATTERY			
	BATTERY PACK LI+ 6CELL 2.2MAH SIMPLO 934T2079F	BTY PACK LI+ LG 6C 2.2AH SMP	BT.00607.127
BOARDS			
	CARDREADER&USB BOARD & CABLE	JE40-CP USB BD 09736-2 D	55.N9B01.002
	POWER BUTTON BOARD	BA40-CP POWER BD 09768-1 D	55.TVQ01.001
	BLUETOOTH BOARD FOXCONN BCM2046 V2.1 FW 861	BT MDL BCM2046 V2.1 FW 861	56.25032.011
	TOUCHPAD BOARD SYNAPTIC TM-01191-004	TOUCHPAD SYNAPTIC TM-01191-004	56.17010.291
	WIRELESS LAN BOARD 802.11BG FOXCONN T77H121.01 ATHEROS AR9285(HB95)	WLAN 802.11BG ATHEROS AR9285(HB95)	NI.23600.047
CABLES			
	BLUETOOTH CABLE	BA40 BT CABLE MEC	50.4JD07.021
	POWER CORD 250V 3PIN EUR BK	CORD EUR 250V 3P BK	27.01518.731
	POWER CABLE 16A 250V 3PIN EUR BK	CORD 16A 250V 3P EUR BK	27.01518.601
	DC-IN CABLE 65W	C.A. DC-IN 65W	50.4GW04.011
	DC-IN CABLE 65W	C.A. DC-IN 65W FOR HL	50.4GW04.001
	LED LCD/CCD CABLE	C.A. LVDS HT HM42	50.4GW01.032
CASE/COVER/BRACKET ASSEMBLY			
	UNITLOAD COVER	ASSY 60 BIG DOOR BA40	42.TVQ01.001

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
	LOWER CASE W/USB BOARD CABLE	ASSY 60 L-CASE BA40	60.TVQ01.001
	CARDREADER DUMMY CARD	CARD READER DUMMY BA40	42.TVQ01.002
	UPPER CASE SILVER W/SPEAKER & POWER BUTTON BOARD CABLE & TOUCHPAD CABLE **Note:** Upper case shown here is black.	BA40_U-CASE_60_ASM	60.TVQ01.002
	OPTICAL BRACKET	BRKT SJV41 ODD BRK	33.PUD01.001
	DVD-RW SUPER-MULT BEZEL	ASSY 60 ODD BEZEL BA40 SUPER-MULTI	42.TVQ01.003
	HDD BRACKET	BA40 60 HDD BKT	33.TVQ01.001
	HDD CONNECTOR SOCKET SATA 22PIN	SKT SATA 22P C11724-122A5-Y	20.PUD01.001
	LCD BEZEL SILVER 14" W/CAMERA HOLE	60 ASSY LCD BEZEL CCD BA40	60.TVQ01.003
	LCD BRACKET LEFT W/ HINGE	CHASSIS HINGE L BA40 SZS	33.TVQ01.002
	LCD BRACKET RIGHT W/HINGE	CHASSIS HINGE R BA40 SZS	33.TVQ01.003
	LED LCD COVER 14" PANEL SILVER PAINTING W/ ANTENNA*2 & MICROPHONE NONE 3G **Note:** LCD cover shown here is black.	60 ASSY LCD PANEL NON 3G BA40	60.TVQ01.004
SPEAKER			
	SPEAKER	SPEAKER FG BA40	23.TVQ01.001

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
CPU/PROCESSOR			
	CPU INTEL CORE I3 350M PGA 2.26G 35W ARRANDALE TJ90 VT 3M L3	IC CPU ARRANDALE I3-350M 2.26	KC.35001.DMP
DVD-RW DRIVE			
	DVD-RW SUPER-MULTI MODULE 8X SATA WINDOWS7	ODD NSM8XS SUPER-MULTI DRIVE FOR BA40_CP	6M.TVQ01.001
	ODD HLDS SUPER-MULTI DRIVE 12.7MM TRAY DL 8X GT30N LF W/O BEZEL SATA FOR HF+WINDOWS7	ODD SM12.7 HF+W7 HLDS GT30N	KU.0080F.006
HDD/HARD DISK DRIVE			
	HDD 320GB 5400RPM 2.5" WD3200BEVT-22A23T0,ML320S,WD SATA 8MB LF F/ W:01.01A01	HDD 320GB WD3200BEVT-22A23T0	KH.32007.008
HEATSINK			
	CPU HEATSINK W/FAN	ASSY THERMAL JE40 CP_N11M_DIS AURAS_ADDA	60.4GY36.001
KEYBOARD			
	KEYBOARD 88KEYS TM4T_A10B TM4T INTERNAL 14 STANDARD BLACK NONE Y2010 ACER LEGEND TEXTURE RUSSIAN	KB NSK-ATK0R RUSSIAN 88 TM4T	KB.I140A.249
LCD			
	LED LCD MODULE 14"WXGA NONE GLARE PAINTING SILVER W/ MICROPHONE&ANTENNA*2 NONE 3G	LCD 14"WXGA ANT*2 W/MIC	6M.TVQ01.003
	LED LCD AUO 14" WXGA NONE GLARE B140XW01 V9 0A LF 200NIT 8MS 400:1	LCD 14"HD AU B140XW01 V9 NG	LK.14006.013
CAMERA			
	CAMERA 1.3M SUYIN SY9665SN HF1315-S32B-OV01	CAMERA 1.3M HF1315-S32B-OV01	56.18007.471
MICROPHONE			
	MICROPHONE	MICROPHONE CABLE BA40 XINGMENG	23.42334.001

Downloaded from www.Manualslib.com manuals search engine

Category	Part Name	Description	Acer Part No.
MAINBOARDS			
	MAINBOARD JE40CP AS4741G DIS HM55 VRAM HYNIX DDRIII 800 LF W/RTC BATTERY W/ O CPU&MEMORY NONE 3G	JE40-CP PD-2MB N11M-A3/HYNIX 512 NON3G D	55.4GY01.161G
MEMORY			
	SODIMM 2GB DDRIII 1066MHZ ELPIDA EBJ21UE8BDS0-AE-F LF 128*8 0.065UM	SODIMM 2G EBJ21UE8BDS0-AE-F	KN.2GB0B.012
MISCELLANEOUS			
SCREWS	LCD BEZEL SCREW MYLAR	MYLAR BEZEL SCREW MYLAR DOWN BA40	40.4JD17.011
	SCREW M2*L3 BLACK ZN	M2*L3 BLACK ZN	86.FR901.001
	SCREW M2.5*L5 BLACK ZN+NYLOK	M2.5*L5 BLACK ZN+NYLOK	86.TK501.001
	SCREW M2.5X4L NI NYLOK	SCRW M2.5X4L NI NYLOK	86.00H36.534
	SCREW M2.5*L6 NYLOK CR3+	SCREW M2.5*L6 NYLOK CR3+	86.00E33.736
	SCREW	SCREW M3x4(86.9A524.4R0)	86.9A524.4R0

Downloaded from www.Manualslib.com manuals search engine

Appendix A

Model Definition and Configuration

Downloaded from www.Manualslib.com manuals search engine

TravelMate 4740

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-332G32Mn	EMEA	Middle East	LX.TVQ0C.012	TM4740-332G32Mn LINPUS MTME2 UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-332G16Mn	AAP	India	LX.TVQ03.087	TM4740-332G16Mn W7PR32INTRIN1 MC XPP UMACss_3 1*2G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-524G25Mn	AAP	Australia/New Zealand	LX.TVQ02.048	TM4740-524G25Mn W7HP64TRAU1 MC UMACss_3 2*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Australia w/ label
TM4740-523G32Mnss	AAP	India	LX.TVQ03.141	TM4740-523G32Mnss W7PR32INTRIN1 MC XPP UMACss_3 2G+1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO1GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-332G32Mnss	AAP	India	LX.TVQ03.140	TM4740-332G32Mnss W7PR32INTRIN1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-524G32Mnss	AAP	India	LX.TVQ03.139	TM4740-524G32Mnss W7PR32INTRIN1 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-522G32Mnss	AAP	India	LX.TVQ03.138	TM4740-522G32Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-351G16Mnss	AAP	India	LX.TVQ03.137	TM4740-351G16Mnss W7PR32INTRIN1 MC UMACss_3 1*1G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-352G32Mnss	AAP	India	LX.TVQ03.136	TM4740-352G32Mnss W7PR32INTRIN1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-352G50Mnss	AAP	India	LX.TVQ03.135	TM4740-352G50Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/500_L/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-524G50Mnss	AAP	India	LX.TVQ03.134	TM4740-524G50Mnss W7PR32INTRIN1 MC XPP UMACss_3 2*2G/500_L/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-332G32Mnss	AAP	Thailand	LX.TVQ03.133	TM4740-332G32Mnss EM W7PR32EMTRTH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TH41	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-351G32Mnss	AAP	Indonesia	LX.TVQ0C.021	TM4740-351G32Mnss LINPUS MTID1 UMACss_3 1*1G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ID32	Ci3350M	NLED14 WXGA	UMA	N	SO1GBII I10	N	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Europe
TM4740-332G32Mn	AAP	Philippines	LX.TVQ0C.006	TM4740-332G32Mn LINPUS MTPH1 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-522G25Mnss	AAP	India	LX.TVQ03.132	TM4740-522G25Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-5452G25Mnss	AAP	India	LX.TVQ03.131	TM4740-5452G25Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5450M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-433G25Mn	EMEA	Middle East	LX.TVQ0C.011	TM4740-433G25Mn LINPUS MTME2 UMACss_3 2G+1G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci5430M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-522G32Mn	AAP	Thailand	LX.TVQ03.007	TM4740-522G32Mn EM W7PR32EMTRTH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TH41	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-521G16Mn	AAP	India	LX.TVQ0C.015	TM4740-521G16Mn LINPUS MTIN1 UMACss_3 1*1G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci5520M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N160G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-352G32Mn	AAP	Thailand	LX.TVQ0C.008	TM4740-352G32Mn LINPUS MTTH1 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TH61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-352G25Mnss	AAP	Singapore	LX.TVQ03.103	TM4740-352G25Mnss W7PR32TRSG1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-332G32Mnss	AAP	India	LX.TVQ03.102	TM4740-332G32Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-5454G32Mnss	EMEA	South Africa	LX.TVQ03.124	TM4740-5454G32Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-5454G50Mnss	EMEA	South Africa	LX.TVQ03.122	TM4740-5454G50Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 2*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-5454G64Mnss	EMEA	South Africa	LX.TVQ03.123	TM4740-5454G64Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 2*2G/640/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N640GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-354G32Mnss	EMEA	South Africa	LX.TVQ03.127	TM4740-354G32Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-352G25Mnss	EMEA	South Africa	LX.TVQ03.126	TM4740-352G25Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-352G32Mnss	EMEA	South Africa	LX.TVQ03.125	TM4740-352G32Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-353G25Miss	EMEA	Russia	LX.TVQ01.003	TM4740-353G25Miss W7HB64RUTRRU1 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-353G25Miss	EMEA	Russia	LX.TVQ0C.019	TM4740-353G25Miss LINPUS MTRU1 UMACss_3 2G+1G/250/6L2.2/5R/na_bg_1.3C_AN_RU81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-353G25Miss	EMEA	Russia	LX.TVQ03.129	TM4740-353G25Miss W7PR32RUTRRU1 MC XPP UMACss_3 2G+1G/250/6L2.2/5R/na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G32Mnss	EMEA	Middle East	LX.TVQ01.002	TM4740-352G32Mnss EM W7HB64EMTRME2 MC UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_AR21	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G32Mnss	EMEA	Middle East	LX.TVQ0C.017	TM4740-352G32Mnss LINPUS MTME2 UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-354G50Mnss	EMEA	South Africa	LX.TVQ03.121	TM4740-354G50Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 2*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-522G25Mnss	EMEA	South Africa	LX.TVQ03.130	TM4740-522G25Mnss EM W7PR32EMTRZA2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-332G32Mnss	EMEA	Middle East	LX.TVQ0C.020	TM4740-332G32Mnss LINPUS MTME6 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mnss	AAP	Australia/ New Zealand	LX.TVQ02.051	TM4740-352G25Mnss W7HP64TRAU1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Australia w/ label
TM4740-332G32Mnss	AAP	India	LX.TVQ03.128	TM4740-332G32Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-332G32Mnss	AAP	India	LX.TVQ0C.018	TM4740-332G32Mnss LINPUS MTIN1 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-353G25Mnss	PA	Chile	LX.TVQ03.120	TM4740-353G25Mnss EM W7PR32EMTRCL3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Italian
TM4740-353G25Mnss	PA	ACLA-Spanish	LX.TVQ03.119	TM4740-353G25Mnss EM W7PR32EMTREA4 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_EN31	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-353G25Mnss	PA	ACLA-Spanish	LX.TVQ03.118	TM4740-353G25Mnss EM W7PR32EMTREA1 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	US-110V
TM4740-353G25Mnss	PA	ACLA-Spanish	LX.TVQ03.117	TM4740-353G25Mnss EM W7PR32EMTREA3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Argentine Power Cord

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-353G25Mnss	PA	ACLA-Portuguese	LX.TVQ03.116	TM4740-353G25Mnss EM W7PR32EMTRXC3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_EN61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Brazil IMETRO
TM4740-353G32Mnss	PA	Chile	LX.TVQ03.115	TM4740-353G32Mnss EM W7PR32EMTRCL3 MC UMACss_3 2G+1G/320/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Italian
TM4740-353G32Mnss	PA	ACLA-Spanish	LX.TVQ03.114	TM4740-353G32Mnss EM W7PR32EMTREA4 MC UMACss_3 2G+1G/320/6L2.2/5R/na_bgn_1.3C_AN_EN31	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-353G32Mnss	PA	ACLA-Spanish	LX.TVQ03.113	TM4740-353G32Mnss EM W7PR32EMTREA1 MC UMACss_3 2G+1G/320/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	US-110V
TM4740-353G32Mnss	PA	ACLA-Spanish	LX.TVQ03.112	TM4740-353G32Mnss EM W7PR32EMTREA3 MC UMACss_3 2G+1G/320/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Argentine Power Cord
TM4740-353G32Mnss	PA	ACLA-Portuguese	LX.TVQ03.111	TM4740-353G32Mnss EM W7PR32EMTRXC3 MC UMACss_3 2G+1G/320/6L2.2/5R/na_bgn_1.3C_AN_EN61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Brazil IMETRO
TM4740-333G25Mnss	PA	Chile	LX.TVQ03.110	TM4740-333G25Mnss EM W7PR32EMTRCL3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Italian
TM4740-333G25Mnss	PA	ACLA-Spanish	LX.TVQ03.109	TM4740-333G25Mnss EM W7PR32EMTREA4 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_EN31	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-333G25Mnss	PA	ACLA-Spanish	LX.TVQ03.108	TM4740-333G25Mnss EM W7PR32EMTREA1 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	US-110V
TM4740-333G25Mnss	PA	ACLA-Spanish	LX.TVQ03.107	TM4740-333G25Mnss EM W7PR32EMTREA3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Argentine Power Cord
TM4740-333G25Mnss	PA	ACLA-Portuguese	LX.TVQ03.106	TM4740-333G25Mnss EM W7PR32EMTRXC3 MC UMACss_3 2G+1G/250/6L2.2/5R/na_bgn_1.3C_AN_EN61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Brazil IMETRO
TM4740-3372G32Mnss	AAP	Singapore	LX.TVQ03.105	TM4740-3372G32Mnss W7PR32TRSG1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ZH31	Ci3370M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G32Mnss	AAP	Singapore	LX.TVQ03.104	TM4740-352G32Mnss W7PR32TRSG1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G32Mnss	AAP	Indonesia	LX.TVQ03.101	TM4740-352G32Mnss EM W7PR32EMTRID1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ID21	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Europe
TM4740-524G32Mnss	AAP	Singapore	LX.TVQ03.099	TM4740-524G32Mnss W7PR32TRSG1 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-522G16Mnss	AAP	India	LX.TVQ03.098	TM4740-522G16Mnss W7PR32INTRIN1 MC XPP UMACss_3 1*2G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-5454G32Mnss	AAP	Singapore	LX.TVQ03.097	TM4740-5454G32Mnss W7PR32TRSG1 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ZH31	Ci5450M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-522G32Mn	AAP	Singapore	LX.TVQ03.072	TM4740-522G32Mn W7PR32TRSG1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-434G32Mi	EMEA	Russia	LX.TVQ03.091	TM4740-434G32Mi W7PR32RUTRRU1 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/na_bg_1.3C_AN_RU61	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Turkey	LX.TVQ03.064	TM4740-352G25Mn EM W7PR32EMTRTR1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_TR41	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Turkish (KB.I140A.255)	Continental
TM4740-331G25Mn	AAP	India	LX.TVQ03.088	TM4740-331G25Mn W7PR32INTRIN1 MC XPP UMACss_3 1*1G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-353G25Mn	PA	Chile	LX.TVQ03.096	TM4740-353G25Mn EM W7PR32EMTRCL3 MC UMACss_3 2G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Italian
TM4740-353G25Mn	PA	ACLA-Spanish	LX.TVQ03.095	TM4740-353G25Mn EM W7PR32EMTREA4 MC UMACss_3 2G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_EN31	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO1GBII I10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-353G25Mn	PA	ACLA-Spanish	LX.TVQ03.094	TM4740-353G25Mn EMW7PR32EMTREA1 MCUMACss_3 2G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	US-110V
TM4740-353G25Mn	PA	ACLA-Spanish	LX.TVQ03.093	TM4740-353G25Mn EMW7PR32EMTREA3 MCUMACss_3 2G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Argentine Power Cord
TM4740-353G25Mn	PA	ACLA-Portuguese	LX.TVQ03.092	TM4740-353G25Mn EMW7PR32EMTRXC3 MCUMACss_3 2G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_EN61	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Brazil IMETRO
TM4740-522G32Mn	TWN	GCTWN	LX.TVQ03.090	TM4740-522G32Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci5520M	NLED14WXGAG	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740-352G32Mn	PA	ACLA-Spanish	LX.TVQ03.089	TM4740-352G32Mn EMW7PR32EMTREA1 MCUMACss_3 1*2G/320/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	US-110V
TM4740-333G32Mn	EMEA	Middle East	LX.TVQ0C.016	TM4740-333G32Mn LINPUS MTME2UMACss_3 2G+1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3330M	NLED14WXGAG	UMA	N	SO2GBII10	SO1GBII10	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-524G25Mn	AAP	India	LX.TVQ03.086	TM4740-524G25Mn W7PR32INTRIN1 MC XPP UMACss_3 2*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci5520M	NLED14WXGAG	UMA	N	SO2GBII10	SO2GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-352G32Mn	TWN	GCTWN	LX.TVQ03.082	TM4740-352G32Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci3350M	NLED14WXGAG	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740-432G50Mn	TWN	GCTWN	LX.TVQ03.081	TM4740-432G50Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/500_L/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci5430M	NLED14WXGAG	UMA	N	SO2GBII10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740-522G16Mn	AAP	Singapore	LX.TVQ02.050	TM4740-522G16Mn W7HP84TRSG1 MCUMACss_3 1*2G/160/BT/6L2.2/5R/na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14WXGA	UMA	N	SO2GBII10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-432G32Mn	AAP	Malaysia	LX.TVQ03.085	TM4740-432G32Mn EMW7PR32EMTRMY1 MCUMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5430M	NLED14WXGA	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-332G25Mn	AAP	Singapore	LX.TVQ03.074	TM4740-332G25Mn W7PR32TRSG1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.084	TM4740-352G25Mn EM W7PR32EMTRZA2 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-352G25Mn	PA	USA	LX.TVQ03.079	TM4740-352G25Mn W7PR32TRUS1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_FRB3	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-351G32Mn	AAP	Indonesia	LX.TVQ0C.014	TM4740-351G32Mn LINPUS MTID1 UMACss_3 1*1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ID32	Ci3350M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Europe
TM4740-331G25Mn	AAP	India	LX.TVQ0C.013	TM4740-331G25Mn LINPUS MTIN1 UMACss_3 1*1G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N250G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-331G25Mn	AAP	India	LX.TVQ03.083	TM4740-331G25Mn W7PR32INTRIN1 MC UMACss_3 1*1G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-352G25Mn	AAP	Thailand	LX.TVQ03.019	TM4740-352G25Mn EM W7PR32EMTRTH1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_TH41	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-432G32Mn	AAP	Thailand	LX.TVQ03.006	TM4740-432G32Mn EM W7PR32EMTRTH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TH41	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-432G32Mi	EMEA	Russia	LX.TVQ03.080	TM4740-432G32Mi W7PR32RUTRRU1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bg_1.3C_AN_RU65	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-332G32Mn	EMEA	Middle East	LX.TVQ02.049	TM4740-332G32Mn EM W7HP84EMTRME2 MC UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_AR21	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-332G32Mn	AAP	Thailand	LX.TVQ03.010	TM4740-332G32Mn EM W7PR32EMTRTH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_TH41	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-332G16Mn	AAP	Philippines	LX.TVQ03.078	TM4740-332G16Mn EM W7PR32EMTRPH1 MC UMACss_3 1*2G/160/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N160G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-524G25Mn	AAP	Australia/ New Zealand	LX.TVQ03.077	TM4740-524G25Mn W7PR32TRAU1 MC XPP UMACss_3 2*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Australia w/ label
TM4740-432G32Mn	AAP	Singapore	LX.TVQ03.076	TM4740-432G32Mn W7PR32TRSG1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-332G32Mn	AAP	Singapore	LX.TVQ03.075	TM4740-332G32Mn W7PR32TRSG1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-524G32Mn	AAP	Singapore	LX.TVQ03.073	TM4740-524G32Mn W7PR32TRSG1 MC XPP UMACss_3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ02.047	TM4740-352G25Mn EM W7HP64EMTRZA1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.046	TM4740-352G25Mn EM W7HP64EMTRME6 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	Turkey	LX.TVQ02.045	TM4740-352G25Mn EM W7HP64EMTRTR1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_TR31	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Turkish (KB.I140A.255)	Continental
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ02.044	TM4740-352G25Mn EM W7HP64EMTRZA5 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.043	TM4740-352G25Mn EM W7HP64EMTRME3 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ02.042	TM4740-352G25Mn EM W7HP64EMTRZA4 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ02.041	TM4740-352G25Mn EM W7HP64EMTRZA2 MC UMACss_3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.040	TM4740-352G25Mn EMW7HP64EMTRMEB MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.039	TM4740-352G25Mn EMW7HP64EMTRME2 MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.038	TM4740-352G25Mn EMW7HP64EMTRME9 MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.037	TM4740-352G25Mn EMW7HP64EMTRME4 MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RU61	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.036	TM4740-352G25Mn EMW7HP64EMTRME2 MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR11	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ02.035	TM4740-352G25Mn EMW7HP64EMTRME2 MCUMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR21	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.071	TM4740-352G25Mn EMW7PR32EMTRME9 MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR52	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.070	TM4740-352G25Mn EMW7PR32EMTRME2 MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR11	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-352G25Mn	EMEA	Algeria	LX.TVQ03.069	TM4740-352G25Mn EMW7PR32EMTRDZ1 MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.068	TM4740-352G25Mn EMW7PR32EMTRMEB MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.067	TM4740-352G25Mn EMW7PR32EMTRME3 MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.066	TM4740-352G25Mn EMW7PR32EMTRMEB MCXPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	UMA	N	SO2GBII10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.065	TM4740-352G25Mn EM W7PR32EMTRZA6 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_PT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.063	TM4740-352G25Mn EM W7PR32EMTRZA1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.062	TM4740-352G25Mn EM W7PR32EMTRZA2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.061	TM4740-352G25Mn EM W7PR32EMTRME2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.060	TM4740-352G25Mn EM W7PR32EMTRZA5 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.059	TM4740-352G25Mn EM W7PR32EMTRME4 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	South Africa	LX.TVQ03.058	TM4740-352G25Mn EM W7PR32EMTRZA4 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.057	TM4740-352G25Mn EM W7PR32EMTRME9 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740-352G25Mn	EMEA	Middle East	LX.TVQ03.056	TM4740-352G25Mn EM W7PR32EMTRME6 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-352G25Mn	EMEA	Latvia	LX.TVQ03.055	TM4740-352G25Mn W7PR32TRLV1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Norway	LX.TVQ03.054	TM4740-352G25Mn W7PR32TRNO3 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740-352G25Mn	EMEA	Luxembourg	LX.TVQ03.053	TM4740-352G25Mn W7PR32TRLU3 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Swiss/G (KB.I140A.253)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Poland	LX.TVQ03.052	TM4740-352G25Mn W7PR32TRPL1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Switzerland	LX.TVQ03.051	TM4740-352G25Mn W7PR32TRCH1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Swiss/G (KB.I140A.253)	Swiss
TM4740-352G25Mn	EMEA	Holland	LX.TVQ03.050	TM4740-352G25Mn W7PR32TRNL1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	France	LX.TVQ03.049	TM4740-352G25Mn W7PR32TRFR1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES82	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	Spain	LX.TVQ03.048	TM4740-352G25Mn W7PR32TRES1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES52	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Continental
TM4740-352G25Mn	EMEA	Germany	LX.TVQ03.047	TM4740-352G25Mn W7PR32TRDE1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	German (KB.I140A.240)	Continental
TM4740-352G25Mn	EMEA	Israel	LX.TVQ03.046	TM4740-352G25Mn W7PR32TRIL1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_HE32	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ03.045	TM4740-352G25Mn W7PR32TRBC4 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Israel	LX.TVQ03.044	TM4740-352G25Mn W7PR32TRIL1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_HE53	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740-352G25Mn	EMEA	Norway	LX.TVQ03.043	TM4740-352G25Mn W7PR32TRNO1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_NO12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Norwegian (KB.I140A.247)	Continental
TM4740-352G25Mn	EMEA	UK	LX.TVQ03.042	TM4740-352G25Mn W7PR32TRGB1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	UK (KB.I140A.256)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.041	TM4740-352G25Mn W7PR32TREU5 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RO12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.040	TM4740-352G25Mn W7PR32TREU4 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SV22	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Latvia	LX.TVQ02.034	TM4740-352G25Mn W7HP64TRLV1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Switzerland	LX.TVQ02.033	TM4740-352G25Mn W7HP64TRCH1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_IT41	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Swiss/G (KB.I140A.253)	Swiss
TM4740-352G25Mn	EMEA	Norway	LX.TVQ02.032	TM4740-352G25Mn W7HP64TRNO1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_NO11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Norwegian (KB.I140A.247)	Continental
TM4740-352G25Mn	EMEA	Holland	LX.TVQ02.031	TM4740-352G25Mn W7HP64TRNL1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_NL11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.030	TM4740-352G25Mn W7HP64TREU7 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SL11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740-352G25Mn	EMEA	Hungary	LX.TVQ02.029	TM4740-352G25Mn W7HP64TRHU1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_HU11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Hungarian (KB.I140A.242)	Continental
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ02.028	TM4740-352G25Mn W7HP64TRBC4 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Spain	LX.TVQ02.027	TM4740-352G25Mn W7HP64TRES1 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Spanish (KB.I140A.251)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.026	TM4740-352G25Mn W7HP64TREU3 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RU21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ02.025	TM4740-352G25Mn W7HP64TRBC3 MC UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Belgium	LX.TVQ02.024	TM4740-352G25Mn W7HP64TRBE1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_NL11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Belgium (KB.I140A.233)	Continental
TM4740-352G25Mn	EMEA	Sweden	LX.TVQ02.023	TM4740-352G25Mn W7HP64TRSE1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_FI11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ02.022	TM4740-352G25Mn W7HP64TRBC5 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Portugal	LX.TVQ02.021	TM4740-352G25Mn W7HP64TRPT1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_PT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740-352G25Mn	EMEA	France	LX.TVQ02.020	TM4740-352G25Mn W7HP64TRFR1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	French (KB.I140A.239)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.019	TM4740-352G25Mn W7HP64TREU7 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ENQ1	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740-352G25Mn	EMEA	Luxembourg	LX.TVQ02.018	TM4740-352G25Mn W7HP64TRLU3 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_IT41	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Swiss/G (KB.I140A.253)	Continental
TM4740-352G25Mn	EMEA	Denmark	LX.TVQ02.017	TM4740-352G25Mn W7HP64TRDK2 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ENS1	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740-352G25Mn	EMEA	Czech	LX.TVQ02.016	TM4740-352G25Mn W7HP64TRCZ2 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_SK11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	CZ/SK (KB.I140A.235)	Continental
TM4740-352G25Mn	EMEA	Austria	LX.TVQ02.015	TM4740-352G25Mn W7HP64TRAT1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_DE61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	German (KB.I140A.240)	Continental
TM4740-352G25Mn	EMEA	Germany	LX.TVQ02.014	TM4740-352G25Mn W7HP64TRDE1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_DE61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	German (KB.I140A.240)	Continental
TM4740-352G25Mn	EMEA	Denmark	LX.TVQ02.013	TM4740-352G25Mn W7HP64TRDK1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_NO11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Danish (KB.I140A.237)	Danish

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Latvia	LX.TVQ02.012	TM4740-352G25Mn W7HP64TRLV1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_RU21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.011	TM4740-352G25Mn W7HP64TREU3 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Italy	LX.TVQ02.010	TM4740-352G25Mn W7HP64TRIT1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_IT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Italian (KB.I140A.243)	Italian
TM4740-352G25Mn	EMEA	UK	LX.TVQ02.009	TM4740-352G25Mn W7HP64TRGB1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	UK (KB.I140A.256)	UK
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.008	TM4740-352G25Mn W7HP64TREU5 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_RO11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.007	TM4740-352G25Mn W7HP64TREU5 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_PL71	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ02.006	TM4740-352G25Mn W7HP64TREU4 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Poland	LX.TVQ02.005	TM4740-352G25Mn W7HP64TRPL1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_PL71	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Israel	LX.TVQ02.004	TM4740-352G25Mn W7HP64TRIL1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_HE11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740-352G25Mn	EMEA	Finland	LX.TVQ02.003	TM4740-352G25Mn W7HP64TRFI2 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_FI11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Greece	LX.TVQ02.002	TM4740-352G25Mn W7HP64TRGR1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_EL31	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Greek (KB.I140A.241)	Continental
TM4740-352G25Mn	EMEA	Cyprus	LX.TVQ02.001	TM4740-352G25Mn W7HP64TRCY1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	UK (KB.I140A.256)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.039	TM4740-352G25Mn W7PR32TREU7 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740-352G25Mn	EMEA	Cyprus	LX.TVQ03.038	TM4740-352G25Mn W7PR32TRCY1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES63	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	UK (KB.I140A.256)	UK
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.037	TM4740-352G25Mn W7PR32TREU7 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SL12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.036	TM4740-352G25Mn W7PR32TREU5 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Hungary	LX.TVQ03.035	TM4740-352G25Mn W7PR32TRHU1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_HU12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Hungarian (KB.I140A.242)	Continental
TM4740-352G25Mn	EMEA	Greece	LX.TVQ03.034	TM4740-352G25Mn W7PR32TRGR1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_EL32	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Greek (KB.I140A.241)	Continental
TM4740-352G25Mn	EMEA	Sweden	LX.TVQ03.033	TM4740-352G25Mn W7PR32TRSE1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Italy	LX.TVQ03.032	TM4740-352G25Mn W7PR32TRIT1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_IT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Italian (KB.I140A.243)	Italian
TM4740-352G25Mn	EMEA	Belgium	LX.TVQ03.031	TM4740-352G25Mn W7PR32TRBE1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Belgium (KB.I140A.233)	Continental
TM4740-352G25Mn	EMEA	Latvia	LX.TVQ03.030	TM4740-352G25Mn W7PR32TRLV1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RU22	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Austria	LX.TVQ03.029	TM4740-352G25Mn W7PR32TRAT1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	German (KB.I140A.240)	Continental
TM4740-352G25Mn	EMEA	Finland	LX.TVQ03.028	TM4740-352G25Mn W7PR32TRFI2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.027	TM4740-352G25Mn W7PR32TREU7 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ENQ2	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740-352G25Mn	EMEA	Eastern Europe	LX.TVQ03.026	TM4740-352G25Mn W7PR32TREU3 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Russian (KB.I140A.249)	Continental
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ03.025	TM4740-352G25Mn W7PR32TRBC5 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Continental
TM4740-352G25Mn	EMEA	Baltic	LX.TVQ03.024	TM4740-352G25Mn W7PR32TRBC3 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740-352G25Mn	EMEA	Denmark	LX.TVQ03.023	TM4740-352G25Mn W7PR32TRDK2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740-352G25Mn	EMEA	Czech	LX.TVQ03.022	TM4740-352G25Mn W7PR32TRCZ2 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_SK12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	CZ/SK (KB.I140A.235)	Continental
TM4740-352G25Mn	EMEA	Portugal	LX.TVQ03.021	TM4740-352G25Mn W7PR32TRPT1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_PT12	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740-352G32Mn	AAP	Thailand	LX.TVQ03.020	TM4740-352G32Mn EM W7PR32EMTRTH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TH41	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-352G25Mn	AAP	Thailand	LX.TVQ0C.010	TM4740-352G25Mn LINPUS MTTH1 UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_TH61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-332G25Mn	AAP	Thailand	LX.TVQ0C.009	TM4740-332G25Mn LINPUS MTTH1 UMACss_3 1*2G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_TH61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740-352G25Mn	TWN	GCTWN	LX.TVQ03.018	TM4740-352G25Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci3350M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-352G32Mn	AAP	Philippines	LX.TVQ0C.007	TM4740-352G32Mn LINPUS MTPH1 UMACss_3 1*2G/320/ BT/6L2.2/5R/ na_bgn_1.3C_AN_XS11	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-332G32Mn	AAP	Philippines	LX.TVQ01.001	TM4740-332G32Mn EM W7HB64EMTRPH1 MC UMACss_3 1*2G/320/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-331G25Mn	AAP	Philippines	LX.TVQ0C.005	TM4740-331G25Mn LINPUS MTPH1 UMACss_3 1*1G/250/ BT/6L2.2/5R/ na_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGA	UMA	N	SO1GBII I10	N	N250GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-332G32Mn	AAP	Philippines	LX.TVQ03.017	TM4740-332G32Mn EM W7PR32EMTRPH1 MC UMACss_3 1*2G/320/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740-432G32Mn	AAP	Singapore	LX.TVQ03.016	TM4740-432G32Mn W7PR32TRSG1 MC UMACss_3 1*2G/320/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-523G32Mn	AAP	Singapore	LX.TVQ03.015	TM4740-523G32Mn W7PR32TRSG1 MC UMACss_3 2G+1G/320/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	SO1GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-522G32Mn	AAP	Singapore	LX.TVQ03.014	TM4740-522G32Mn W7PR32TRSG1 MC UMACss_3 1*2G/320/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-332G32Mn	AAP	Singapore	LX.TVQ03.013	TM4740-332G32Mn W7PR32TRSG1 MC UMACss_3 1*2G/320/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-332G25Mn	AAP	Singapore	LX.TVQ03.012	TM4740-332G25Mn W7PR32TRSG1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	UK
TM4740-332G25Mn	AAP	India	LX.TVQ03.011	TM4740-332G25Mn W7PR32INTRIN1 MC UMACss_3 1*2G/250/ BT/6L2.2/5R/ CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-331G16Mn	AAP	India	LX.TVQ0C.004	TM4740-331G16Mn LINPUS MTIN1 UMACss_3 1*1G/160/ BT/6L2.2/5R/ na_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGA	UMA	N	SO1GBII I10	N	N160GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-331G16Mn	AAP	India	LX.TVQ0C.003	TM4740-331G16Mn LINPUS MTIN1 UMACss_3 1*1G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N160GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-332G25Mn	AAP	India	LX.TVQ0C.002	TM4740-332G25Mn LINPUS MTIN1 UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-332G16Mn	AAP	India	LX.TVQ03.009	TM4740-332G16Mn W7PR32INTRIN1 MC UMACss_3 1*2G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-331G16Mn	AAP	India	LX.TVQ03.008	TM4740-331G16Mn W7PR32INTRIN1 MC XPP UMACss_3 1*1G/160/BT/6L2.2/5R/CB_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740-331G32Mn	AAP	Indonesia	LX.TVQ0C.001	TM4740-331G32Mn LINPUS MTID1 UMACss_3 1*1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ID32	Ci3330M	NLED14 WXGAG	UMA	N	SO1GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Europe
TM4740-332G32Bn	WW	WW	S2.TVQ03.002	TM4740-332G32Bn W7PR32TWW1 MC UMACbb_3 2*1G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES62	Ci3330M	NLED14 WXGA	UMA	N	SO1GBII I10	SO1GBII I10	N320GB5.4KS	NBDCB4XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740-432G16Mn	AAP	Australia/New Zealand	LX.TVQ03.005	TM4740-432G16Mn W7PR32TRAU1 MC XPP UMACss_3 1*2G/160/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Australia w/ label
TM4740-332G16Mn	AAP	Australia/New Zealand	LX.TVQ03.004	TM4740-332G16Mn W7PR32TRAU1 MC XPP UMACss_3 1*2G/160/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Australia w/ label
TM4740-332G25Mn	TWN	GCTWN	LX.TVQ03.003	TM4740-332G25Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/250/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci3330M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740-522G50Mn	TWN	GCTWN	LX.TVQ03.002	TM4740-522G50Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_AN_TC11	Ci5520M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740-432G32Mn	TWN	GCTWN	LX.TVQ03.001	TM4740-432G32Mn W7PR32TRTW1 MC XPP UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_TC11	Ci5430M	NLED14 WXGAG	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-332G32Bn	WW	GCTWN	S2.TVQ 03.001	TM4740-332G32Bn W7PR32TWW1 MC UMACbb_3 2*1G/320/ BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO1GBII I10	SO1GBII I10	N320G B5.4K S	NBDCB 4XS	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	US and Contine ntal
TM4740-5454G64Mnss	EME A	South Africa	LX.TW0 03.014	TM4740-5454G64Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 2*2G/640/BT/6L2.2/5R/ na_bgn_1.3C_F33-900_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N640G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-5454G32Mnss	EME A	South Africa	LX.TW0 03.013	TM4740-5454G32Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_F33-900_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-5454G50Mnss	EME A	South Africa	LX.TW0 03.012	TM4740-5454G50Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 2*2G/500_L/BT/6L2.2/ 5R/na_bgn_1.3C_F33-900_AN_ES61	Ci5450M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-352G32Mnss	EME A	South Africa	LX.TW0 03.009	TM4740-352G32Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_F33-900_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-354G32Mnss	EME A	South Africa	LX.TW0 03.010	TM4740-354G32Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_F33-900_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-354G50Mnss	EME A	South Africa	LX.TW0 03.011	TM4740-354G50Mnss EM W7PR32EMTRZA2 MC XPP UMAGCss_3 2*2G/500_L/BT/6L2.2/ 5R/na_bgn_1.3C_F33-900_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2. 2	65W	1.3M	US Internati onal (KB.I140 A.257)	AF
TM4740-332G32Mnss	AAP	Thailand	LX.TW0 03.008	TM4740-332G32Mnss EM W7PR32EMTRTH1 MC UMAGCss_3 1*2G/ 320/BT/6L2.2/5R/ na_bgn_1.3C_F33-900_AN_TH41	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2. 2	65W	1.3M	Thailand (KB.I140 A.254)	US-110V
TM4740-332G16Mi	EME A	Russia	LX.TW0 01.002	TM4740-332G16Mi W7HB64RUTRRU1 MC UMAGCss_3 2*1G/160/ BT/6L2.2/5R/ na_bg_1.3C_F33-900_AN_RU61	Ci3330M	NLED14 WXGA	UMA	N	SO1GBII I10	SO1GBII I10	N160G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2. 2	65W	1.3M	Russian (KB.I140 A.249)	Contine ntal
TM4740-332G32Mn	AAP	Thailand	LX.TW0 03.007	TM4740-332G32Mn EM W7PR32EMTRTH1 MC UMAGCss_3 1*2G/320/ 6L2.2/5R/ na_bgn_1.3C_F33-900_AN_TH41	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1- Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2. 2	65W	1.3M	Thailand (KB.I140 A.254)	US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740-354G32Mn	EMEA	South Africa	LX.TW003.006	TM4740-354G32Mn EMW7PR32EMTRZA2 MCUMAGCss_3 2*2G/320/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-332G16Mn	EMEA	Middle East	LX.TW001.001	TM4740-332G16Mn EMW7HB64EMTRME2 MCUMAGCss_3 1*2G/160/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_AR21	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740-332G32Mn	EMEA	South Africa	LX.TW003.005	TM4740-332G32Mn EMW7PR32EMTRZA2 MCUMAGCss_3 1*2G/320/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-434G50Mn	EMEA	South Africa	LX.TW003.004	TM4740-434G50Mn EMW7PR32EMTRZA2 MCUMAGCss_3 2*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-434G32Mn	EMEA	South Africa	LX.TW003.003	TM4740-434G32Mn EMW7PR32EMTRZA2 MCUMAGCss_3 2*2G/320/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci5430M	NLED14 WXGA	UMA	N	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-352G32Mn	EMEA	South Africa	LX.TW003.002	TM4740-352G32Mn EMW7PR32EMTRZA2 MCUMAGCss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci3350M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-332G32Mn	EMEA	South Africa	LX.TW003.001	TM4740-332G32Mn EMW7PR32EMTRZA2 MCUMAGCss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES61	Ci3330M	NLED14 WXGA	UMA	N	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	AF
TM4740-334G50Mn	WW	GCTWN	S2.TW003.001	TM4740-334G50Mn W7PR32TWW1 MC XPPUMAGCss_3 1*4G/500_L/6L2.2/5R/CB_bgn_1.3C_E77W_AN_ES61	Ci3330M	NLED14 WXGAG	UMA	N	SO4GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740-334G50Mn	WW	WW	S2.TW003.002	TM4740-334G50Mn W7PR32TWW1 MC XPPUMAGCss_3 1*4G/500_L/6L2.2/5R/CB_bgn_1.3C_E77W_AN_ES62	Ci3330M	NLED14 WXGAG	UMA	N	SO4GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental

Downloaded from www.Manualslib.com manuals search engine

Travelmate 4740G

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	AAP	Singapore	LX.TVS03.146	TM4740G-352G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-332G32Mnss	AAP	Thailand	LX.TVS03.151	TM4740G-332G32Mnss EM W7PR32EMTRTH1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH41	Ci3330M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-522G16Mn	AAP	Singapore	LX.TVS03.006	TM4740G-522G16Mn W7PR32TRSG1 MC N11MGE1512Css_3V3 1*2G/160/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N160G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-353G25Miss	EMEA	Russia	LX.TVS03.150	TM4740G-353G25Miss W7PR32RUTRRU1 MC XPP N11MGE1512Css_3V3 2G+1G/250/6L2.2/5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-5453G32Mnss	EMEA	Middle East	LX.TVS0C.004	TM4740G-5453G32Mnss LINPUSTME2 N11MGE1512Css_3V3 2G+1G/320/BT/6L2.2/5R/ CB_bgn_1.3C_AN_EN13	Ci5450M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-353G25Miss	EMEA	Russia	LX.TVS0C.005	TM4740G-353G25Miss LINPUSTRU1 N11MGE1512Css_3V3 2G+1G/250/6L2.2/5R/ na_bg_1.3C_AN_EN71	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Miss	EMEA	Russia	LX.TVS01.001	TM4740G-353G25Miss W7HB64RUTRRU1 MC N11MGE1512Css_3V3 2G+1G/250/6L2.2/5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	N	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Turkey	LX.TVS03.032	TM4740G-352G32Mn EM W7PR32EMTRTR1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TR41	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Turkish (KB.I140A.255)	Continental
TM4740G-353G25Mn	EMEA	Turkey	LX.TVS03.093	TM4740G-353G25Mn EM W7PR32EMTRTR1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_TR41	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Turkish (KB.I140A.255)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Turkey	LX.TVS03.036	TM4740G-352G32Mn EM W7PR32EMTRTR1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TR41	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Turkish (KB.I140A.255)	Continental
TM4740G-433G32Mn	EMEA	Middle East	LX.TVS0C.003	TM4740G-433G32Mn LINPUSTME2 N11MGE1512Css_3V3 2G+1G/320/BT/6L2.2/5R/ CB_bgn_1.3C_AN_EN13	Ci5430M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	SO1GBII I10	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-522G50Mn	AAP	Malaysia	LX.TVS03.149	TM4740G-522G50Mn EM W7PR32EMTRMY1 MC N11MGE1512Css_3V3 1*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci5520M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-432G32Mn	AAP	Thailand	LX.TVS03.004	TM4740G-432G32Mn EM W7PR32EMTRTH1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH41	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-352G32Mn	AAP	Thailand	LX.TVS03.008	TM4740G-352G32Mn EM W7PR32EMTRTH1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH41	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-333G32Mn	EMEA	Middle East	LX.TVS02.050	TM4740G-333G32Mn EM W7HP64EMTRME2 MC N11MGE1512Css_3V3 2G+1G/320/BT/6L2.2/5R/ CB_bgn_1.3C_AN_AR21	Ci3330M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	SO1GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-432G32Mn	EMEA	Middle East	LX.TVS0C.001	TM4740G-432G32Mn LINPUSTME2 N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_EN13	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-332G32Mn	AAP	Thailand	LX.TVS03.003	TM4740G-332G32Mn EM W7PR32EMTRTH1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ CB_bgn_1.3C_AN_TH41	Ci3330M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-352G32Mn	AAP	Thailand	LX.TVS0C.002	TM4740G-352G32Mn LINPUSTTH1 N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH51	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-352G32Mn	EMEA	Latvia	LX.TVS02.049	TM4740G-352G32Mn W7HP64TRLV1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Switzerland	LX.TVS02.048	TM4740G-352G32MnW7HP64TRCH1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_IT41	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Swiss/G(KB.I140A.253)	Swiss
TM4740G-352G32Mn	EMEA	Norway	LX.TVS02.047	TM4740G-352G32MnW7HP64TRNO1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_NO11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Norwegian(KB.I140A.247)	Continental
TM4740G-352G32Mn	EMEA	Holland	LX.TVS02.046	TM4740G-352G32MnW7HP64TRNL1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_NL11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International(KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.045	TM4740G-352G32MnW7HP64TREU7 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_SL11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	SLO/CRO(KB.I140A.250)	Continental
TM4740G-352G32Mn	EMEA	Hungary	LX.TVS02.044	TM4740G-352G32MnW7HP64TRHU1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_HU11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Hungarian(KB.I140A.242)	Continental
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS02.043	TM4740G-352G32MnW7HP64TRBC4 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Russian(KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Spain	LX.TVS02.042	TM4740G-352G32MnW7HP64TRES1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES51	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Spanish(KB.I140A.251)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.041	TM4740G-352G32MnW7HP64TREU3 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_RU21	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Russian(KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS02.040	TM4740G-352G32MnW7HP64TRBC3 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_SV21	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Sweden(KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Belgium	LX.TVS02.039	TM4740G-352G32MnW7HP64TRBE1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_NL11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Belgium(KB.I140A.233)	Continental
TM4740G-352G32Mn	EMEA	Sweden	LX.TVS02.038	TM4740G-352G32MnW7HP64TRSE1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_FI11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Sweden(KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS02.037	TM4740G-352G32MnW7HP64TRBC5 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International(KB.I140A.257)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Portugal	LX.TVS02.036	TM4740G-352G32MnW7HP64TRPT1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_PT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740G-352G32Mn	EMEA	France	LX.TVS02.035	TM4740G-352G32MnW7HP64TRFR1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.034	TM4740G-352G32MnW7HP64TREU7 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ENQ1	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-352G32Mn	EMEA	Luxembourg	LX.TVS02.033	TM4740G-352G32MnW7HP64TRLU3 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_IT41	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Swiss/G (KB.I140A.253)	Continental
TM4740G-352G32Mn	EMEA	Denmark	LX.TVS02.032	TM4740G-352G32MnW7HP64TRDK2 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ENS1	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740G-352G32Mn	EMEA	Czech	LX.TVS02.031	TM4740G-352G32MnW7HP64TRCZ2 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_SK11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	CZ/SK (KB.I140A.235)	Continental
TM4740G-352G32Mn	EMEA	Austria	LX.TVS02.030	TM4740G-352G32MnW7HP64TRAT1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_DE61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-352G32Mn	EMEA	Germany	LX.TVS02.029	TM4740G-352G32MnW7HP64TRDE1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_DE61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-352G32Mn	EMEA	Denmark	LX.TVS02.028	TM4740G-352G32MnW7HP64TRDK1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_NO11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Danish (KB.I140A.237)	Danish
TM4740G-352G32Mn	EMEA	Latvia	LX.TVS02.027	TM4740G-352G32MnW7HP64TRLV1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_RU21	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.026	TM4740G-352G32MnW7HP64TREU3 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_LT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Italy	LX.TVS02.025	TM4740G-352G32MnW7HP64TRIT1 MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_IT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Italian (KB.I140A.243)	Italian

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	UK	LX.TVS02.024	TM4740G-352G32Mn W7HP64TRGB1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.023	TM4740G-352G32Mn W7HP64TREU5 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RO11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.022	TM4740G-352G32Mn W7HP64TREU5 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PL71	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS02.021	TM4740G-352G32Mn W7HP64TREU4 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Poland	LX.TVS02.020	TM4740G-352G32Mn W7HP64TRPL1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PL71	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Israel	LX.TVS02.019	TM4740G-352G32Mn W7HP64TRIL1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_HE11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740G-352G32Mn	EMEA	Finland	LX.TVS02.018	TM4740G-352G32Mn W7HP64TRFI2 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_FI11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Greece	LX.TVS02.017	TM4740G-352G32Mn W7HP64TRGR1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_EL31	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Greek (KB.I140A.241)	Continental
TM4740G-352G32Mn	EMEA	Cyprus	LX.TVS02.016	TM4740G-352G32Mn W7HP64TRCY1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-354G32Mn	AAP	Singapore	LX.TVS03.148	TM4740G-354G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	SO2GBII I10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-332G25Mn	AAP	Singapore	LX.TVS03.147	TM4740G-332G25Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G25Mn	AAP	Singapore	LX.TVS03.145	TM4740G-352G25Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G16Mn	AAP	Singapore	LX.TVS03.144	TM4740G-352G16Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/160/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N160G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-332G16Mn	AAP	Singapore	LX.TVS03.143	TM4740G-332G16Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/160/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N160G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-332G32Mn	AAP	Singapore	LX.TVS03.142	TM4740G-332G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-432G32Mn	AAP	Singapore	LX.TVS03.141	TM4740G-432G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-434G50Mn	AAP	Singapore	LX.TVS03.140	TM4740G-434G50Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 2*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-524G50Mn	AAP	Singapore	LX.TVS03.139	TM4740G-524G50Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 2*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-524G32Mn	AAP	Singapore	LX.TVS03.138	TM4740G-524G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO2GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-434G32Mn	AAP	Singapore	LX.TVS03.137	TM4740G-434G32Mn W7PR32TRSG1 MC XPP N11MGE1512Css_3V3 2*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO2GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-353G25Mn	EMEA	Latvia	LX.TVS03.136	TM4740G-353G25Mn W7PR32TRLV1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Norway	LX.TVS03.135	TM4740G-353G25Mn W7PR32TRNO3 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Nordic (KB.I140A.246)	Danish/ Continental
TM4740G-353G25Mn	EMEA	Luxembourg	LX.TVS03.134	TM4740G-353G25Mn W7PR32TRLU3 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Swiss/G (KB.I140A.253)	Continental
TM4740G-353G25Mn	EMEA	Poland	LX.TVS03.133	TM4740G-353G25Mn W7PR32TRPL1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-353G25Mn	EMEA	Switzerland	LX.TVS03.132	TM4740G-353G25Mn W7PR32TRCH1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Swiss/G (KB.I140A.253)	Swiss
TM4740G-353G25Mn	EMEA	Holland	LX.TVS03.131	TM4740G-353G25Mn W7PR32TRNL1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-353G25Mn	EMEA	France	LX.TVS03.130	TM4740G-353G25Mn W7PR32TRFR1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES82	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-353G25Mn	EMEA	Spain	LX.TVS03.129	TM4740G-353G25Mn W7PR32TRES1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES52	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Spanish (KB.I140A.251)	Continental
TM4740G-353G25Mn	EMEA	Germany	LX.TVS03.128	TM4740G-353G25Mn W7PR32TRDE1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-353G25Mn	EMEA	Israel	LX.TVS03.127	TM4740G-353G25Mn W7PR32TRIL1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_HE32	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Baltic	LX.TVS03.126	TM4740G-353G25Mn W7PR32TRBC4 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mn	EMEA	Israel	LX.TVS03.125	TM4740G-353G25Mn W7PR32TRIL1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_HE53	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740G-353G25Mn	EMEA	Norway	LX.TVS03.124	TM4740G-353G25Mn W7PR32TRNO1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_NO12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Norwegian (KB.I140A.247)	Continental
TM4740G-353G25Mn	EMEA	UK	LX.TVS03.123	TM4740G-353G25Mn W7PR32TRGB1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.122	TM4740G-353G25Mn W7PR32TREU5 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_RO12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.121	TM4740G-353G25Mn W7PR32TREU4 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_SV22	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.120	TM4740G-353G25Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-353G25Mn	EMEA	Cyprus	LX.TVS03.119	TM4740G-353G25Mn W7PR32TRCY1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES63	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.118	TM4740G-353G25Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_SL12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.117	TM4740G-353G25Mn W7PR32TREU5 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-353G25Mn	EMEA	Hungary	LX.TVS03.116	TM4740G-353G25Mn W7PR32TRHU1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_HU12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Hungarian (KB.I140A.242)	Continental
TM4740G-353G25Mn	EMEA	Greece	LX.TVS03.115	TM4740G-353G25Mn W7PR32TRGR1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_EL32	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Greek (KB.I140A.241)	Continental
TM4740G-353G25Mn	EMEA	Sweden	LX.TVS03.114	TM4740G-353G25Mn W7PR32TRSE1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-353G25Mn	EMEA	Italy	LX.TVS03.113	TM4740G-353G25Mn W7PR32TRIT1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_IT11	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Italian (KB.I140A.243)	Italian
TM4740G-353G25Mn	EMEA	Belgium	LX.TVS03.112	TM4740G-353G25Mn W7PR32TRBE1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Belgium (KB.I140A.233)	Continental
TM4740G-353G25Mn	EMEA	Latvia	LX.TVS03.111	TM4740G-353G25Mn W7PR32TRLV1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_RU22	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mn	EMEA	Austria	LX.TVS03.110	TM4740G-353G25Mn W7PR32TRAT1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-353G25Mn	EMEA	Finland	LX.TVS03.109	TM4740G-353G25Mn W7PR32TRFI2 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.108	TM4740G-353G25Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENQ2	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-353G25Mn	EMEA	Eastern Europe	LX.TVS03.107	TM4740G-353G25Mn W7PR32TREU3 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mn	EMEA	Baltic	LX.TVS03.106	TM4740G-353G25Mn W7PR32TRBC5 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-353G25Mn	EMEA	Baltic	LX.TVS03.105	TM4740G-353G25Mn W7PR32TRBC3 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-353G25Mn	EMEA	Denmark	LX.TVS03.104	TM4740G-353G25Mn W7PR32TRDK2 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740G-353G25Mn	EMEA	Czech	LX.TVS03.103	TM4740G-353G25Mn W7PR32TRCZ2 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_SK12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	CZ/SK (KB.I140A.235)	Continental
TM4740G-353G25Mn	EMEA	Portugal	LX.TVS03.102	TM4740G-353G25Mn W7PR32TRPT1 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_PT12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.101	TM4740G-353G25Mn EM W7PR32EMTRME9 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR52	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.099	TM4740G-353G25Mn EM W7PR32EMTRME2 MC XPP N11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Algeria	LX.TVS03.098	TM4740G-353G25MnEM W7PR32EMTRDZ1MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/Arabic(KB.I140A.238)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.097	TM4740G-353G25MnEM W7PR32EMTRMEBMC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic(KB.I140A.232)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.096	TM4740G-353G25MnEM W7PR32EMTRME3MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French(KB.I140A.239)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.095	TM4740G-353G25MnEM W7PR32EMTRMEBMC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic(KB.I140A.232)	Continental
TM4740G-353G25Mn	EMEA	South Africa	LX.TVS03.094	TM4740G-353G25MnEM W7PR32EMTRZA6MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_PT11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Portuguese(KB.I140A.248)	Continental
TM4740G-353G25Mn	EMEA	South Africa	LX.TVS03.092	TM4740G-353G25MnEM W7PR32EMTRZA1MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French(KB.I140A.239)	Continental
TM4740G-353G25Mn	EMEA	South Africa	LX.TVS03.091	TM4740G-353G25MnEM W7PR32EMTRZA2MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International(KB.I140A.257)	AF
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.090	TM4740G-353G25MnEM W7PR32EMTRME2MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_AR21	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic(KB.I140A.232)	UK and US-110V
TM4740G-353G25Mn	EMEA	South Africa	LX.TVS03.089	TM4740G-353G25MnEM W7PR32EMTRZA5MC XPPN11MGE1512Css_3V32G+1G/250/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	SO1GBII10	N250GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International(KB.I140A.257)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.088	TM4740G-353G25Mn EM W7PR32EMTRME4 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mn	EMEA	South Africa	LX.TVS03.087	TM4740G-353G25Mn EM W7PR32EMTRZA4 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.086	TM4740G-353G25Mn EM W7PR32EMTRME9 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-353G25Mn	EMEA	Middle East	LX.TVS03.085	TM4740G-353G25Mn EM W7PR32EMTRME6 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-353G25Mi	EMEA	Russia	LX.TVS03.084	TM4740G-353G25Mi W7PR32RUTRRU1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mn	EMEA	Ukraine	LX.TVS03.083	TM4740G-353G25Mn W7PR32RUTRUK1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bgn_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-353G25Mi	EMEA	Russia	LX.TVS03.082	TM4740G-353G25Mi W7PR32RUTRRU1 MC XPP N11MGE1512Css_3V3 2G+1G/250/BT/6L2.2/ 5R/ na_bg_1.3C_AN_RU65	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N250G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS02.015	TM4740G-352G32Mn EM W7HP64EMTRZA1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.014	TM4740G-352G32Mn EM W7HP64EMTRME6 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Turkey	LX.TVS02.013	TM4740G-352G32MnEM W7HP64EMTRTR1MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_TR31	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Turkish (KB.I140A.255)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS02.012	TM4740G-352G32MnEM W7HP64EMTRZA5MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.011	TM4740G-352G32MnEM W7HP64EMTRME3MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS02.010	TM4740G-352G32MnEM W7HP64EMTRZA4MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS02.009	TM4740G-352G32MnEM W7HP64EMTRZA2MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	AF
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.008	TM4740G-352G32MnEM W7HP64EMTRMEBMCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.007	TM4740G-352G32MnEM W7HP64EMTRME2MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.006	TM4740G-352G32MnEM W7HP64EMTRME9MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.005	TM4740G-352G32MnEM W7HP64EMTRME4MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_RU61	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.004	TM4740G-352G32MnEM W7HP64EMTRME2MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_AR11	Ci3350M	NLED14WXGA	N11MGE1	512M-DDR3(64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS02.003	TM4740G-352G32MnEM W7HP64EMTRME2 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-352G32Mn	EMEA	Ukraine	LX.TVS02.002	TM4740G-352G32Mn W7HP64RUTRUK1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mi	EMEA	Russia	LX.TVS02.001	TM4740G-352G32Mi W7HP64RUTRRU1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Israel	LX.TVS03.081	TM4740G-352G32Mn W7PR32TRIL1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_HE32	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS03.080	TM4740G-352G32Mn W7PR32TRBC4 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Israel	LX.TVS03.079	TM4740G-352G32Mn W7PR32TRIL1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_HE53	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International w/ Hebrew (KB.I140A.258)	Israel
TM4740G-352G32Mn	EMEA	Norway	LX.TVS03.078	TM4740G-352G32Mn W7PR32TRNO1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_NO12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Norwegian (KB.I140A.247)	Continental
TM4740G-352G32Mn	EMEA	UK	LX.TVS03.077	TM4740G-352G32Mn W7PR32TRGB1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.076	TM4740G-352G32Mn W7PR32TREU5 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RO12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.075	TM4740G-352G32Mn W7PR32TREU4 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_SV22	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBIII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.074	TM4740G-352G32Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES62	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-352G32Mn	EMEA	Cyprus	LX.TVS03.073	TM4740G-352G32Mn W7PR32TRCY1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES63	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	UK (KB.I140A.256)	UK
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.072	TM4740G-352G32Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_SL12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.071	TM4740G-352G32Mn W7PR32TREU5 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Hungary	LX.TVS03.070	TM4740G-352G32Mn W7PR32TRHU1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_HU12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Hungarian (KB.I140A.242)	Continental
TM4740G-352G32Mn	EMEA	Greece	LX.TVS03.069	TM4740G-352G32Mn W7PR32TRGR1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_EL32	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Greek (KB.I140A.241)	Continental
TM4740G-352G32Mn	EMEA	Sweden	LX.TVS03.068	TM4740G-352G32Mn W7PR32TRSE1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Italy	LX.TVS03.067	TM4740G-352G32Mn W7PR32TRIT1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_IT11	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Italian (KB.I140A.243)	Italian
TM4740G-352G32Mn	EMEA	Belgium	LX.TVS03.066	TM4740G-352G32Mn W7PR32TRBE1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Belgium (KB.I140A.233)	Continental
TM4740G-352G32Mn	EMEA	Latvia	LX.TVS03.065	TM4740G-352G32Mn W7PR32TRLV1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU22	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Austria	LX.TVS03.064	TM4740G-352G32Mn W7PR32TRAT1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-352G32Mn	EMEA	Finland	LX.TVS03.063	TM4740G-352G32Mn W7PR32TRFI2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_FI12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-352G32Mi	EMEA	Russia	LX.TVS03.062	TM4740G-352G32Mi W7PR32RUTRRU1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Ukraine	LX.TVS03.061	TM4740G-352G32Mn W7PR32RUTRUK1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mi	EMEA	Russia	LX.TVS03.060	TM4740G-352G32Mi W7PR32RUTRRU1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bg_1.3C_AN_RU65	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Latvia	LX.TVS03.059	TM4740G-352G32Mn W7PR32TRLV1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Norway	LX.TVS03.058	TM4740G-352G32Mn W7PR32TRNO3 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740G-352G32Mn	EMEA	Luxembourg	LX.TVS03.057	TM4740G-352G32Mn W7PR32TRLU3 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Swiss/G (KB.I140A.253)	Continental
TM4740G-352G32Mn	EMEA	Poland	LX.TVS03.056	TM4740G-352G32Mn W7PR32TRPL1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PL72	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Switzerland	LX.TVS03.055	TM4740G-352G32Mn W7PR32TRCH1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_IT42	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Swiss/G (KB.I140A.253)	Swiss
TM4740G-352G32Mn	EMEA	Holland	LX.TVS03.054	TM4740G-352G32Mn W7PR32TRNL1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_NL12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	France	LX.TVS03.053	TM4740G-352G32Mn W7PR32TRFR1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES82	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	Spain	LX.TVS03.052	TM4740G-352G32Mn W7PR32TRES1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES52	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Spanish (KB.I140A.251)	Continental
TM4740G-352G32Mn	EMEA	Germany	LX.TVS03.051	TM4740G-352G32Mn W7PR32TRDE1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_DE62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	German (KB.I140A.240)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.050	TM4740G-352G32Mn W7PR32TREU7 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENQ2	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	SLO/CRO (KB.I140A.250)	Continental
TM4740G-352G32Mn	EMEA	Eastern Europe	LX.TVS03.049	TM4740G-352G32Mn W7PR32TREU3 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS03.048	TM4740G-352G32Mn W7PR32TRBC5 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_LT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Baltic	LX.TVS03.047	TM4740G-352G32Mn W7PR32TRBC3 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_SV21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Sweden (KB.I140A.252)	Continental
TM4740G-352G32Mn	EMEA	Denmark	LX.TVS03.046	TM4740G-352G32Mn W7PR32TRDK2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENS2	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Nordic (KB.I140A.246)	Danish/Continental
TM4740G-352G32Mn	EMEA	Czech	LX.TVS03.045	TM4740G-352G32Mn W7PR32TRCZ2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_SK12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	CZ/SK (KB.I140A.235)	Continental
TM4740G-352G32Mn	EMEA	Portugal	LX.TVS03.044	TM4740G-352G32Mn W7PR32TRPT1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PT12	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Portuguese (KB.I140A.248)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.043	TM4740G-352G32Mn EM W7PR32EMTRME9 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR52	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.042	TM4740G-352G32Mn EM W7PR32EMTRME2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-352G32Mn	EMEA	Algeria	LX.TVS03.041	TM4740G-352G32Mn EM W7PR32EMTRDZ1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.040	TM4740G-352G32Mn EM W7PR32EMTRMEB MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.039	TM4740G-352G32Mn EM W7PR32EMTRME3 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.038	TM4740G-352G32Mn EM W7PR32EMTRMEB MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.037	TM4740G-352G32Mn EM W7PR32EMTRZA6 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Portuguese (KB.I140A.248)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.035	TM4740G-352G32Mn EM W7PR32EMTRZA1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.034	TM4740G-352G32Mn EM W7PR32EMTRMEB MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.033	TM4740G-352G32Mn EM W7PR32EMTRZA6 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_PT11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Portuguese (KB.I140A.248)	Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.031	TM4740G-352G32Mn EM W7PR32EMTRZA1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.030	TM4740G-352G32Mn EM W7PR32EMTRZA2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	AF
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.029	TM4740G-352G32Mn EM W7PR32EMTRME2 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.028	TM4740G-352G32Mn EM W7PR32EMTRZA5 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.027	TM4740G-352G32Mn EM W7PR32EMTRME4 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.026	TM4740G-352G32Mn EM W7PR32EMTRZA4 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.025	TM4740G-352G32Mn EM W7PR32EMTRME9 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.024	TM4740G-352G32Mn EM W7PR32EMTRME6 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.023	TM4740G-352G32Mn EM W7PR32EMTRME9 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR52	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/ Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.022	TM4740G-352G32Mn EM W7PR32EMTRME2 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_AR11	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mn	EMEA	Algeria	LX.TVS03.021	TM4740G-352G32MnEM W7PR32EMTRDZ1MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.020	TM4740G-352G32MnEM W7PR32EMTRMEBMCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ARA1	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.019	TM4740G-352G32MnEM W7PR32EMTRME3MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	French (KB.I140A.239)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.018	TM4740G-352G32MnEM W7PR32EMTRZA2MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	AF
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.017	TM4740G-352G32MnEM W7PR32EMTRME2MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_AR21	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.016	TM4740G-352G32MnEM W7PR32EMTRZA5MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.015	TM4740G-352G32MnEM W7PR32EMTRME4MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_RU62	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	South Africa	LX.TVS03.014	TM4740G-352G32MnEM W7PR32EMTRZA4MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ENA1	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.013	TM4740G-352G32MnEM W7PR32EMTRME9MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES81	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	FR/Arabic (KB.I140A.238)	Continental
TM4740G-352G32Mn	EMEA	Middle East	LX.TVS03.012	TM4740G-352G32MnEM W7PR32EMTRME6MCN11MGE1512Css_3V31*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	Ci3350M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-352G32Mi	EMEA	Russia	LX.TVS03.011	TM4740G-352G32Mi W7PR32RUTRRU1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bg_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mn	EMEA	Ukraine	LX.TVS03.010	TM4740G-352G32Mn W7PR32RUTRUK1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_RU61	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-352G32Mi	EMEA	Russia	LX.TVS03.009	TM4740G-352G32Mi W7PR32RUTRRU1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bg_1.3C_AN_RU65	Ci3350M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi BG	BT 2.1	HM55	6CELL2.2	90W	1.3M	Russian (KB.I140A.249)	Continental
TM4740G-433G32Mn	WW	WW	S2.TVS03.002	TM4740G-433G32Mn W7PR32TWW1 MC N11MGE1512Css_3V3 2G+1G/320/6L2.2/5R/ CB_bgn_1.3C_AN_ES62	Ci5430M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-332G16Mn	AAP	Singapore	LX.TVS03.007	TM4740G-332G16Mn W7PR32TRSG1 MC N11MGE1512Css_3V3 1*2G/160/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N160G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-522G32Mn	AAP	Singapore	LX.TVS03.005	TM4740G-522G32Mn W7PR32TRSG1 MC N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-433G32Mn	WW	GCTWN	S2.TVS03.001	TM4740G-433G32Mn W7PR32TWW1 MC N11MGE1512Css_3V3 2G+1G/320/6L2.2/5R/ CB_bgn_1.3C_AN_ES61	Ci5430M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	SO1GBII I10	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-332G32Mn	TWN	GCTWN	LX.TVS03.002	TM4740G-332G32Mn W7PR32TRTW1 MC XPP N11MGE1512Css_3V3 1*2G/320/BT/6L2.2/5R/ CB_bgn_1.3C_AN_TC11	Ci3330M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740G-432G50Mn	TWN	GCTWN	LX.TVS03.001	TM4740G-432G50Mn W7PR32TRTW1 MC XPP N11MGE1512Css_3V3 1*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_TC11	Ci5430M	NLED14 WXGA	N11M GE1	512M-DDR3 (64*16 *4)	SO2GBII I10	N	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Chinese (KB.I140A.236)	US-110V (BSMI)
TM4740G-332G16Mn	WW	GCTWN	S2.TVS0C.001	TM4740G-332G16Mn LINPUSTWW1 N11MGE1512Cbb_3V3 2*1G/160/6L2.2/5R/ CB_bgn_1.3C_AN_ENX1	Ci3330M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO1GBII I10	SO1GBII I10	N160G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-332G16Mn	WW	WW	S2.TVS0C.002	TM4740G-332G16Mn LINPUSTWW1 N11MGE1512Cbb_3V3 2*1G/160/6L2.2/5R/ CB_bgn_1.3C_AN_EN11	Ci3330M	NLED14 WXGAG	N11M GE1	512M-DDR3 (64*16 *4)	SO1GBII I10	SO1GBII I10	N160G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-332G16Mn	EMEA	Middle East	LX.TW201.001	TM4740G-332G16Mn EM W7HB64EMTRME2 MC N11MGE1512GCss_3V31*2G/160/BT/6L2.2/5R/ CB_bgn_1.3C_F33-900_AN_AR21	Ci3330M	NLED14 WXGAG	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N160GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-332G50Mn	WW	GCTWN	S2.TW203.001	TM4740G-332G50Mn W7PR32TWW1 MC XPP N11MGE1512GCss_3V31*2G/500_L/6L2.2/5R/ na_bgn_1.3C_E77W_AN_ES61	Ci3330M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-332G50Mn	WW	WW	S2.TW203.002	TM4740G-332G50Mn W7PR32TWW1 MC XPP N11MGE1512GCss_3V31*2G/500_L/6L2.2/5R/ na_bgn_1.3C_E77W_AN_ES62	Ci3330M	NLED14 WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII I10	N	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-522G32Mn	AAP	Thailand	LX.TVR03.009	TM4740G-522G32Mn EM W7PR32EMTRTH1 MC N11PGE11GBCss_3V31*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH41	Ci5520M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-432G32Mn	AAP	Singapore	LX.TVR03.008	TM4740G-432G32Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V31*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-352G32Mn	AAP	Singapore	LX.TVR03.007	TM4740G-352G32Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V31*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-332G32Mn	AAP	Singapore	LX.TVR03.006	TM4740G-332G32Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V31*2G/320/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-334G50Mn	AAP	Singapore	LX.TVR03.005	TM4740G-334G50Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V32*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3330M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-354G50Mn	AAP	Singapore	LX.TVR03.004	TM4740G-354G50Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V32*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci3350M	NLED14 WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1 (GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740G-434G50Mn	AAP	Singapore	LX.TVR03.003	TM4740G-434G50Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V3 2*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5430M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-524G50Mn	AAP	Singapore	LX.TVR03.002	TM4740G-524G50Mn W7PR32TRSG1 MC XPP N11PGE11GBCss_3V3 2*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_ZH31	Ci5520M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	UK
TM4740G-432G32Mn	EMEA	Middle East	LX.TVR0C.001	TM4740G-432G32Mn LINPUSTME2 N11PGE11GBCss_3V3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_EN13	Ci5430M	NLED14 WXGAG	N11P GE1	1G-DDR3 (64*16*8)	SO2GBII I10	N	N320G B5.4K S	NSM8X S	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740G-524G50Mn	AAP	Thailand	LX.TVR03.001	TM4740G-524G50Mn EM W7PR32EMTRTH1 MC N11PGE11GBCss_3V3 2*2G/500_L/BT/6L2.2/5R/ na_bgn_1.3C_AN_TH41	Ci5520M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	Thailand (KB.I140A.254)	US-110V
TM4740G-338G64Bn	WW	WW	S2.TVR02.002	TM4740G-338G64Bn W7HP64TWW1 MC N11PGE11GBCbb_3V3 2*4G/640/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES62	Ci3330M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO4GBII I10	SO4GBII I10	N640G B5.4K S	NBDCB 4XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-338G64Bn	WW	GCTWN	S2.TVR02.001	TM4740G-338G64Bn W7HP64TWW1 MC N11PGE11GBCbb_3V3 2*4G/640/BT/6L2.2/5R/ na_bgn_1.3C_AN_ES61	Ci3330M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO4GBII I10	SO4GBII I10	N640G B5.4K S	NBDCB 4XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-524G50Mn	WW	WW	S2.TW102.002	TM4740G-524G50Mn W7HP64TWW1 MC N11PGE11GBGCss_3V3 2*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES62	Ci5520M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO2GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-526G50Mn	WW	WW	S2.TW102.001	TM4740G-526G50Mn W7HP64TWW1 MC N11PGE11GBGCss_3V3 4G+2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES62	Ci5520M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO4GBII I10	SO2GBII I10	N500G B5.4K S	NSM8X S	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-338G64Bn	WW	WW	S2.TW10C.002	TM4740G-338G64Bn LINPUSTWW1 N11PGE11GBGCss_3V3 2*4G/640/BT/6L2.2/5R/ na_bgn_1.3C_E77W_AN_EN11	Ci3330M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO4GBII I10	SO4GBII I10	N640G B5.4K S	NBDCB 4XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740G-338G64Bn	WW	GCTWN	S2.TW10C.001	TM4740G-338G64Bn LINPUSTWW1 N11PGE11GBGCss_3V3 2*4G/640/BT/6L2.2/5R/ na_bgn_1.3C_E77W_AN_ENX1	Ci3330M	NLED14 WXGA	N11P GE1	1G-DDR3 (64*16*8)	SO4GBII I10	SO4GBII I10	N640G B5.4K S	NBDCB 4XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental

Downloaded from www.Manualslib.com manuals search engine

Travelmate 4740Z

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740Z-P602G32Mnss	AAP	Philippines	LX.TXW01.001	TM4740Z-P602G32Mnss EM W7HB64EMTRPH1 MC UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_ES61	PMDP6000	NLED14WXGA	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740Z-P602G32Mnss	AAP	Philippines	LX.TXW0C.007	TM4740Z-P602G32Mnss LINPUS MTPH1 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGA	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US-110V
TM4740Z-P602G32Mns	EMEA	Middle East	LX.TXW0C.006	TM4740Z-P602G32Mns LINPUS MTME2 UMACss_3 1*2G/320/BT/6L2.2/5R/na_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGA	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	Arabic (KB.I140A.232)	UK and US-110V
TM4740Z-P604G32Mnss	AAP	India	LX.TXW0C.005	TM4740Z-P604G32Mnss LINPUS MTIN1 UMACss_3 2*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGAG	UMA	N	SO2GBII10	SO2GBII10	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740Z-P602G32Mnss	AAP	India	LX.TXW0C.004	TM4740Z-P602G32Mnss LINPUS MTIN1 UMACss_3 1*2G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGAG	UMA	N	SO2GBII10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740Z-P603G32Mnss	AAP	India	LX.TXW0C.003	TM4740Z-P603G32Mnss LINPUS MTIN1 UMACss_3 2G+1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGAG	UMA	N	SO2GBII10	SO1GBII10	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740Z-P601G32Mnss	AAP	India	LX.TXW0C.002	TM4740Z-P601G32Mnss LINPUS MTIN1 UMACss_3 1*1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_XS11	PMDP6000	NLED14WXGAG	UMA	N	SO1GBII10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	South Africa-S (India)
TM4740Z-P601G32Mnss	AAP	Indonesia	LX.TXW0C.001	TM4740Z-P601G32Mnss LINPUS MTID1 UMACss_3 1*1G/320/BT/6L2.2/5R/CB_bgn_1.3C_AN_ID32	PMDP6000	NLED14WXGAG	UMA	N	SO1GBII10	N	N320GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	Europe
TM4740Z-P606G32Mn	WW	WW	S2.TXW02.001	TM4740Z-P606G32Mn W7HP64TWW1 MC UMACss_3 2G+4G/320/6L2.2/5R/na_bgn_1.3C_AN_ES62	PMDP6000	NLED14WXGA	UMA	N	SO2GBII10	SO4GBII10	N320GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740Z-P604G50Mn	WW	GCTWN	S2.TXZ02.001	TM4740Z-P604G50Mn W7HP64TWW1 MC UMAGCss_3 2*2G/500_L/6L2.2/5R/CB_bgn_1.3C_F33-900_AN_ES61	PMDP6000	NLED14WXGAG	UMA	N	SO2GBII10	SO2GBII10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental

Downloaded from www.Manualslib.com manuals search engine

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740Z-P604G50Mn	WW	WW	S2.TXZ02.002	TM4740Z-P604G50Mn W7HP64TWW1 MC UMAGCss_3 2*2G/500_L/6L2.2/5R/CB_bgn_1.3C_F33-900_AN_ES62	PMDP6000	NLED14WXGAG	UMA	N	SO2GBII10	SO2GBII10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	65W	1.3M	US International (KB.I140A.257)	US and Continental

Travelmate 4740ZG

Model	RO	Country	Acer Part No	Description	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	HDD 1(GB)	ODD	Extra SW1	Card Reader	Wireless LAN1	Bluetooth	NB Chipset	Battery	Adapter	Camera	K/B	Power Cord
TM4740ZG-P604G50Mn	WW	WW	S2.TXS02.001	TM4740ZG-P604G50Mn W7HP64TWW1 MC N11MGE1512Css_3V3 2*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_AN_ES62	PMDP6000	NLED14WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO2GBII10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 3.0	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740ZG-P604G50Mn	WW	WW	S2.TXT02.001	TM4740ZG-P604G50Mn W7HP64TWW1 MC N11MGE1512GCss_3V3 2*2G/500_L/6L2.2/5R/na_bgn_1.3C_F33-900_AN_ES62	PMDP6000	NLED14WXGA	N11MGE1	512M-DDR3 (64*16*4)	SO2GBII10	SO2GBII10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740ZG-P604G50Mn	WW	GCTWN	S2.TXU02.001	TM4740ZG-P604G50Mn W7HP64TWW1 MC N11PGE11GBCss_3V3 2*2G/500_L/6L2.2/5R/na_bgn_1.3C_AN_ES61	PMDP6000	NLED14WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII10	SO2GBII10	N500GB5.4KS	NSM8XS	McAfee	5 in 1-Build in	3rd WiFi 2x2 BGN	N	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental
TM4740ZG-P602G50Mn	WW	WW	S2.TXV0C.001	TM4740ZG-P602G50Mn LINPUSTWW1 N11PGE11GBGCss_3V3 1*2G/500_L/BT/6L2.2/5R/na_bgn_1.3C_F33-900_AN_EN11	PMDP6000	NLED14WXGA	N11PGE1	1G-DDR3 (64*16*8)	SO2GBII10	N	N500GB5.4KS	NSM8XS	N	5 in 1-Build in	3rd WiFi 2x2 BGN	BT 2.1	HM55	6CELL2.2	90W	1.3M	US International (KB.I140A.257)	US and Continental

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Appendix B

Test Compatible Components

This computer's compatibility is tested and verified by Acer's internal testing department. All of its system functions are tested under compatible Windows® operating system for each model.

Refer to the following lists for components, adapter cards, and peripherals which have passed these tests. Regarding configuration, combination and test procedures, please refer to the Compatibility Test Report released by the Acer Mobile System Testing Department.

Downloaded from www.Manualslib.com manuals search engine

Hardware Device Tests

Item	Device name	Vendor
I/O peripherals		
Access Point	Air Station Wireless NFINITI [ModeNum:WZR-G144N], 802.11n/g/b	Buffalo
	Buffalo Air Station NFINITI [ModeNum:WZR2-G300N], 802.11n/g/b	Buffalo
Bluetooth Access Point	Bluetooth Access Point [ModeNum:BT300]	X Bridge
Bluetooth Devices	Bluetooth Stereo Headset [ModeNum:HT820]	Motorola
	Bluetooth mouse [ModeNum:097855020512]	Logitech
	Motorola Bluetooth Wireless Headset H300	Motorola
	Sony Ericsson Stereo Bluetooth Headset HBH-DS970	Sony
External LCD	P243W 24-inch LCD Monitor	Acer
	P244W 24-inch LCD Monitor	Acer
	SP2208WFP 22-inch LCD Monitor	Dell
	UltraSharp 3008WFP 30-inch LCD Monitor	Dell
	2407FPW 24-inch LCD Monito	Dell
	UltraSharp E2408WFP 24-inch widescreen HDMI	Dell
Earphone / Microphone	Hawk Stereo Headset 933	Hawk
Projector	3300MP Projector	Dell
SIM Card	FarEasTone 3G SIM Card	FarEasTone
	Chunghwa Telecom 3G SIM Card	Chunghwa Telecom
TV	W37G (HDMI)	Westenhouse
	TC-37MPK (VGA/HDMI)	Panasonic
USB 3G Card	Huawei mobile connect E220 USB Modem 3G (E220: HSDPA/ UMTS/EDGE/GPRS/GSM)	Huawei
USB Camera	Canon Digital IXUS 860 IS Digital Compact Camera (8.0 Megapixel CCD sensor/DIGIC III with Face Detection AF/AE/FE/ 28mm wide-angle lens with optical Image Stabilizer, Media storage:SD,SDHC,MMC,MMCplus, built-in SD32MB)	Canon
USB Flash Drive	Transcend JetFlash USB2.0 Flash Drive V85 8GB Memory Key	Transcend
	Apacer AH421 8GB	Apacer
	A-Data PD16 Vista 16GB	A-Data
	Transcend JetFlash USB2.0 Flash Drive V10 16GB Memory Key	Transcend
USB HDD	2.5-inch Portable 80GB Hard Disk	Transcend
USB Hub and Others	Huawei mobile connect E220 USB Modem 3G (E220: HSDPA/ UMTS/EDGE/GPRS/GSM)	Huawei
	PowerSync USB2.0 4-Port mini HUB(HU151W White)	PowerSync
	Techworks 4-Port USB2.0 Mini HUB(OW4PTUSBHB)	Techworks
USB Keyboard / Mouse	First Wheel Mouse	Logitech
	Internet Navigator Keyboard	Logitech
	Dell L30U 0N242F USB Keybaord	Dell
USB ODD	DVD+R/RW (Usb2.0)	Plextor
USB Printer	HP Deskjet F4280 All-in-One:Printer/ Scanner/Copier, 1200x2400dpi)	HP
USB Speaker / Joystick	iFun USB Speaker(JS1200UA)	JS
	Dell USB Speaker	Dell
USB Storage Drive	6 IN 1 Flash Card Reader/Writer	PQI

Downloaded from www.Manualslib.com manuals search engine

Item	Device name	Vendor
Wireless Printer	Photosmart C309 (CC35A) All-in-One Printer (4x6 photos/CD/ DVD/Quick Forms)/Scanner/Copier/Fax) Port: USB2.0/Ethernet/PictBridge/802.11g/BT	HP
	Photosmart C4580 All-in-One Printer (4x6 photos) /Scanner/ Copier Port:USB2.0/802.11g.b/Memory Card	HP
Memory Card		
Memory Stick	High speed 1GB Memory stick Pro Duo	Lexar
	MS PRO Dou 2GB High Speed	SONY
	MS PRO 2GB Memory Card	SONY
	SanDisk Meomry Stick Micro (M2) 8GB Card	SanDisk
Multimedia Card	RS-MMC 128MB Memory Card	Sandisk
	RS-MMC Mobile 256MB Memory Card	PQI
	Transcend MMC plus 4GB Card	Transcend
	Turbo 200X 2GB MMC Card	A-DATA
SD Card	4GB SD PRO Memory Card	RiDATA
	SanDisk multi-use SD Class2 Memory Card 2GB	SanDisk
	SD card 2GB (150x Hi-Speed)	Apacer
	SanDisk microSDHC 4GB Card with Adapter	SanDisk
	Kingston SDHC SD4 32GB Card	Kingston
XD Card	OLYMPUS XD-Picture Card M+ 2GB Speed Card	OLYMPUS
	FUJIFLM XD-Picture Card TypeM 2GB	FUJIFLM

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Appendix C

Online Support Information

This section describes online technical support services available to help you repair your Acer products.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer branch offices and regional business units can access our website. However some information sources will require a user ID and password. These can be obtained directly from Acer CSD Taiwan.

Acer's website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all Acer notebook, desktop and server models including:

- Service guides for all models
- User's manuals
- Bios updates
- Software utilities
- Spare parts lists
- TABs (Technical Announcement Bulletin)

For these purposes, we have included a PDF File to facilitate the problem-free downloading of our technical material.

Also available on this website are:

- Detailed information on Acer's International Traveller's Warranty (ITW)
- Returned material authorization procedures
- An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

B

Back Cover
removing 39
Basic Input/Output System, see BIOS 23
Battery Pack
removing 38
BIOS 16
Phoenix SecureCore Setup Utility 23
vendor 16
version 16
BIOS Recovery 87
BIOS Recovery by Crisis Disk 87
steps 87
BIOS setup utility
General Help window 25
Item Specific Help panel 25
navigation keys 25
BIOS Utility
Boot 31
Exit 32
Information 26
Main 27
Security 28
Block Diagram 81
Bluetooth Module
removing 54
brightness
hotkeys 12

C

Card Reader Dummy Card
removing 38
Clearing BIOS Password
steps 85
Clearing Password 85
computer
on indicator 11, 12
Crisis Disk 33
creating 87

D

DIMM Modules
removing 41
display
hotkeys 12

E

Environmental Requirements 21
Error Symptom-to-Spare Part Index 68
External CD-ROM Drive Check 66
External Module Disassembly
Flowchart 37

F

Flash Utility 87
FRU (Field Replaceable Unit) List 89

H

Hard disk 18
Hard Disk Drive Module
removing 39
hardware
configuration utility 23
HDD 18
Heatsink Fan Module
removing 56
Hibernation mode
hotkey 12
hotkeys 12
HW Gap position 85

I

Intermittent Problems 79

J

Jumper and Connector Locations
Top View 82

K

Keyboard
hotkeys 12
removing 45
Keyboard or Auxiliary Input Device Check 66

L

LCD Bezel
removing 60
LCD Hinges

Downloaded from www.Manualslib.com manuals search engine

removing 62
LCD Module
removing 51
LCD Module Disassembly
Flowchart 59
LCD Panel
removing 61

M

Main Unit Disassembly
Flowchart 43
Mainboard 82
removing 55
media access
on indicator 12
Memory Check 67
menu
Exit 32
Information 26
Security 28
Microphone
removing 63
Model Definition 100

N

notebook tour 11

O

Online Support Information 97
Optical drive
removing 44

P

password
changing 29
removing 29
resetting 30
setting 29
Phoenix SecureCore Setup Utility 23
Physical Specifications 21
Power Board
removing 49
Power System Check 67
Battery Pack 68
Power Adapter 67
Processor
removing 57

R

RTC battery
BIOS error 23

S

Screw List 36
speakers
hotkey 12
Specifications
3G Module 16
AC Adapter 20
Battery Pack 20
BIOS 16
Bluetooth 17
Ethernet 16
Hard Disk Drive 18
LCD Panel 19
Power Management 20
Processor 15
System Chipsets 15
System Controllers 15
System Memory 17
Video 16
Webcam 20
Wireless LAN 16
System
Block Diagram 81
System Architecture 81
System Check Procedures 66
System Utilities 23

T

Test Compatible Components 93
Touchpad Board
removing 51
Touchpad Check 68
Troubleshooting 65
TV Tuner Board 39

U

Undetermined Problems 80
Unlocking HDD 86
Updating BIOS 33
Upper Case
removing 45
USB Board
removing 53

Downloaded from www.Manualslib.com manuals search engine

V

view
base 14
front 13
left 13
right 13
top 11

W

Webcam Module
removing 62
WLAN Antennas
removing 63
WLAN Module
removing 41

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine